

DaVinci Deluxe 1.0.44 — Cloud Edition

SUPPORTED ECU LIST — MODULES & TUNING

Latest update: 18 September 2026

58
BRANDS

3209
ECUs

30
MODULES

22
TUNING OPTIONS

CAPABILITIES — EVERY MODULE & TUNING OPTION IN THE CATALOG

Performance Tuning (22)

Stage1

Stage2

E85 Conversion

VMAX

Stage1+

Pops&Bangs

Torque Monitor

Stage3

Exhaust Valve OFF

HardCut

RPM Soft Limiter Removal

Gearbox Tuning

Launch Control Activation

Hotstart

Pops&Bangs (Switchable)

Cylinder On Demand OFF

Sport Displays Calibration

Hot Start Fix

Anti-Lag

Boost Increase

Eco Tune

Rev Limiter Raise

Emissions & Diagnostics (30)

EGR

DPF

LAMBDA

DTC Off

CAT/KAT

FLAPS (Swirl)

TVA

Adblue

EVAP

Start-Stop

Readiness Calibration

NOX

MAF

GPF/OPF

SAP

Water Pump

Active Grill Shutter (AGS)

Decat

Oil Pressure Fix

Glow Plug

LIMP

Ignition Cut

EGT Off

Cold Start Delete

Farts (GOLF 7 SIMOS18)

Multimap

Stage2+

TVA Off

Smoke Limiter Off

Swirl Flaps Off

Immo & Security (4)

Immo Off (FLASH)

Immo Off (EPROM)

TPROT

FCA Unlock

ABARTH

29 ECU

96F	E85 Conversion	Stage1	Adblue	CAT/KAT	DPF	DTC Off	EGR	EVAP	LAMBDA
GPEC2	Pops&Bangs	VMAX	CAT/KAT	EVAP	LAMBDA				
GPEC2A	Cylinder On Demand OFF	Stage1	CAT/KAT	EGR	EVAP	FLAPS (Swirl)	LAMBDA	FCA Unlock	
GPEC3	Active Grill Shutter (AGS)	CAT/KAT	FLAPS (Swirl)	LAMBDA					
GPEC4	Stage1	CAT/KAT	DTC Off	EVAP	LAMBDA				
IAW4SF	Immo Off (FLASH)								
ME17.3.0	E85 Conversion	Pops&Bangs	Stage1	Stage2	DTC Off				
ME17.3.X	E85 Conversion	Pops&Bangs	Pops&Bangs (Switchable)	Stage1	Stage1+	Stage2	CAT/KAT	LAMBDA	
ME2.8	Stage1								
ME3.1	Stage1								
ME7	E85 Conversion								
ME7.3	Stage1								
ME7.3.1	E85 Conversion	Stage1	Stage2	Stage3					
ME7.3.2	E85 Conversion								
ME7.4.5	Stage1								
ME7.6	Stage1								
ME7.6.2	E85 Conversion								
ME7.9.10	E85 Conversion	Pops&Bangs	Stage1	Stage1+	VMAX	CAT/KAT	LAMBDA		
ME9.1	Stage1								
MED17	Pops&Bangs	Stage1	Stage3	CAT/KAT					
MED17.3	E85 Conversion								
MED17.3.0	E85 Conversion								
MED17.3.1	Stage1								
MED17.3.30	Stage1								
MED17.3.5	Stage1								
MED17.6.9	Stage1								
MED7.1.1	Stage1								
MED7.6.2	Stage1								
MM8GMF	CAT/KAT	LAMBDA							

ALFA ROMEO

60 ECU

96F	E85 Conversion	Stage1	Adblue	CAT/KAT	DPF	DTC Off	EGR	EVAP	LAMBDA
CRD2.X	FLAPS (Swirl)								
EDC15	Stage1	Stage2	DPF	EGR					
EDC15C2	Stage1	Stage2	VMAX	DPF	EGR				

EDC15C5	Stage1	Stage2											
EDC15C6	Stage1												
EDC15C7	Stage1	Stage1+	Stage2	Stage3	DTC Off	EGR	Immo Off (FLASH)						
EDC16	Stage1												
EDC16C31	E85 Conversion	Stage1											
EDC16C31-CP31	Stage1	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration	TVA				
EDC16C34	Stage1	Stage2	DPF	EGR									
EDC16C39	E85 Conversion	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	TVA
	Immo Off (FLASH)												
EDC16C8	E85 Conversion	Stage1	Stage1+	Stage2	DPF	EGR							
EDC16C9	Stage1	DTC Off											
EDC16CP31	Stage1	DPF	EGR										
EDC16U31	Stage1	Stage1+	Stage2	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA				
EDC16V2	Stage1												
EDC17	Pops&Bangs	Stage1											
EDC17C09	Stage1												
EDC17C10	Stage1	DPF											
EDC17C49	Launch Control Activation	Stage1	Stage1+	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA		
	NOX	TVA											
EDC17C69	E85 Conversion	Stage1	Stage1+	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	
	Readiness Calibration	Start-Stop	TVA	Immo Off (FLASH)									
EDC17C79	Stage1	Stage2	Torque Monitor	VMAX	Active Grill Shutter (AGS)	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	
	TVA												
EDC17CP04	Stage1												
EDC17CP14	Stage1												
EDC17CP27	Stage1	Stage1+	Torque Monitor	DPF	EGR	FLAPS (Swirl)	Immo Off (EPROM)						
EDC17CP52	E85 Conversion	Stage1	Torque Monitor	VMAX	Adblue	DPF	EGR	LAMBDA	NOX	Immo Off (EPROM)			
GPEC2	Pops&Bangs	VMAX	CAT/KAT	EVAP	LAMBDA								
GPEC2A	Cylinder On Demand OFF	Stage1	CAT/KAT	EGR	EVAP	FLAPS (Swirl)	LAMBDA	FCA Unlock					
GPEC3	Active Grill Shutter (AGS)	CAT/KAT	FLAPS (Swirl)	LAMBDA									
GPEC4	Stage1	CAT/KAT	DTC Off	EVAP	LAMBDA								
IAW4SF	Immo Off (FLASH)												
MARELLI	Stage1	Stage1+	DPF	EGR									
ME17.3.0	E85 Conversion	Pops&Bangs	Stage1	Stage2	DTC Off								
ME17.3.X	E85 Conversion	Pops&Bangs	Pops&Bangs (Switchable)	Stage1	Stage1+	Stage2	CAT/KAT	LAMBDA					
ME2.8	Stage1												
ME3.1	Stage1												
ME7	E85 Conversion												
ME7.3	Stage1												
ME7.3.1	E85 Conversion	Stage1	Stage2	Stage3									
ME7.3.2	E85 Conversion												
ME7.4.5	Stage1												
ME7.6	Stage1												
ME7.6.2	E85 Conversion												
ME7.9.10	E85 Conversion	Pops&Bangs	Stage1	Stage1+	VMAX	CAT/KAT	LAMBDA						
ME9.1	Stage1												
MED17	Pops&Bangs	Stage1	Stage3	CAT/KAT									
MED17.3	E85 Conversion												
MED17.3.0	E85 Conversion												
MED17.3.1	Stage1												
MED17.3.30	Stage1												
MED17.3.5	Stage1												
MED17.6.9	Stage1												
MED7.1.1	Stage1												
MED7.6.2	Stage1												
MJ8DF	HardCut	Stage1	VMAX	Adblue	CAT/KAT	DPF	EGR	FLAPS (Swirl)	Glow Plug	LAMBDA	MAF	Start-Stop	TVA
MJ9DF	E85 Conversion	Stage1	Stage1+	Stage2	VMAX	Adblue	CAT/KAT	DPF	EGR	LAMBDA	NOX	Start-Stop	TVA
	Immo Off (FLASH)												
MJD6F	HardCut	Stage1	Stage2	VMAX	DPF	DTC Off	EGR	LAMBDA	MAF				
MM8GMF	CAT/KAT	LAMBDA											

SID803A

Stage1 DPF EGR EVAP

ASTON MARTIN

1 ECU

GEN1024K

Stage1

AUDI

250 ECU

CRD3.X	Adblue
DCM3.5	Stage1
DCM3.7	E85 Conversion Stage1 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA TVA Water Pump
DCM6.2	E85 Conversion Exhaust Valve OFF Stage1 Stage1+ VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Start-Stop Water Pump
DELPHI	Stage1
DL501	Gearbox Tuning Stage1
DQ200	Gearbox Tuning Stage1
DQ200G2	Gearbox Tuning Stage1
DQ250	Gearbox Tuning Launch Control Activation Stage1 Stage1+
DQ381	Gearbox Tuning Pops&Bangs Stage1
DQ38X	Gearbox Tuning Stage1
DQ500	Gearbox Tuning Stage1 Stage2
DSG AL551	Gearbox Tuning Stage1 Stage1+
EDC15	E85 Conversion Hotstart Launch Control Activation Pops&Bangs Stage1 Stage1+ Stage2 Stage3 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) MAF Multimap TVA
EDC15C	Stage1
EDC15C4	Stage1
EDC15C5	Stage1
EDC15C6	Stage1 Stage2
EDC15P	Stage1 Stage2 VMAX MAF
EDC15V	Stage1
EDC15VM	Stage1 Stage2 DPF
EDC15VMP	Stage1
EDC16	E85 Conversion Stage1 Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF
EDC16C0	Stage1 Stage2 DTC Off MAF
EDC16C1	Stage1
EDC16C10	Stage1
EDC16C2	Stage1
EDC16C3	Stage1
EDC16C31	E85 Conversion Stage1 Stage1+ Stage2 DPF DTC Off EGR FLAPS (Swirl) MAF
EDC16C32	E85 Conversion Stage1 Stage2 DPF
EDC16C34	E85 Conversion Stage1 Stage2 VMAX DPF EGR FLAPS (Swirl)
EDC16C35	Stage1 VMAX
EDC16C36	Stage1
EDC16C39	Stage1
EDC16C4	Stage1 Stage2 VMAX EGR
EDC16C7	Stage1
EDC16C8	Stage1
EDC16C9	Stage1
EDC16CAN	Stage1
EDC16CP31	E85 Conversion Stage1 Stage2 DPF
EDC16CP34	E85 Conversion Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA
EDC16CP35	Stage1
EDC16CP36	Stage1 Stage2 DPF
EDC16CP39	Stage1
EDC16CP42	Stage1
EDC16U1	E85 Conversion Gearbox Tuning HardCut Hot Start Fix Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA Immo Off (FLASH)
EDC16U2	Stage1 Stage2
EDC16U2.1	Stage1

EDC16U3	Stage1
EDC16U31	E85 ConversionHardCutHotstartRPM Soft Limiter RemovalStage1Stage1+Stage2Stage3VMAXDPFDTC Off EGREGT OffFLAPS (Swirl)LAMBDAMAFTVAImmo Off (EPROM)
EDC16U34	E85 ConversionHardCutHot Start FixHotstartStage1Stage1+Stage2Stage3VMAXAdblueDPFDTC OffEGR FLAPS (Swirl)LAMBDAMAFTVAImmo Off (EPROM)
EDC16UC40	Stage1
EDC16V2	Stage1DPFEGR
EDC17	E85 ConversionPops&BangsStage1Stage1+Stage2VMAXAdblueCAT/KATDPFDTC OffEGRFLAPS (Swirl)
EDC17121	Stage1
EDC17521	Stage1
EDC17C01	Stage1
EDC17C06	Stage1
EDC17C08	Stage1
EDC17C10	Stage1DPFEGR
EDC17C18	Stage1
EDC17C19	Stage1
EDC17C41	Stage1
EDC17C42	DPFEGR
EDC17C43	Stage1
EDC17C43-CP46	Stage1
EDC17C46	E85 ConversionPops&BangsStage1Stage1+Stage2Torque MonitorVMAXAdblueCAT/KATDecatDPFDTC Off EGRFLAPS (Swirl)LAMBDALIMPMAFNOXReadiness CalibrationStart-StopTVAWater PumpImmo Off (FLASH)
EDC17C49	Stage1DPFEGRLAMBDA TVA
EDC17C54	E85 ConversionExhaust Valve OFFStage1Stage2Stage3Torque MonitorVMAXAdblueDPFDTC OffEGR FLAPS (Swirl)LAMBDA NOXOil Pressure FixReadiness CalibrationStart-StopTVAWater PumpImmo Off (FLASH)
EDC17C60	Stage1AdblueDPF
EDC17C64	E85 ConversionExhaust Valve OFFHardCutPops&BangsStage1Stage1+Stage2Torque MonitorVMAXAdblue CAT/KATDPFDTC OffEGRFLAPS (Swirl)LAMBDAMAFNOXReadiness CalibrationStart-StopTVAWater Pump Immo Off (FLASH)TPROT
EDC17C66	E85 ConversionStage1
EDC17C69	Stage1
EDC17C74	E85 ConversionHardCutStage1Stage1+Stage2Torque MonitorVMAXActive Grill Shutter (AGS)AdblueCAT/KATDPF DTC OffEGRFLAPS (Swirl)LAMBDA NOXReadiness CalibrationStart-StopTVAWater PumpImmo Off (FLASH)TPROT
EDC17C79	Stage1
EDC17CP01	Stage1DPFEGR
EDC17CP02	Stage1DPFLAMBDAReadiness Calibration
EDC17CP04	E85 ConversionHardCutStage1Stage2Torque MonitorVMAXDPFDTC OffEGRFLAPS (Swirl)LAMBDA Readiness CalibrationTVAImmo Off (FLASH)
EDC17CP10	Stage1Stage2DPFEGR
EDC17CP11	Stage1
EDC17CP14	E85 ConversionHardCutRPM Soft Limiter RemovalStage1Stage1+Stage2Stage3Torque MonitorVMAXAdblue DecatDPFDTC OffEGRFLAPS (Swirl)LAMBDA NOXReadiness CalibrationStage2+Start-StopTVAWater Pump Immo Off (FLASH)
EDC17CP20	E85 ConversionStage1Stage1+Stage2Torque MonitorVMAXAdblueDPFDTC OffEGRFLAPS (Swirl)LAMBDA NOXReadiness CalibrationStart-StopTVAWater PumpImmo Off (FLASH)
EDC17CP24	Exhaust Valve OFFStage1Stage2VMAXAdblueDPFEGRFLAPS (Swirl)LAMBDAReadiness CalibrationTVA
EDC17CP42	Stage1
EDC17CP44	E85 ConversionExhaust Valve OFFHardCutPops&BangsStage1Stage1+Stage2Stage3Torque MonitorVMAX AdblueDPFDTC OffEGRFLAPS (Swirl)LAMBDA NOXOil Pressure FixReadiness CalibrationStart-StopTVAImmo Off (FLASH)
EDC17CP46	Stage1Stage2
EDC17CP54	Stage1Stage2VMAXAdblueDPFEGRFLAPS (Swirl)LAMBDA NOXOil Pressure FixReadiness CalibrationStart-StopTVA
EDC17CP57	Stage1Stage2Adblue
EDC17CP74	E85 ConversionStage1VMAXAdblueDPFDTC OffEGRFLAPS (Swirl)LAMBDA NOXReadiness CalibrationStart-Stop TVAWater Pump
EDC17CV52	Stage1
EDC17U01	Stage1Stage2DTC Off
EDC17U01-05	Stage1Stage1+Stage2Torque MonitorDPFEGRFLAPS (Swirl)LAMBDA TVA
EDC17U05	Stage1
IAW4MV	E85 ConversionPops&BangsStage1Stage1+Stage2CAT/KATDPFEGRLAMBDA
MARELLI	Pops&BangsStage1Stage1+Stage2CAT/KATDTC OffEGRLAMBDA
MD1CP001	Stage1

MD1CP004	Stage1 Stage2 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop TVA
MD1CP014	Stage1 VMAX Adblue DPF EGR FLAPS (Swirl) NOX Start-Stop
MD1CS004	Hotstart Stage1 Stage1+ VMAX Adblue DPF DTC Off EGR LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop
MD1CS006	Stage1 Adblue
MD1CS014	Stage1 Adblue DPF EGR LAMBDA Oil Pressure Fix Start-Stop
MDG1	Stage1
ME17	E85 Conversion Stage1 TVA
ME17.5.2	E85 Conversion Stage1 DTC Off TVA
ME17.5.20	E85 Conversion Stage1 DTC Off TVA
ME17.5.20-26	Cylinder On Demand OFF E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX CAT/KAT DTC Off EGR EVAP LAMBDA Readiness Calibration Immo Off (EPROM) Immo Off (FLASH)
ME17.5.24	Stage1
ME17.5.26	E85 Conversion
ME17.5.2X	Stage1
ME17.5.6	E85 Conversion Pops&Bangs Stage1 Stage2 CAT/KAT DTC Off EVAP LAMBDA Readiness Calibration
ME2.0	Stage1
ME2.7	Stage1
ME2.7.1	Stage1
ME2.7.2	Stage1
ME2.8	Stage1
ME2.8.1	Stage1 Stage2
ME3	Stage1
ME3.8	Stage1 Stage2 DPF
ME3.8.1	Stage1
ME5.2	Stage1
ME5.9.2	Stage1
ME7	E85 Conversion Stage1 Stage2
ME7.1	E85 Conversion Stage1 Stage2 Stage3 VMAX
ME7.1-ME7.1.1	E85 Conversion HardCut Pops&Bangs Stage1 Stage1+ Stage2 Stage3 VMAX Adblue CAT/KAT DPF DTC Off EVAP Ignition Cut LAMBDA
ME7.1.1	E85 Conversion Stage1 Stage2 Stage3 VMAX Decat LAMBDA
ME7.1.5	Stage1
ME7.2	Stage1 Stage2
ME7.3.2	Stage1
ME7.5	Anti-Lag E85 Conversion Launch Control Activation Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 VMAX Adblue CAT/KAT DPF DTC Off EGR EVAP LAMBDA MAF SAP TVA
ME7.5.10	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 CAT/KAT DTC Off EGR EVAP LAMBDA
ME7.8	E85 Conversion Stage1 Stage2
ME7.8.2	Stage1
ME9	Stage1 Stage2
ME9.1	Stage1 Stage2 VMAX
ME9.1.1	Stage1 Stage2
ME9.5	Pops&Bangs Stage1 Stage1+ Stage2 Adblue DTC Off EGR LAMBDA
ME9.7	Stage1 Stage2
MED17	E85 Conversion Pops&Bangs Stage1 VMAX CAT/KAT DPF EGR
MED17.1	E85 Conversion Exhaust Valve OFF HardCut Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA Readiness Calibration SAP TVA TPROT
MED17.1.1	Cylinder On Demand OFF E85 Conversion Exhaust Valve OFF Pops&Bangs Stage1 Stage1+ Stage2 VMAX CAT/KAT DPF DTC Off EVAP FLAPS (Swirl) GPF/OPF LAMBDA Readiness Calibration SAP Start-Stop TVA Immo Off (FLASH)
MED17.1.10	Stage1 Stage2
MED17.1.11	Stage1 Stage2
MED17.1.15	E85 Conversion
MED17.1.2	E85 Conversion Stage1 CAT/KAT EVAP LAMBDA Readiness Calibration
MED17.1.21	E85 Conversion Stage1
MED17.1.27	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX Active Grill Shutter (AGS) CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA
MED17.1.6	Stage1 Stage2
MED17.1.61	Stage1

MED17.1.62	E85 Conversion Stage1 Stage2
MED17.1.63	Stage1
MED17.1.6X	E85 Conversion Pops&Bangs Pops&Bangs (Switchable) RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 VMAX Active Grill Shutter (AGS) Adblue CAT/KAT Decat DPF DTC Off EGR EVAP FLAPS (Swirl) GPF/OPF LAMBDA Readiness Calibration SAP TVA Immo Off (FLASH)
MED17.5	E85 Conversion Hot Start Fix Launch Control Activation Pops&Bangs Pops&Bangs (Switchable) RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX Adblue CAT/KAT DPF DTC Off EGR EVAP FLAPS (Swirl) LAMBDA MAF Readiness Calibration TVA Immo Off (FLASH)
MED17.5.1	E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX CAT/KAT DTC Off FLAPS (Swirl) LAMBDA Readiness Calibration
MED17.5.2	E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX CAT/KAT EVAP FLAPS (Swirl) LAMBDA Readiness Calibration Start-Stop TVA
MED17.5.20	E85 Conversion Pops&Bangs Stage1 Stage2
MED17.5.20-26	Cylinder On Demand OFF E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA Readiness Calibration TVA Immo Off (FLASH)
MED17.5.21	Cylinder On Demand OFF E85 Conversion Pops&Bangs Stage1 Stage2 DTC Off TVA
MED17.5.25	E85 Conversion Pops&Bangs Stage1 Stage2 FLAPS (Swirl) TVA
MED17.5.5	E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX CAT/KAT DTC Off FLAPS (Swirl) LAMBDA Readiness Calibration Start-Stop TVA Immo Off (FLASH)
MED17.5.53	E85 Conversion Pops&Bangs Stage1 Stage2 DTC Off
MED17.5.X	Stage1 Stage2
MED17.6.9	Stage1
MED17.7	Stage1 Stage2
MED17.7.1	Stage1
MED17.7.2	Stage1 Stage2
MED17.7.3	Stage1 Stage2
MED17.7.3.1	Stage1
MED17.7.5	Stage1
MED17.7.7	Stage1
MED7.5.11	E85 Conversion Pops&Bangs Stage1 CAT/KAT EGR NOX
MED9	E85 Conversion Stage1
MED9.1	E85 Conversion Exhaust Valve OFF HardCut Launch Control Activation Pops&Bangs Pops&Bangs (Switchable) RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 VMAX Adblue CAT/KAT Cold Start Delete Decat DPF DTC Off EGR EVAP FLAPS (Swirl) LAMBDA MAF TVA Immo Off (FLASH)
MED9.1.1	E85 Conversion Stage1 DTC Off
MED9.1.2	E85 Conversion Stage1
MED9.1.3	E85 Conversion Stage1
MED9.1.4	E85 Conversion Stage1
MED9.1.5	E85 Conversion Stage1 Stage2
MED9.5	E85 Conversion Stage1
MED9.5.10	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Immo Off (FLASH)
MED9.6	Stage1
MED9.6.1	Stage1 Stage2
MED9.7	Stage1
MEDC17	Pops&Bangs Stage1 Stage2 Adblue DPF DTC Off EGR Immo Off (FLASH)
MEDC17521	Stage1
MEVD17.2	Stage1
MG1CP002	Stage1
MG1CP007	Pops&Bangs Stage1 Stage2 CAT/KAT EVAP GPF/OPF LAMBDA Start-Stop
MG1CS001	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX Active Grill Shutter (AGS) CAT/KAT EVAP FLAPS (Swirl) LAMBDA SAP
MG1CS002	E85 Conversion Exhaust Valve OFF Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX CAT/KAT DPF EVAP FLAPS (Swirl) GPF/OPF LAMBDA SAP Start-Stop
MG1CS008	Exhaust Valve OFF Pops&Bangs Stage1 Stage2 CAT/KAT EVAP FLAPS (Swirl) GPF/OPF LAMBDA
MG1CS011	Cylinder On Demand OFF E85 Conversion Pops&Bangs Stage1 Stage1+ Torque Monitor VMAX CAT/KAT EVAP GPF/OPF LAMBDA Start-Stop
MG1CS031	Pops&Bangs RPM Soft Limiter Removal Torque Monitor CAT/KAT EVAP FLAPS (Swirl) LAMBDA
MG1CS111	E85 Conversion Pops&Bangs Stage1 Stage1+ VMAX CAT/KAT EVAP GPF/OPF LAMBDA Readiness Calibration
MS6.2	Stage1
MSA15	Stage1

MSB15	Stage1
PCR2.1	E85 Conversion HardCut Launch Control Activation Pops&Bangs Stage1 Stage1+ Stage2 Stage3 VMAX Adblue Decat DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF Readiness Calibration Start-Stop TVA Water Pump
PPD1.2	DPF
PPD1.X	Hotstart Launch Control Activation Stage1 Stage1+ Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA Immo Off (FLASH)
SDI10	VMAX CAT/KAT LAMBDA
SDI3	CAT/KAT DPF LAMBDA
SDI6/7/8/9	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 CAT/KAT EVAP LAMBDA
SID3	Stage2
SID307	Stage1
SID310	DPF EGR
SID9	Stage1 Stage2
SIM05	Stage1 Stage2 DPF DTC Off Immo Off (FLASH)
SIM0510	E85 Conversion Stage1
SIM0510.10	E85 Conversion Stage1 Stage2 VMAX
SIM0510.12	Stage1
SIM0510.1X	E85 Conversion Stage1
SIM0510.2	Stage1
SIM0510.22	Stage1
SIM0510.23	Stage1
SIM0510.24	Stage1
SIM0510.2X	E85 Conversion Pops&Bangs Stage1 Stage2
SIM0510.X	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX CAT/KAT DPF EGR EVAP FLAPS (Swirl) LAMBDA MAF Start-Stop
SIM0511.X	E85 Conversion Pops&Bangs CAT/KAT EVAP FLAPS (Swirl) LAMBDA
SIM0512	E85 Conversion Pops&Bangs Stage1 Stage2 CAT/KAT DTC Off TVA
SIM0512.1	E85 Conversion Pops&Bangs
SIM0512.2	E85 Conversion Stage1
SIM0512.X	E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA
SIM0516.X	CAT/KAT EVAP LAMBDA SAP
SIM0518	E85 Conversion Pops&Bangs Stage1 Stage2 VMAX CAT/KAT DTC Off
SIM0518.1	E85 Conversion Pops&Bangs Stage1
SIM0518.10	E85 Conversion Pops&Bangs Stage1 Stage2 VMAX
SIM0518.2	Stage1 DTC Off
SIM0518.4	Stage1
SIM0518.6	E85 Conversion
SIM0518.X	E85 Conversion Exhaust Valve OFF Launch Control Activation Pops&Bangs Pops&Bangs (Switchable) RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX Active Grill Shutter (AGS) CAT/KAT DPF DTC Off EVAP Farts (GOLF 7 SIMOS18) FLAPS (Swirl) GPF/OPF LAMBDA Readiness Calibration SAP Start-Stop TVA Immo Off (FLASH)
SIM0519.X	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX Adblue CAT/KAT EVAP FLAPS (Swirl) GPF/OPF LAMBDA SAP Start-Stop TVA
SIM052	E85 Conversion Stage1 Stage2
SIM053	E85 Conversion Stage1 Stage2
SIM053.2	Stage1
SIM053.3	E85 Conversion
SIM053.X	E85 Conversion Stage1 Stage2 CAT/KAT EGR LAMBDA
SIM054	Stage1
SIM056.2	E85 Conversion
SIM056.X	E85 Conversion Stage1 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA
SIM057.1	E85 Conversion Stage1
SIM057.X	E85 Conversion Pops&Bangs Stage1 CAT/KAT EGR LAMBDA
SIM058	E85 Conversion Stage1
SIM058.2	E85 Conversion Stage1
SIM058.3	Stage1
SIM058.4	E85 Conversion Stage1 Stage2 VMAX DTC Off LAMBDA
SIM058.5	E85 Conversion Stage1 Stage2 TVA
SIM058.X	E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage2 Stage3 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA SAP TVA

SIMOS9.1	E85 Conversion	Stage1		
SIMOS9.X	E85 Conversion	Stage1	CAT/KAT	LAMBDA
TEMIC	Gearbox Tuning	Stage1	Stage2	DPF

BENTLEY

1 ECU

ME7.1.1	Stage1
---------	--------

BMW

88 ECU

DCM3.7	Stage1																						
EDC15	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	DPF	EGR	FLAPS (Swirl)	MAF												
EDC15C4	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	Immo Off (EPROM)	Immo Off (FLASH)										
EDC15C6	Stage1																						
EDC15P	Stage1	Stage2																					
EDC16	Stage1																						
EDC16C1	EGR																						
EDC16C31	E85 Conversion	Gearbox Tuning	HardCut	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	Smoke Limiter Off	TVA	Immo Off (FLASH)			
EDC16C35	E85 Conversion	HardCut	Stage1	Stage1+	Stage2	Stage3	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	TVA									
EDC16CP35	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	Readiness Calibration	TVA							
EDC16CP39	Stage1																						
EDC17	Stage1	Stage2	Adblue	CAT/KAT	DPF	DTC Off	EGR																
EDC17C06	E85 Conversion	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	DPF	EGR	FLAPS (Swirl)	LAMBDA	MAF	NOX	Start-Stop	Immo Off (FLASH)							
EDC17C41	E85 Conversion	HardCut	RPM Soft Limiter Removal	Sport Displays Calibration	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop	TVA				
EDC17C42	DPF																						
EDC17C50	Stage1	Stage2	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)															
EDC17C50-C56	E85 Conversion	HardCut	Launch Control Activation	Pops&Bangs	RPM Soft Limiter Removal	Sport Displays Calibration	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop	TVA	Immo Off (FLASH)
EDC17C56	E85 Conversion	Stage1	Stage2	DPF	DTC Off	EGR																	
EDC17C76	VMAX	DPF	EGR	FLAPS (Swirl)	LAMBDA	NOX	TVA																
EDC17CP02	HardCut	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration	Start-Stop	Swirl Flaps Off	TVA	TPROT				
EDC17CP09	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration	Start-Stop	TVA								
EDC17CP45	E85 Conversion	Stage1	Stage2	Adblue	DPF	DTC Off	EGR	TVA															
EDC17CP45-CP49	Sport Displays Calibration	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop	TVA	Immo Off (FLASH)						
EDC17CP49	Stage1	Stage2	Adblue	DPF																			
EMS2	Stage1																						
MARELLI	Stage1																						
MD1CP002	Sport Displays Calibration	Stage1	Stage2	Stage3	Torque Monitor	VMAX	Adblue	DPF	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration											
MD1CP032	DPF	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration	TVA																	
MD1CS001	Sport Displays Calibration	Stage1	Stage2	Torque Monitor	VMAX	Active Grill Shutter (AGS)	Adblue	CAT/KAT	DPF	EGR	FLAPS (Swirl)	LAMBDA	LIMP	NOX	Readiness Calibration	TVA	TVA Off						
ME7	E85 Conversion	Stage1																					
ME7.1	E85 Conversion	Stage1																					
ME7.1-ME7.1.1	E85 Conversion	Stage1	CAT/KAT	DTC Off	LAMBDA																		
ME7.2	E85 Conversion	Stage1	Stage2	VMAX																			
ME9	E85 Conversion	Stage1	Stage2	VMAX	DTC Off																		
ME9.0	E85 Conversion	Stage1																					
ME9.1	E85 Conversion	Stage1																					
ME9.2	E85 Conversion	Stage1	VMAX	DTC Off																			
ME9.2.2	E85 Conversion																						

ME9.4	E85 Conversion	Stage1	DPF															
ME9.6	Stage1																	
ME9.8	Stage1																	
ME9.X	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DTC Off	LAMBDA									
MED17	E85 Conversion	Stage1	Stage2	CAT/KAT	EGR													
MED17.1.1	E85 Conversion	Stage1	Stage2															
MED17.2	E85 Conversion	Stage1	Stage2															
MED17.2.2	E85 Conversion	Stage1																
MED9	E85 Conversion																	
MED9.1.5	E85 Conversion	Stage1																
MEV17.2	E85 Conversion	Stage1																
MEV17.2.2	E85 Conversion																	
MEV17.4	E85 Conversion	Stage1																
MEV17.4.6	E85 Conversion	Stage1																
MEV9.1	E85 Conversion																	
MEV9.2	E85 Conversion																	
MEV9.4.6	E85 Conversion	Stage1																
MEVD17.2	E85 Conversion	Pops&Bangs	Pops&Bangs (Switchable)	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DPF	DTC Off	FLAPS (Swirl)	LAMBDA						
MEVD17.2.2	E85 Conversion	Stage1	CAT/KAT															
MEVD17.2.3	E85 Conversion	Pops&Bangs	Sport Displays Calibration	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DTC Off	EVAP	LAMBDA	Readiness Calibration	SAP	Start-Stop				
MEVD17.2.4	Pops&Bangs	Sport Displays Calibration	Stage1	Stage2	VMAX	CAT/KAT	EVAP	LAMBDA	Readiness Calibration									
MEVD17.2.5	E85 Conversion	Pops&Bangs	Sport Displays Calibration	Stage1	Stage2	VMAX	CAT/KAT	FLAPS (Swirl)	LAMBDA	Readiness Calibration	Start-Stop							
MEVD17.2.6	E85 Conversion	Pops&Bangs	Sport Displays Calibration	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	LAMBDA									
MEVD17.2.8	Pops&Bangs	Pops&Bangs (Switchable)	Sport Displays Calibration	Stage1	Stage2	Torque Monitor	VMAX	CAT/KAT	LAMBDA	Readiness Calibration								
MEVD17.2.84	Stage1																	
MEVD17.2.9	E85 Conversion	Pops&Bangs	Pops&Bangs (Switchable)	Sport Displays Calibration	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	CAT/KAT	LAMBDA	Readiness Calibration	Start-Stop					
MEVD17.2.95	Stage1	Stage2																
MEVD17.2.97	Stage1																	
MEVD17.2.98	Stage1																	
MEVD17.2.6	E85 Conversion	Pops&Bangs	Pops&Bangs (Switchable)	Sport Displays Calibration	Stage1	Stage2	VMAX	CAT/KAT	DPF	FLAPS (Swirl)	GPF/OPF	LAMBDA	Start-Stop					
MEVD17.2.H	E85 Conversion	Pops&Bangs	Sport Displays Calibration	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	CAT/KAT	LAMBDA	Start-Stop							
MEVD17.8.4	Stage1																	
MG1CS003	E85 Conversion	Exhaust Valve OFF	Pops&Bangs	Pops&Bangs (Switchable)	Sport Displays Calibration	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DPF	DTC Off	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA	Readiness Calibration	Start-Stop
MG1CS049	Pops&Bangs	Stage1	VMAX	CAT/KAT	GPF/OPF	Start-Stop												
MG1CS201	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	Active Grill Shutter (AGS)	Adblue	CAT/KAT	DTC Off	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA	MAF		
MS41	Pops&Bangs	Stage1	Ignition Cut															
MS42	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	LAMBDA	Immo Off (FLASH)										
MS43	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	CAT/KAT	EVAP	LAMBDA	SAP									
MS45	E85 Conversion	Pops&Bangs	Stage1	CAT/KAT	DTC Off	EVAP	LAMBDA											
MSD80	E85 Conversion	Pops&Bangs	Pops&Bangs (Switchable)	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	CAT/KAT	DTC Off	EGR	EVAP	FLAPS (Swirl)	LAMBDA	NOX	TVA
MSD81	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Adblue	CAT/KAT	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	TVA				
MSD85	E85 Conversion	Pops&Bangs	Stage1	VMAX	CAT/KAT	EVAP	FLAPS (Swirl)	LAMBDA	NOX	TVA								
MSD87	Stage1	VMAX	Adblue	CAT/KAT	LAMBDA													
MSD8X	Stage1	Adblue																
MSS60	Stage1	VMAX	CAT/KAT	DTC Off	LAMBDA													
MSS6X	E85 Conversion	Pops&Bangs	Stage1	Stage2	VMAX	CAT/KAT	DTC Off	EVAP	LAMBDA									
MSV70	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	LAMBDA	MAF					
MSV80	E85 Conversion	Pops&Bangs	Stage1	Stage1+	VMAX	CAT/KAT	EVAP	LAMBDA										
MSV90	Pops&Bangs	Stage1	CAT/KAT	DTC Off	LAMBDA													

[Gearbox Tuning](#)
[Stage1](#)
[Stage1+](#)
[Stage2](#)

2 ECU

Pops&Bangs
Stage1
Stage2
CAT/KAT
DTC Off
LAMBDA

64 ECU

DCM3	Stage1
DCM3.7	Stage1 Adblue DPF EGR FLAPS (Swirl) LAMBDA TVA
DCM7.1	VMAX Adblue DPF EGR LAMBDA NOX Start-Stop
DELCO E37	CAT/KAT EVAP LAMBDA
DELCO E38	Stage1 CAT/KAT EVAP LAMBDA
DELCO E39	E85 Conversion Pops&Bangs Stage1 CAT/KAT EVAP LAMBDA
DELCO E78	E85 Conversion Stage1 Stage2 CAT/KAT LAMBDA
DELCO E80-E84	E85 Conversion Stage1 CAT/KAT LAMBDA
DELCO E83	E85 Conversion Stage1 Stage1+ CAT/KAT EGR LAMBDA
DELCO E87	Pops&Bangs Stage1 CAT/KAT DPF EGR FLAPS (Swirl) LAMBDA
DELCO E92	Stage1 CAT/KAT DPF LAMBDA
DELCO E98	E85 Conversion Stage1 Stage2 VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX TVA
DENS0	Stage1 DPF EGR
E98	Stage1
EDC15	Stage1 Stage1+ Stage2 Stage3 DPF EGR MAF
EDC15C2	Stage1
EDC15C4	Stage1
EDC15C7	Stage1
EDC15V	Stage1
EDC15VM	Stage1 Stage2 DPF EGR
EDC16C3	Stage1 Adblue
EDC16C36	E85 Conversion Stage1 VMAX DPF DTC Off EGR
EDC16C39	E85 Conversion Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) MAF TVA
EDC16C9	E85 Conversion Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA
EDC16CP33	Stage1 Stage2 VMAX DPF DTC Off EGR TVA
EDC17	Stage1 VMAX Adblue DPF
EDC17C01	Stage1
EDC17C11	Stage1 Torque Monitor VMAX DPF EGR LAMBDA
EDC17C18	Stage1 Stage2 EGR
EDC17C18-C19	Stage1 Stage1+ Stage2 Torque Monitor VMAX DPF EGR FLAPS (Swirl) Glow Plug LAMBDA TVA
EDC17C19	Stage1 Stage2 DPF
EDC17C42	Stage1 Stage2 Torque Monitor VMAX DPF EGR
EDC17C59	Stage1 Stage1+ Stage2 Torque Monitor VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA TVA
EDC17C60	Stage1
EDC17C84	Torque Monitor VMAX Adblue DPF EGR LAMBDA NOX Start-Stop TVA
EDC17CP47	Stage1 Torque Monitor Adblue DPF EGR FLAPS (Swirl) LAMBDA TVA
EMS040	DTC Off
MARELLI	Stage1 Stage2 Adblue DPF DTC Off EGR
MD1CS003	Stage1 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA Start-Stop TPROT
ME1.5.5	E85 Conversion Stage1 Stage1+ Stage2 Stage3 CAT/KAT EGR LAMBDA
ME17.8.8	CAT/KAT EVAP LAMBDA
ME3.1.1	Stage1
ME7.6.2	E85 Conversion Stage1 Stage2
ME7.6.3	Stage1 Stage2
ME7.6.4	Stage1
ME7.6.X	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA
ME7.9.9	Stage1
ME9	Stage1
ME9.1	Stage1

ME9.5	Stage1
ME9.6	Stage1 Stage2 DTC Off
ME9.6.1	Stage1
MED9	Stage1
MED9.6.1	Stage1
MG1CS042	Stage1
MJD602-3	HardCut Stage1 Stage1+ Stage2 Adblue DPF EGR MAF
MS56	Stage1
MT35	E85 Conversion Stage1 Stage2 Stage3 CAT/KAT DTC Off EGR EVAP LAMBDA
MT80	CAT/KAT LAMBDA
PSG16	Stage1 DPF DTC Off EGR FLAPS (Swirl) TVA
SH7059	Stage1
SID310	Stage1
SIMTEC7.5	Stage1 CAT/KAT LAMBDA
SIMTEC76	E85 Conversion Stage1 CAT/KAT EGR LAMBDA

CHRYSLER

1 ECU

EDC16	Stage1 EGR
-------	------------

CITROËN

82 ECU

DCM3.4	Stage1 Stage2 DPF EGR NOX Immo Off (EPROM)
DCM3.5	Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA
DCM6.2	E85 Conversion Stage1 Stage1+ Torque Monitor VMAX Adblue DPF EGR FLAPS (Swirl) LAMBDA NOX Start-Stop TVA Immo Off (EPROM)
DCM7	Adblue DPF
DCM7.1	E85 Conversion Stage1 Stage1+ Stage3 Torque Monitor VMAX Adblue CAT/KAT DPF DTC Off EGR LAMBDA NOX
DCU102	Stage1 DPF EGR
DDCR	Stage1 EGR
DELPHI	Stage1 Stage1+ Stage2 DPF DTC Off
EDC15	Stage1 Stage2 VMAX DPF EGR MAF
EDC15C	Stage1
EDC15C2	Stage1 Stage2 VMAX DPF EGR Immo Off (EPROM) Immo Off (FLASH)
EDC15C3-C7	Stage1 Stage2 CAT/KAT EGR MAF Immo Off (FLASH)
EDC15C6	Stage1
EDC15C7	Stage1
EDC16	Stage1 Stage2 DPF
EDC16C0	Stage1 DPF
EDC16C3	Stage1 Stage1+ Stage2 VMAX DPF EGR Glow Plug LAMBDA TVA
EDC16C31	Stage1 DPF
EDC16C32	Stage1
EDC16C34	E85 Conversion HardCut Pops&Bangs Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) Glow Plug LAMBDA MAF TVA Immo Off (FLASH)
EDC16C39	Stage1 Stage2 VMAX DPF EGR LAMBDA MAF TVA
EDC16CP34	Stage1
EDC16CP36	Stage1
EDC16CP39	Stage1 Stage2 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA
EDC16U31	Stage1
EDC17	Stage1 DPF MAF
EDC17C09	Stage1 DPF
EDC17C10	Stage1 Stage1+ Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA Readiness Calibration Start-Stop TVA Immo Off (FLASH)
EDC17C42-CP42	Stage1 Stage1+ Torque Monitor DPF DTC Off EGR FLAPS (Swirl) LAMBDA TVA
EDC17C60	E85 Conversion Stage1 Stage1+ Torque Monitor VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop TVA Immo Off (FLASH) TPROT
EDC17CP04	Stage1
EDC17CP11	Stage1 Torque Monitor DPF EGR
EDC17CP14	Stage1
EDC17CP42	Stage1

EDC17CP52	Stage1	Stage2	VMAX	Adblue	DPF	EGR	LAMBDA					
M7.9.5	Torque Monitor	CAT/KAT	LAMBDA									
MARELLI	Stage1	Stage1+	Stage2									
MD1CS003	Stage1	Torque Monitor	VMAX	Adblue	CAT/KAT	DPF	EGR	FLAPS (Swirl)	LAMBDA	NOX	Start-Stop	Immo Off (FLASH)
	TPROT											
ME17.4	E85 Conversion											
ME7	E85 Conversion	Stage1										
ME7.4.4	E85 Conversion	Stage1										
ME7.4.5	E85 Conversion	Stage1										
ME7.4.6	E85 Conversion											
ME7.4.7	E85 Conversion											
ME7.4.X	E85 Conversion	Stage1	CAT/KAT	LAMBDA								
ME7.5	E85 Conversion											
ME7.9.51	Stage1											
MED17	Stage1	Stage2	DPF	EGR								
MED17.4	E85 Conversion	Stage1										
MED17.4.2	E85 Conversion	Stage1										
MED17.4.4	E85 Conversion	Stage1	Stage2									
MED17.4.X	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	CAT/KAT	DTC Off	EGR	LAMBDA	MAF		
MED17.5.1	Stage1											
MED7.4.4	E85 Conversion											
MED9	Stage1											
MEV17	E85 Conversion	Stage1										
MEV17.4	E85 Conversion											
MEV17.4.2	E85 Conversion	Stage1										
MEVD17.2.2	Stage1											
MEVD17.4.2	Stage1											
MEVD17.4.4	Stage1	Stage2	MAF									
MG1CS042	E85 Conversion	Stage1	VMAX	CAT/KAT	DTC Off	GP/OPF						
MJ8	Stage1	DPF	EGR									
SID201	Stage1	Stage1+	Stage2	DPF	EGR	LAMBDA						
SID206	Stage1											
SID208	E85 Conversion	Pops&Bangs	Stage1	Stage2	VMAX	CAT/KAT	DPF	DTC Off	EGR	LAMBDA	TVA	
SID80	Stage1											
SID801	Stage1											
SID801-804	Pops&Bangs	Stage1	Stage1+	Stage2	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF			
SID801A	Stage1											
SID801X	Stage1											
SID803	E85 Conversion	Stage1	DPF	DTC Off								
SID803-803A	E85 Conversion	Stage1	Stage1+	Stage2	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA	
SID803A	Stage1	DPF										
SID804	Stage1	EGR										
SID805	EGR											
SID806	E85 Conversion	Stage1	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA					
SID807	Stage1	DPF	EGR									
SID807-807EVO	E85 Conversion	Stage1	Stage1+	VMAX	DPF	DTC Off	EGR	LAMBDA	Start-Stop	TVA	Immo Off (FLASH)	
SID80X	Stage1	DPF										
V46	E85 Conversion	Stage1	CAT/KAT	DTC Off	LAMBDA							
VD56	E85 Conversion	Stage1	CAT/KAT	LAMBDA								

CUPRA

250 ECU

CRD3.X	Adblue											
DCM3.5	Stage1											
DCM3.7	E85 Conversion	Stage1	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA	Water Pump	
DCM6.2	E85 Conversion	Exhaust Valve OFF	Stage1	Stage1+	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX
	Start-Stop	Water Pump										
DELPHI	Stage1											
DL501	Gearbox Tuning	Stage1										
DQ200	Gearbox Tuning	Stage1										

DQ200G2	Gearbox Tuning	Stage1											
DQ250	Gearbox Tuning	Launch Control Activation	Stage1	Stage1+									
DQ381	Gearbox Tuning	Pops&Bangs	Stage1										
DQ38X	Gearbox Tuning	Stage1											
DQ500	Gearbox Tuning	Stage1	Stage2										
DSG AL551	Gearbox Tuning	Stage1	Stage1+										
EDC15	E85 Conversion	Hotstart	Launch Control Activation	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	DPF		
	DTC Off	EGR	FLAPS (Swirl)	MAF	Multimap	TVA							
EDC15C	Stage1												
EDC15C4	Stage1												
EDC15C5	Stage1												
EDC15C6	Stage1	Stage2											
EDC15P	Stage1	Stage2	VMAX	MAF									
EDC15V	Stage1												
EDC15VM	Stage1	Stage2	DPF										
EDC15VMP	Stage1												
EDC16	E85 Conversion	Stage1	Stage2	Stage3	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF		
EDC16C0	Stage1	Stage2	DTC Off	MAF									
EDC16C1	Stage1												
EDC16C10	Stage1												
EDC16C2	Stage1												
EDC16C3	Stage1												
EDC16C31	E85 Conversion	Stage1	Stage1+	Stage2	DPF	DTC Off	EGR	FLAPS (Swirl)	MAF				
EDC16C32	E85 Conversion	Stage1	Stage2	DPF									
EDC16C34	E85 Conversion	Stage1	Stage2	VMAX	DPF	EGR	FLAPS (Swirl)						
EDC16C35	Stage1	VMAX											
EDC16C36	Stage1												
EDC16C39	Stage1												
EDC16C4	Stage1	Stage2	VMAX	EGR									
EDC16C7	Stage1												
EDC16C8	Stage1												
EDC16C9	Stage1												
EDC16CAN	Stage1												
EDC16CP31	E85 Conversion	Stage1	Stage2	DPF									
EDC16CP34	E85 Conversion	Hotstart	Stage1	Stage1+	Stage2	Stage3	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF
	TVA												
EDC16CP35	Stage1												
EDC16CP36	Stage1	Stage2	DPF										
EDC16CP39	Stage1												
EDC16CP42	Stage1												
EDC16U1	E85 Conversion	Gearbox Tuning	HardCut	Hot Start Fix	Hotstart	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue		
	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	TVA	Immo Off (FLASH)				
EDC16U2	Stage1	Stage2											
EDC16U2.1	Stage1												
EDC16U3	Stage1												
EDC16U31	E85 Conversion	HardCut	Hotstart	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	VMAX	DPF	DTC Off		
	EGR	EGT Off	FLAPS (Swirl)	LAMBDA	MAF	TVA	Immo Off (EPROM)						
EDC16U34	E85 Conversion	HardCut	Hot Start Fix	Hotstart	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	DPF	DTC Off	EGR
	FLAPS (Swirl)	LAMBDA	MAF	TVA	Immo Off (EPROM)								
EDC16UC40	Stage1												
EDC16V2	Stage1	DPF	EGR										
EDC17	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	
EDC17121	Stage1												
EDC17521	Stage1												
EDC17C01	Stage1												
EDC17C06	Stage1												
EDC17C08	Stage1												
EDC17C10	Stage1	DPF	EGR										
EDC17C18	Stage1												
EDC17C19	Stage1												

EDC17C41	Stage1
EDC17C42	DPF EGR
EDC17C43	Stage1
EDC17C43-CP46	Stage1
EDC17C46	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue CAT/KAT Decat DPF DTC Off EGR FLAPS (Swirl) LAMBDA LIMP MAF NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH)
EDC17C49	Stage1 DPF EGR LAMBDA TVA
EDC17C54	E85 Conversion Exhaust Valve OFF Stage1 Stage2 Stage3 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH)
EDC17C60	Stage1 Adblue DPF
EDC17C64	E85 Conversion Exhaust Valve OFF HardCut Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH) TPROT
EDC17C66	E85 Conversion Stage1
EDC17C69	Stage1
EDC17C74	E85 Conversion HardCut Stage1 Stage1+ Stage2 Torque Monitor VMAX Active Grill Shutter (AGS) Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH) TPROT
EDC17C79	Stage1
EDC17CP01	Stage1 DPF EGR
EDC17CP02	Stage1 DPF LAMBDA Readiness Calibration
EDC17CP04	E85 Conversion HardCut Stage1 Stage2 Torque Monitor VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA Readiness Calibration TVA Immo Off (FLASH)
EDC17CP10	Stage1 Stage2 DPF EGR
EDC17CP11	Stage1
EDC17CP14	E85 Conversion HardCut RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX Adblue Decat DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Stage2+ Start-Stop TVA Water Pump Immo Off (FLASH)
EDC17CP20	E85 Conversion Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH)
EDC17CP24	Exhaust Valve OFF Stage1 Stage2 VMAX Adblue DPF EGR FLAPS (Swirl) LAMBDA Readiness Calibration TVA
EDC17CP42	Stage1
EDC17CP44	E85 Conversion Exhaust Valve OFF HardCut Pops&Bangs Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop TVA Immo Off (FLASH)
EDC17CP46	Stage1 Stage2
EDC17CP54	Stage1 Stage2 VMAX Adblue DPF EGR FLAPS (Swirl) LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop TVA
EDC17CP57	Stage1 Stage2 Adblue
EDC17CP74	E85 Conversion Stage1 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop TVA Water Pump
EDC17CV52	Stage1
EDC17U01	Stage1 Stage2 DTC Off
EDC17U01-05	Stage1 Stage1+ Stage2 Torque Monitor DPF EGR FLAPS (Swirl) LAMBDA TVA
EDC17U05	Stage1
IAW4MV	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 CAT/KAT DPF EGR LAMBDA
MARELLI	Pops&Bangs Stage1 Stage1+ Stage2 CAT/KAT DTC Off EGR LAMBDA
MD1CP001	Stage1
MD1CP004	Stage1 Stage2 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop TVA
MD1CP014	Stage1 VMAX Adblue DPF EGR FLAPS (Swirl) NOX Start-Stop
MD1CS004	Hotstart Stage1 Stage1+ VMAX Adblue DPF DTC Off EGR LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop
MD1CS006	Stage1 Adblue
MD1CS014	Stage1 Adblue DPF EGR LAMBDA Oil Pressure Fix Start-Stop
MDG1	Stage1
ME17	E85 Conversion Stage1 TVA
ME17.5.2	E85 Conversion Stage1 DTC Off TVA
ME17.5.20	E85 Conversion Stage1 DTC Off TVA
ME17.5.20-26	Cylinder On Demand OFF E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX CAT/KAT DTC Off EGR EVAP LAMBDA Readiness Calibration Immo Off (EPROM) Immo Off (FLASH)
ME17.5.24	Stage1
ME17.5.26	E85 Conversion
ME17.5.2X	Stage1

ME17.5.6	E85 Conversion	Pops&Bangs	Stage1	Stage2	CAT/KAT	DTC Off	EVAP	LAMBDA	Readiness Calibration				
ME2.0	Stage1												
ME2.7	Stage1												
ME2.7.1	Stage1												
ME2.7.2	Stage1												
ME2.8	Stage1												
ME2.8.1	Stage1	Stage2											
ME3	Stage1												
ME3.8	Stage1	Stage2	DPF										
ME3.8.1	Stage1												
ME5.2	Stage1												
ME5.9.2	Stage1												
ME7	E85 Conversion	Stage1	Stage2										
ME7.1	E85 Conversion	Stage1	Stage2	Stage3	VMAX								
ME7.1-ME7.1.1	E85 Conversion	HardCut	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EVAP
	Ignition Cut	LAMBDA											
ME7.1.1	E85 Conversion	Stage1	Stage2	Stage3	VMAX	Decat	LAMBDA						
ME7.1.5	Stage1												
ME7.2	Stage1	Stage2											
ME7.3.2	Stage1												
ME7.5	Anti-Lag	E85 Conversion	Launch Control Activation	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2					
	Stage3	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	EVAP	LAMBDA	MAF	SAP	TVA	
ME7.5.10	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	CAT/KAT	DTC Off	EGR	EVAP	LAMBDA			
ME7.8	E85 Conversion	Stage1	Stage2										
ME7.8.2	Stage1												
ME9	Stage1	Stage2											
ME9.1	Stage1	Stage2	VMAX										
ME9.1.1	Stage1	Stage2											
ME9.5	Pops&Bangs	Stage1	Stage1+	Stage2	Adblue	DTC Off	EGR	LAMBDA					
ME9.7	Stage1	Stage2											
MED17	E85 Conversion	Pops&Bangs	Stage1	VMAX	CAT/KAT	DPF	EGR						
MED17.1	E85 Conversion	Exhaust Valve OFF	HardCut	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX				
	CAT/KAT	DTC Off	EVAP	FLAPS (Swirl)	LAMBDA	Readiness Calibration	SAP	TVA	TPROT				
MED17.1.1	Cylinder On Demand OFF	E85 Conversion	Exhaust Valve OFF	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DPF			
	DTC Off	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA	Readiness Calibration	SAP	Start-Stop	TVA	Immo Off (FLASH)			
MED17.1.10	Stage1	Stage2											
MED17.1.11	Stage1	Stage2											
MED17.1.15	E85 Conversion												
MED17.1.2	E85 Conversion	Stage1	CAT/KAT	EVAP	LAMBDA	Readiness Calibration							
MED17.1.21	E85 Conversion	Stage1											
MED17.1.27	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Active Grill Shutter (AGS)	CAT/KAT	DTC Off	EVAP			
	FLAPS (Swirl)	LAMBDA											
MED17.1.6	Stage1	Stage2											
MED17.1.61	Stage1												
MED17.1.62	E85 Conversion	Stage1	Stage2										
MED17.1.63	Stage1												
MED17.1.6X	E85 Conversion	Pops&Bangs	Pops&Bangs (Switchable)	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3					
	VMAX	Active Grill Shutter (AGS)	Adblue	CAT/KAT	Decat	DPF	DTC Off	EGR	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA	
	Readiness Calibration	SAP	TVA	Immo Off (FLASH)									
MED17.5	E85 Conversion	Hot Start Fix	Launch Control Activation	Pops&Bangs	Pops&Bangs (Switchable)	RPM Soft Limiter Removal							
	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	EVAP	FLAPS (Swirl)
	LAMBDA	MAF	Readiness Calibration	TVA	Immo Off (FLASH)								
MED17.5.1	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DTC Off	FLAPS (Swirl)			
	LAMBDA	Readiness Calibration											
MED17.5.2	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	EVAP	FLAPS (Swirl)			
	LAMBDA	Readiness Calibration	Start-Stop	TVA									
MED17.5.20	E85 Conversion	Pops&Bangs	Stage1	Stage2									
MED17.5.20-26	Cylinder On Demand OFF	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT				
	DTC Off	EVAP	FLAPS (Swirl)	LAMBDA	Readiness Calibration	TVA	Immo Off (FLASH)						
MED17.5.21	Cylinder On Demand OFF	E85 Conversion	Pops&Bangs	Stage1	Stage2	DTC Off	TVA						
MED17.5.25	E85 Conversion	Pops&Bangs	Stage1	Stage2	FLAPS (Swirl)	TVA							

MED17.5.5	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DTC Off	FLAPS (Swirl)		
	LAMBDA	Readiness Calibration	Start-Stop	TVA	Immo Off (FLASH)							
MED17.5.53	E85 Conversion	Pops&Bangs	Stage1	Stage2	DTC Off							
MED17.5.X	Stage1	Stage2										
MED17.6.9	Stage1											
MED17.7	Stage1	Stage2										
MED17.7.1	Stage1											
MED17.7.2	Stage1	Stage2										
MED17.7.3	Stage1	Stage2										
MED17.7.3.1	Stage1											
MED17.7.5	Stage1											
MED17.7.7	Stage1											
MED7.5.11	E85 Conversion	Pops&Bangs	Stage1	CAT/KAT	EGR	NOX						
MED9	E85 Conversion	Stage1										
MED9.1	E85 Conversion	Exhaust Valve OFF	HardCut	Launch Control Activation	Pops&Bangs	Pops&Bangs (Switchable)						
	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	CAT/KAT	Cold Start Delete	Decat	DPF	
	DTC Off	EGR	EVAP	FLAPS (Swirl)	LAMBDA	MAF	TVA	Immo Off (FLASH)				
MED9.1.1	E85 Conversion	Stage1	DTC Off									
MED9.1.2	E85 Conversion	Stage1										
MED9.1.3	E85 Conversion	Stage1										
MED9.1.4	E85 Conversion	Stage1										
MED9.1.5	E85 Conversion	Stage1	Stage2									
MED9.5	E85 Conversion	Stage1										
MED9.5.10	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)
	LAMBDA	NOX	Immo Off (FLASH)									
MED9.6	Stage1											
MED9.6.1	Stage1	Stage2										
MED9.7	Stage1											
MEDC17	Pops&Bangs	Stage1	Stage2	Adblue	DPF	DTC Off	EGR	Immo Off (FLASH)				
MEDC17521	Stage1											
MEVD17.2	Stage1											
MG1CP002	Stage1											
MG1CP007	Pops&Bangs	Stage1	Stage2	CAT/KAT	EVAP	GPF/OPF	LAMBDA	Start-Stop				
MG1CS001	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Active Grill Shutter (AGS)	CAT/KAT	EVAP	FLAPS (Swirl)		
	LAMBDA	SAP										
MG1CS002	E85 Conversion	Exhaust Valve OFF	Pops&Bangs	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	CAT/KAT	DPF	EVAP	
	FLAPS (Swirl)	GPF/OPF	LAMBDA	SAP	Start-Stop							
MG1CS008	Exhaust Valve OFF	Pops&Bangs	Stage1	Stage2	CAT/KAT	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA			
MG1CS011	Cylinder On Demand OFF	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Torque Monitor	VMAX	CAT/KAT	EVAP	GPF/OPF		
	LAMBDA	Start-Stop										
MG1CS031	Pops&Bangs	RPM Soft Limiter Removal	Torque Monitor	CAT/KAT	EVAP	FLAPS (Swirl)	LAMBDA					
MG1CS111	E85 Conversion	Pops&Bangs	Stage1	Stage1+	VMAX	CAT/KAT	EVAP	GPF/OPF	LAMBDA	Readiness Calibration		
MS6.2	Stage1											
MSA15	Stage1											
MSB15	Stage1											
PCR2.1	E85 Conversion	HardCut	Launch Control Activation	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue		
	Decat	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	Readiness Calibration	Start-Stop	TVA	Water Pump	
PPD1.2	DPF											
PPD1.X	Hotstart	Launch Control Activation	Stage1	Stage1+	Stage2	Stage3	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA
	MAF	TVA	Immo Off (FLASH)									
SDI10	VMAX	CAT/KAT	LAMBDA									
SDI3	CAT/KAT	DPF	LAMBDA									
SDI6/7/8/9	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	CAT/KAT	EVAP	LAMBDA				
SID3	Stage2											
SID307	Stage1											
SID310	DPF	EGR										
SID9	Stage1	Stage2										
SIMOS	Stage1	Stage2	DPF	DTC Off	Immo Off (FLASH)							
SIMOS10	E85 Conversion	Stage1										
SIMOS10.10	E85 Conversion	Stage1	Stage2	VMAX								

SIMOS10.12	Stage1
SIMOS10.1X	E85 Conversion Stage1
SIMOS10.2	Stage1
SIMOS10.22	Stage1
SIMOS10.23	Stage1
SIMOS10.24	Stage1
SIMOS10.2X	E85 Conversion Pops&Bangs Stage1 Stage2
SIMOS10.X	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX CAT/KAT DPF EGR EVAP FLAPS (Swirl) LAMBDA MAF Start-Stop
SIMOS11.X	E85 Conversion Pops&Bangs CAT/KAT EVAP FLAPS (Swirl) LAMBDA
SIMOS12	E85 Conversion Pops&Bangs Stage1 Stage2 CAT/KAT DTC Off TVA
SIMOS12.1	E85 Conversion Pops&Bangs
SIMOS12.2	E85 Conversion Stage1
SIMOS12.X	E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA
SIMOS16.X	CAT/KAT EVAP LAMBDA SAP
SIMOS18	E85 Conversion Pops&Bangs Stage1 Stage2 VMAX CAT/KAT DTC Off
SIMOS18.1	E85 Conversion Pops&Bangs Stage1
SIMOS18.10	E85 Conversion Pops&Bangs Stage1 Stage2 VMAX
SIMOS18.2	Stage1 DTC Off
SIMOS18.4	Stage1
SIMOS18.6	E85 Conversion
SIMOS18.X	E85 Conversion Exhaust Valve OFF Launch Control Activation Pops&Bangs Pops&Bangs (Switchable) RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX Active Grill Shutter (AGS) CAT/KAT DPF DTC Off EVAP Farts (GOLF 7 SIMOS18) FLAPS (Swirl) GPF/OPF LAMBDA Readiness Calibration SAP Start-Stop TVA Immo Off (FLASH)
SIMOS19.X	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX Adblue CAT/KAT EVAP FLAPS (Swirl) GPF/OPF LAMBDA SAP Start-Stop TVA
SIMOS2	E85 Conversion Stage1 Stage2
SIMOS3	E85 Conversion Stage1 Stage2
SIMOS3.2	Stage1
SIMOS3.3	E85 Conversion
SIMOS3.X	E85 Conversion Stage1 Stage2 CAT/KAT EGR LAMBDA
SIMOS4	Stage1
SIMOS6.2	E85 Conversion
SIMOS6.X	E85 Conversion Stage1 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA
SIMOS7.1	E85 Conversion Stage1
SIMOS7.X	E85 Conversion Pops&Bangs Stage1 CAT/KAT EGR LAMBDA
SIMOS8	E85 Conversion Stage1
SIMOS8.2	E85 Conversion Stage1
SIMOS8.3	Stage1
SIMOS8.4	E85 Conversion Stage1 Stage2 VMAX DTC Off LAMBDA
SIMOS8.5	E85 Conversion Stage1 Stage2 TVA
SIMOS8.X	E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage2 Stage3 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA SAP TVA
SIMOS9.1	E85 Conversion Stage1
SIMOS9.X	E85 Conversion Stage1 CAT/KAT LAMBDA
TEMIC	Gearbox Tuning Stage1 Stage2 DPF

DACIA

58 ECU

DCM1.2	Stage1 Stage2
DCM3.4	Stage1 VMAX DPF EGR LAMBDA
DCM3.7	DPF EGR
DDCR-DCM1.2	Boost Increase Stage1 Stage1+ Stage2 VMAX DPF EGR TVA
DELPHI	Stage1
DENSO	E85 Conversion Stage1 Stage1+ VMAX DPF EGR
EDC15	Stage1 Stage2
EDC15C	Stage1
EDC15C13	Stage1+ EGR
EDC15C2	Stage1 DPF

EDC15C3	Stage1	Stage1+	Stage2	Stage3	VMAX	DTC Off	EGR	MAF					
EDC15V	Stage1												
EDC16	Stage1												
EDC16C3	E85 Conversion	Stage1	Stage1+	Stage2	VMAX	DPF	EGR						
EDC16C36	E85 Conversion	Stage1	VMAX	DPF	DTC Off	EGR	TVA						
EDC16C41	E85 Conversion	Stage1	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration					
EDC16CP33	E85 Conversion	Hotstart	Stage1	Stage1+	Stage2	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA
	Immo Off (FLASH)												
EDC16CP42	Stage1	Stage2	VMAX	Adblue	DPF	DTC Off	EGR	TVA					
EDC17	Stage1	VMAX	Adblue	DPF	DTC Off	FLAPS (Swirl)							
EDC17C11	Exhaust Valve OFF	Stage1	Stage2	VMAX	DPF	EGR	LAMBDA	TVA					
EDC17C42	E85 Conversion	Exhaust Valve OFF	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)		
	LAMBDA	TVA											
EDC17C45	Exhaust Valve OFF	Stage1	Torque Monitor	Adblue	DPF	EGR	LAMBDA	TVA					
EDC17C84	Exhaust Valve OFF	Stage1	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Start-Stop	
	TVA	Immo Off (FLASH)											
EDC17CP11	Stage1	VMAX	DPF	EGR	FLAPS (Swirl)								
EDC17CP19	Stage1	Torque Monitor	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA						
EDC17CP58	Exhaust Valve OFF	Stage1	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA						
EMS2	Stage1												
EMS2.2	Adblue												
EMS3	Stage1												
EMS3110	E85 Conversion	Exhaust Valve OFF	Launch Control Activation	Pops&Bangs	Stage1	Stage2	VMAX	CAT/KAT	DPF	EVAP			
	LAMBDA												
EMS3125	E85 Conversion	Stage1	CAT/KAT	EVAP	LAMBDA								
EMS3130	Stage1												
EMS3132	Stage1												
EMS314X	E85 Conversion	Stage1	Adblue	CAT/KAT	EVAP	GPF/OPF	LAMBDA						
EMS3150	Stage1												
EMS3155	E85 Conversion	Stage1	Stage2										
EMS315X	E85 Conversion	Exhaust Valve OFF	Pops&Bangs	Stage1	Torque Monitor	VMAX	CAT/KAT	DTC Off	EVAP	LAMBDA			
EMS3160	CAT/KAT	EVAP	GPF/OPF	LAMBDA									
EMS3161	CAT/KAT	EVAP	GPF/OPF	LAMBDA									
HITACHI	E85 Conversion	Pops&Bangs	Stage1	Stage2	CAT/KAT	DTC Off	EGR	LAMBDA					
MAXITY	Stage1+												
MD1CS006	Exhaust Valve OFF	Stage1	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	LAMBDA	TVA			
MD1CS016	Stage1	Torque Monitor	Adblue	DPF	EGR	LAMBDA							
ME17.9.23	CAT/KAT	LAMBDA											
MEC93	Stage1												
S3000	E85 Conversion	Stage1	CAT/KAT	LAMBDA									
SID301	Stage1	EGR											
SID301-04	Stage1	DPF	EGR	TVA									
SID305	Stage1	DPF	DTC Off	EGR									
SID305-6	Stage1	Stage1+	Stage2	VMAX	Adblue	DPF	DTC Off	EGR	LAMBDA	TVA			
SID306	Stage1	DPF											
SID307	Stage1	Torque Monitor	Adblue	DPF	EGR	LAMBDA	TVA						
SID309	Exhaust Valve OFF	Stage1	VMAX	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA					
SID310	Exhaust Valve OFF	Stage1	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	LAMBDA	NOX	Start-Stop	TVA	
SID321	Stage1	Torque Monitor	VMAX	Adblue	DPF	EGR	LAMBDA	Start-Stop	TVA				
SIM32	E85 Conversion	Stage1	CAT/KAT	DTC Off	LAMBDA								
V42	E85 Conversion	Pops&Bangs	Stage1	Stage2	CAT/KAT	DPF	EGR	EVAP	LAMBDA				
V50	Stage1												

DS

82 ECU

DCM	Stage	DPF	EGR	NOX	Immo Off (EPROM)	Other
DCM3.4	Stage1	DPF	EGR	NOX	Immo Off (EPROM)	
DCM3.5	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX, DPF, DTC Off, EGR, FLAPS (Swirl), LAMBDA, MAF, TVA
DCM6.2	E85 Conversion	Stage1	Stage1+	Torque Monitor	VMAX	Adblue, DPF, EGR, FLAPS (Swirl), LAMBDA, NOX, Start-Stop, TVA
	Immo Off (EPROM)					
DCM7	Adblue, DPF					

DCM7.1	E85 Conversion	Stage1	Stage1+	Stage3	Torque Monitor	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	LAMBDA	NOX
DCU102	Stage1	DPF	EGR										
DDCR	Stage1	EGR											
DELPHI	Stage1	Stage1+	Stage2	DPF	DTC Off								
EDC15	Stage1	Stage2	VMAX	DPF	EGR	MAF							
EDC15C	Stage1												
EDC15C2	Stage1	Stage2	VMAX	DPF	EGR	Immo Off (EPROM)	Immo Off (FLASH)						
EDC15C3-C7	Stage1	Stage2	CAT/KAT	EGR	MAF	Immo Off (FLASH)							
EDC15C6	Stage1												
EDC15C7	Stage1												
EDC16	Stage1	Stage2	DPF										
EDC16C0	Stage1	DPF											
EDC16C3	Stage1	Stage1+	Stage2	VMAX	DPF	EGR	Glow Plug	LAMBDA	TVA				
EDC16C31	Stage1	DPF											
EDC16C32	Stage1												
EDC16C34	E85 Conversion	HardCut	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	DPF	DTC Off	
	EGR	FLAPS (Swirl)	Glow Plug	LAMBDA	MAF	TVA	Immo Off (FLASH)						
EDC16C39	Stage1	Stage2	VMAX	DPF	EGR	LAMBDA	MAF	TVA					
EDC16CP34	Stage1												
EDC16CP36	Stage1												
EDC16CP39	Stage1	Stage2	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	TVA			
EDC16U31	Stage1												
EDC17	Stage1	DPF	MAF										
EDC17C09	Stage1	DPF											
EDC17C10	Stage1	Stage1+	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration	Start-Stop	
	TVA	Immo Off (FLASH)											
EDC17C42-CP42	Stage1	Stage1+	Torque Monitor	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA				
EDC17C60	E85 Conversion	Stage1	Stage1+	Torque Monitor	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	
	NOX	Readiness Calibration	Start-Stop	TVA	Immo Off (FLASH)	TPROT							
EDC17CP04	Stage1												
EDC17CP11	Stage1	Torque Monitor	DPF	EGR									
EDC17CP14	Stage1												
EDC17CP42	Stage1												
EDC17CP52	Stage1	Stage2	VMAX	Adblue	DPF	EGR	LAMBDA						
M7.9.5	Torque Monitor	CAT/KAT	LAMBDA										
MARELLI	Stage1	Stage1+	Stage2										
MD1CS003	Stage1	Torque Monitor	VMAX	Adblue	CAT/KAT	DPF	EGR	FLAPS (Swirl)	LAMBDA	NOX	Start-Stop	Immo Off (FLASH)	
	TPROT												
ME17.4	E85 Conversion												
ME7	E85 Conversion	Stage1											
ME7.4.4	E85 Conversion	Stage1											
ME7.4.5	E85 Conversion	Stage1											
ME7.4.6	E85 Conversion												
ME7.4.7	E85 Conversion												
ME7.4.X	E85 Conversion	Stage1	CAT/KAT	LAMBDA									
ME7.5	E85 Conversion												
ME7.9.51	Stage1												
MED17	Stage1	Stage2	DPF	EGR									
MED17.4	E85 Conversion	Stage1											
MED17.4.2	E85 Conversion	Stage1											
MED17.4.4	E85 Conversion	Stage1	Stage2										
MED17.4.X	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	CAT/KAT	DTC Off	EGR	LAMBDA	MAF			
MED17.5.1	Stage1												
MED7.4.4	E85 Conversion												
MED9	Stage1												
MEV17	E85 Conversion	Stage1											
MEV17.4	E85 Conversion												
MEV17.4.2	E85 Conversion	Stage1											
MEVD17.2.2	Stage1												
MEVD17.4.2	Stage1												

MEVD17.4.4	Stage1	Stage2	MAF								
MG1CS042	E85 Conversion	Stage1	VMAX	CAT/KAT	DTC Off	GPF/OPF					
MJ8	Stage1	DPF	EGR								
SID201	Stage1	Stage1+	Stage2	DPF	EGR	LAMBDA					
SID206	Stage1										
SID208	E85 Conversion	Pops&Bangs	Stage1	Stage2	VMAX	CAT/KAT	DPF	DTC Off	EGR	LAMBDA	TVA
SID80	Stage1										
SID801	Stage1										
SID801-804	Pops&Bangs	Stage1	Stage1+	Stage2	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF		
SID801A	Stage1										
SID801X	Stage1										
SID803	E85 Conversion	Stage1	DPF	DTC Off							
SID803-803A	E85 Conversion	Stage1	Stage1+	Stage2	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA
SID803A	Stage1	DPF									
SID804	Stage1	EGR									
SID805	EGR										
SID806	E85 Conversion	Stage1	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA				
SID807	Stage1	DPF	EGR								
SID807-807EVO	E85 Conversion	Stage1	Stage1+	VMAX	DPF	DTC Off	EGR	LAMBDA	Start-Stop	TVA	Immo Off (FLASH)
SID80X	Stage1	DPF									
V46	E85 Conversion	Stage1	CAT/KAT	DTC Off	LAMBDA						
VD56	E85 Conversion	Stage1	CAT/KAT	LAMBDA							

FERRARI

```

graph LR
    MED17.6.9 --- LAMBDA
    LAMBDA --- MED9.6
    MED9.6 --- Stage1
    MED9.6 --- Stage2
  
```

FIAT

9GF	E85 Conversion	Stage1	Adblue	CAT/KAT	DPF	DTC Off	EGR	EVAP	LAMBDA							
CRD2.X	FLAPS (Swirl)															
EDC15	Stage1	Stage2	DPF	EGR												
EDC15C2	Stage1	Stage2	VMAX	DPF	EGR											
EDC15C5	Stage1	Stage2														
EDC15C6	Stage1															
EDC15C7	Stage1	Stage1+	Stage2	Stage3	DTC Off	EGR	Immo Off (FLASH)									
EDC16	Stage1															
EDC16C31	E85 Conversion	Stage1														
EDC16C31-CP31	Stage1	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration	TVA							
EDC16C34	Stage1	Stage2	DPF	EGR												
EDC16C39	E85 Conversion	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	TVA	Immo Off (FLASH)		
EDC16C8	E85 Conversion	Stage1	Stage1+	Stage2	DPF	EGR										
EDC16C9	Stage1	DTC Off														
EDC16CP31	Stage1	DPF	EGR													
EDC16U31	Stage1	Stage1+	Stage2	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA							
EDC16V2	Stage1															
EDC17	Pops&Bangs	Stage1														
EDC17C09	Stage1															
EDC17C10	Stage1	DPF														
EDC17C49	Launch Control Activation	Stage1	Stage1+	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	TVA			
EDC17C69	E85 Conversion	Stage1	Stage1+	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop	TVA	Immo Off (FLASH)
EDC17C79	Stage1	Stage2	Torque Monitor	VMAX	Active Grill Shutter (AGS)	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	TVA			
EDC17CP04	Stage1															
EDC17CP14	Stage1															
EDC17CP27	Stage1	Stage1+	Torque Monitor	DPF	EGR	FLAPS (Swirl)	Immo Off (EPROM)									

EDC17CP52	E85 Conversion	Stage1	Torque Monitor	VMAX	Adblue	DPF	EGR	LAMBDA	NOX	Immo Off (EPROM)			
GPEC2	Pops&Bangs	VMAX	CAT/KAT	EVAP	LAMBDA								
GPEC2A	Cylinder On Demand OFF	Stage1	CAT/KAT	EGR	EVAP	FLAPS (Swirl)	LAMBDA	FCA Unlock					
GPEC3	Active Grill Shutter (AGS)	CAT/KAT	FLAPS (Swirl)	LAMBDA									
GPEC4	Stage1	CAT/KAT	DTC Off	EVAP	LAMBDA								
IAW4SF	Immo Off (FLASH)												
MARELLI	Stage1	Stage1+	DPF	EGR									
ME17.3.0	E85 Conversion	Pops&Bangs	Stage1	Stage2	DTC Off								
ME17.3.X	E85 Conversion	Pops&Bangs	Pops&Bangs (Switchable)	Stage1	Stage1+	Stage2	CAT/KAT	LAMBDA					
ME2.8	Stage1												
ME3.1	Stage1												
ME7	E85 Conversion												
ME7.3	Stage1												
ME7.3.1	E85 Conversion	Stage1	Stage2	Stage3									
ME7.3.2	E85 Conversion												
ME7.4.5	Stage1												
ME7.6	Stage1												
ME7.6.2	E85 Conversion												
ME7.9.10	E85 Conversion	Pops&Bangs	Stage1	Stage1+	VMAX	CAT/KAT	LAMBDA						
ME9.1	Stage1												
MED17	Pops&Bangs	Stage1	Stage3	CAT/KAT									
MED17.3	E85 Conversion												
MED17.3.0	E85 Conversion												
MED17.3.1	Stage1												
MED17.3.30	Stage1												
MED17.3.5	Stage1												
MED17.6.9	Stage1												
MED7.1.1	Stage1												
MED7.6.2	Stage1												
MJ8DF	HardCut	Stage1	VMAX	Adblue	CAT/KAT	DPF	EGR	FLAPS (Swirl)	Glow Plug	LAMBDA	MAF	Start-Stop	TVA
MJ9DF	E85 Conversion	Stage1	Stage1+	Stage2	VMAX	Adblue	CAT/KAT	DPF	EGR	LAMBDA	NOX	Start-Stop	TVA
	Immo Off (FLASH)												
MJD6F	HardCut	Stage1	Stage2	VMAX	DPF	DTC Off	EGR	LAMBDA	MAF				
MM8GMF	CAT/KAT	LAMBDA											
SID803A	Stage1	DPF	EGR	EVAP									

FORD

63 ECU

DCM1.X	Stage1	DTC Off	EGR										
DCM3.2	DPF	EGR											
DCM3.5	Stage1	Stage1+	VMAX	Active Grill Shutter (AGS)	DPF	DTC Off	EGR	LAMBDA					
DCM6.1	Stage1	Torque Monitor	VMAX	CAT/KAT	DPF	DTC Off	EGR						
DCU	Adblue												
DCU102	Stage1	Stage1+	Stage2	VMAX	DPF	DTC Off	EGR						
DCU17PC43	Adblue												
DELPHI	Stage1	Stage1+	Stage2										
EDC15	Stage1	Stage2	Stage3										
EDC15P	Stage1	Stage2											
EDC16	Stage1	Adblue	DPF										
EDC16C2	Stage1												
EDC16C3	Stage1	Stage1+	Stage2	VMAX	DPF	EGR	FLAPS (Swirl)	Glow Plug	LAMBDA	TVA			
EDC16C34	E85 Conversion	Stage1	Stage2	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	Glow Plug	LAMBDA	MAF	TVA
	Immo Off (FLASH)												
EDC16C7	E85 Conversion	Stage1	VMAX	EGR	FLAPS (Swirl)	LAMBDA	TVA						
EDC16CP39	Stage1	Stage1+	Stage2	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA			
EDC17	Stage1	Stage2	Adblue	CAT/KAT	DPF	DTC Off	FLAPS (Swirl)						
EDC17C08	Stage1												
EDC17C10	E85 Conversion	Stage1	Stage2	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	LAMBDA	MAF	TVA	Immo Off (FLASH)
EDC17C46	Stage1												
EDC17C70	E85 Conversion	Stage1	Stage1+	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	TVA

EDC17CP05	E85 ConversionTorque MonitorAdblueDPFDTC OffEGRLAMBDA
EDC17CP42	Stage1Stage2DPFEGR
EDC17CP65	Stage1AdblueDPFDTC OffEGRFLAPS (Swirl)LAMBDA
EMS210X	E85 ConversionStage1CAT/KAT
EMS2204	E85 ConversionPops&BangsStage1CAT/KATEGR
EMS24XX	E85 ConversionPops&BangsStage1VMAXCAT/KATLAMBDA
EMS2510	Stage1
EMS2511	E85 Conversion
MD1CP006	Torque MonitorActive Grill Shutter (AGS)AdblueDPFEGR
MD1CS005	E85 ConversionHot Start FixStage1Torque MonitorActive Grill Shutter (AGS)AdblueCAT/KATDPFEGRFLAPS (Swirl)
ME17	Stage1
ME9	E85 ConversionStage1
ME9.0	E85 ConversionStage1Stage2DTC Off
ME9.0C	E85 ConversionPops&BangsStage1Stage2Stage3CAT/KATDPFDTC OffEGRGPF/OPFLAMBDA
MED17	E85 ConversionPops&BangsStage1Stage2CAT/KATDPFEGR
MED17.0.1	E85 ConversionPops&BangsStage1Stage1+VMAXAdblueCAT/KATDTC OffEGREVAPLAMBDA
MED17.2	E85 ConversionStage1
MED17.2.2	E85 ConversionStage1Stage2
MED9	E85 ConversionStage1
MG1CS015	Cylinder On Demand OFFE85 ConversionPops&BangsStage1Stage1+VMAXCAT/KATGPF/OPFLAMBDA
MG1CS016	E85 ConversionPops&BangsStage1
MG1CS017	E85 ConversionStage2CAT/KATLAMBDA
MG1CS018	Pops&BangsVMAXCAT/KATDTC Off
MG1CS019	Pops&BangsStage1Stage2VMAXDTC Off
MG1CS028	CAT/KATLAMBDA
SID202-206	E85 ConversionHardCutStage1Stage1+Stage2VMAXAdblueDPFDTC OffEGRLAMBDA
SID206	Stage1AdblueDPFDTC OffEGR
SID208	E85 ConversionEco TuneStage1Stage2Torque MonitorVMAXAdblueDPFDTC OffEGRLAMBDA
SID209	Stage1DPFDTC OffEGR
SID209-211	E85 ConversionStage1Torque MonitorVMAXAdblueDPFDTC OffEGRFLAPS (Swirl)LAMBDA
SID211	Stage1VMAXAdblueDPF
SID212	Stage1Torque MonitorAdblueDPFEGR
SID309	E85 ConversionStage1Stage2VMAXDPFDTC Off
SID802	Stage1
SID802-804	Stage1EGR
SID803	Stage1
SID803-803A	Stage1DPFEGR
SID804	Stage1EGR
SID807	Stage1DPFEGR
SID807-807EVO	E85 ConversionStage1Stage1+DPFEGR
SID902	Stage1DPFEGR
SIM28	Stage1CAT/KAT

GEELY	1 ECU
MED17.8.10	Stage1CAT/KATLAMBDA

GREAT WALL	1 ECU
DCM3.7	DPFEGR

HONDA	17 ECU
EDC15	Stage1
EDC16C31	E85 ConversionStage1VMAXDPFDTC OffEGR
EDC16C31-C7	Stage1Stage1+Stage2VMAXDPFEGRFLAPS (Swirl)LAMBDA
EDC16C7	Stage1
EDC17C01	Stage1DPF

EDC17C08	Stage1
EDC17C50-CP50	Stage1 Torque Monitor DPF EGR FLAPS (Swirl) LAMBDA TVA
EDC17C58	E85 Conversion Stage1 DPF EGR
EDC17C58-CP58	Stage1 Stage1+ DPF DTC Off EGR FLAPS (Swirl) LAMBDA TVA
EDC17CP06	Stage1 Stage2 DPF EGR
EDC17CP06-16	Stage1 Stage2 Torque Monitor CAT/KAT DPF EGR FLAPS (Swirl) LAMBDA TVA
EDC17CP16	Stage1
EDC17CP50	Stage1
KEIHIN	E85 Conversion Stage1 Stage2 CAT/KAT LAMBDA
ME7.9.3	EGR LAMBDA
MED17.9.3	Pops&Bangs Stage1 Stage2 CAT/KAT DTC Off LAMBDA
SH7058	Stage1

HYUNDAI

34 ECU

CPGDSH2.2X	E85 Conversion Pops&Bangs Stage1 VMAX CAT/KAT EGR GPF/OPF LAMBDA
DCM1.2	Stage1
DCM3.2	Stage1
DCM3.7	Stage1 VMAX DPF EGR FLAPS (Swirl) LAMBDA Immo Off (FLASH)
DCM6.2	Stage1 Adblue CAT/KAT DPF EGR LAMBDA
DCU17PC43	Adblue
DELPHI	Stage1 Stage1+ Stage2 EGR
DENSO	E85 Conversion Pops&Bangs Stage1 Adblue CAT/KAT DPF DTC Off EGR
EDC15	Stage1 Stage2
EDC15C2	Stage1 DPF
EDC15C3	Stage1 Stage2
EDC15C7	Stage1 Stage1+ Stage2 Stage3 VMAX DPF EGR Immo Off (EPROM) Immo Off (FLASH)
EDC16C39	E85 Conversion Stage1 Stage1+ Stage2 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA LIMP MAF TVA Immo Off (FLASH)
EDC16CP34	Stage1
EDC17	Stage1 Torque Monitor VMAX EGR
EDC17C08	HardCut Stage1 Stage2 DPF EGR
EDC17C53	Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA TVA Immo Off (FLASH)
EDC17C57	Pops&Bangs Stage1 Stage2 Torque Monitor VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Start-Stop TVA Immo Off (FLASH)
EDC17CP14	Stage1 Stage2 Torque Monitor VMAX Adblue DPF EGR FLAPS (Swirl) LAMBDA TVA Immo Off (FLASH)
M7.9.7	Stage1 Adblue CAT/KAT LAMBDA Immo Off (FLASH)
MD1CS012	DPF EGR
ME17.9	E85 Conversion Stage1 CAT/KAT LAMBDA
ME17.9.1	E85 Conversion
ME17.9.21	LAMBDA
MED17	Stage1
MED17.1.4	E85 Conversion
MED17.9.11-12	VMAX CAT/KAT LAMBDA
MED17.9.2X	CAT/KAT LAMBDA
MED17.9.8	E85 Conversion Pops&Bangs Stage1 Stage2 VMAX CAT/KAT EVAP LAMBDA
MG7.9.8	E85 Conversion Stage1 CAT/KAT LAMBDA Immo Off (FLASH)
MT38	CAT/KAT EVAP LAMBDA
MT86	CAT/KAT EVAP FLAPS (Swirl) LAMBDA Immo Off (FLASH)
SIM2K	Pops&Bangs Stage1 CAT/KAT EVAP FLAPS (Swirl) LAMBDA Immo Off (FLASH)
SIMK41	Stage1

ISUZU

5 ECU

BETA	EGR
DCU17PC43	Adblue
EDC17C83	Stage1 Stage1+ Torque Monitor Adblue DPF EGR
SH7058	EGR
TRANSTRON	Stage1 Stage1+ VMAX Adblue DPF DTC Off EGR FLAPS (Swirl)

IVECO

6 ECU

EDC16C39	Stage1	Stage1+	Stage2	DPF
EDC16C8	Stage1	Stage2	VMAX	
EDC17C49	Stage1	Adblue	DPF	EGR
EDC17C69	DPF			
EDC17CP52	Stage1	DPF	DTC Off	EGR
EDC17U31	Adblue			

JAC

1 ECU

MD1CS089 Adblue DPF EGR

JAGUAR

25 ECU

DELPHI	Stage1	Stage1+	Stage2											
EDC15	Stage1	Stage2												
EDC15C4	Stage1	Stage1+	Stage2	Stage3	EGR									
EDC16CP39	Stage1	Stage2	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA							
EDC17	Stage1	DPF												
EDC17C08	Stage1	Stage2	DPF											
EDC17CP11	Stage1	Stage2	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX				
EDC17CP42	Stage1	Stage1+	Torque Monitor	VMAX	DPF	EGR	FLAPS (Swirl)	LAMBDA	NOX					
EDC17CP55	Launch Control Activation	Stage1	Torque Monitor	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Start-Stop	TVA
MED17	Stage1	Stage2	CAT/KAT	DPF	DTC Off	EGR								
MED17.0	Stage1													
MED17.1.9	Stage1													
MED17.5.4	Stage1	Stage2												
MED17.8.3	Stage1													
MED17.8.31	Stage1	Stage2												
MED17.8.32	Stage2													
MED17.8.3X	Pops&Bangs	Stage1	CAT/KAT	DTC Off	GPF/OPF	LAMBDA								
MED17.9.7-17.9.9	Exhaust Valve OFF	Launch Control Activation	Stage1	CAT/KAT	EVAP	LAMBDA								
MED17.9.9	Stage2													
MED172	Stage1													
MEDC17.9	Exhaust Valve OFF	Stage1	Torque Monitor	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Start-Stop	TVA
SID201-04	E85 Conversion	Stage1	Stage1+	Stage2	VMAX	Adblue	DPF	DTC Off	EGR					
SID204	Stage1													
SID208	Stage1	Adblue	DPF	EGR										
SID20X	Stage1													

JEEP

60 ECU

[illegible]

EDC16CP31	Stage1	DPF	EGR													
EDC16U31	Stage1	Stage1+	Stage2	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA							
EDC16V2	Stage1															
EDC17	Pops&Bangs	Stage1														
EDC17C09	Stage1															
EDC17C10	Stage1	DPF														
EDC17C49	Launch Control Activation	Stage1	Stage1+	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	TVA			
EDC17C69	E85 Conversion	Stage1	Stage1+	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop	TVA	Immo Off (FLASH)
EDC17C79	Stage1	Stage2	Torque Monitor	VMAX	Active Grill Shutter (AGS)	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	TVA			
EDC17CP04	Stage1															
EDC17CP14	Stage1															
EDC17CP27	Stage1	Stage1+	Torque Monitor	DPF	EGR	FLAPS (Swirl)	Immo Off (EPROM)									
EDC17CP52	E85 Conversion	Stage1	Torque Monitor	VMAX	Adblue	DPF	EGR	LAMBDA	NOX	Immo Off (EPROM)						
GPEC2	Pops&Bangs	VMAX	CAT/KAT	EVAP	LAMBDA											
GPEC2A	Cylinder On Demand OFF	Stage1	CAT/KAT	EGR	EVAP	FLAPS (Swirl)	LAMBDA	FCA Unlock								
GPEC3	Active Grill Shutter (AGS)	CAT/KAT	FLAPS (Swirl)	LAMBDA												
GPEC4	Stage1	CAT/KAT	DTC Off	EVAP	LAMBDA											
IAW4SF	Immo Off (FLASH)															
MARELLI	Stage1	Stage1+	DPF	EGR												
ME17.3.0	E85 Conversion	Pops&Bangs	Stage1	Stage2	DTC Off											
ME17.3.X	E85 Conversion	Pops&Bangs	Pops&Bangs (Switchable)	Stage1	Stage1+	Stage2	CAT/KAT	LAMBDA								
ME2.8	Stage1															
ME3.1	Stage1															
ME7	E85 Conversion															
ME7.3	Stage1															
ME7.3.1	E85 Conversion	Stage1	Stage2	Stage3												
ME7.3.2	E85 Conversion															
ME7.4.5	Stage1															
ME7.6	Stage1															
ME7.6.2	E85 Conversion															
ME7.9.10	E85 Conversion	Pops&Bangs	Stage1	Stage1+	VMAX	CAT/KAT	LAMBDA									
ME9.1	Stage1															
MED17	Pops&Bangs	Stage1	Stage3	CAT/KAT												
MED17.3	E85 Conversion															
MED17.3.0	E85 Conversion															
MED17.3.1	Stage1															
MED17.3.30	Stage1															
MED17.3.5	Stage1															
MED17.6.9	Stage1															
MED7.1.1	Stage1															
MED7.6.2	Stage1															
MJ8DF	HardCut	Stage1	VMAX	Adblue	CAT/KAT	DPF	EGR	FLAPS (Swirl)	Glow Plug	LAMBDA	MAF	Start-Stop	TVA			
MJ9DF	E85 Conversion	Stage1	Stage1+	Stage2	VMAX	Adblue	CAT/KAT	DPF	EGR	LAMBDA	NOX	Start-Stop	TVA	Immo Off (FLASH)		
MJD6F	HardCut	Stage1	Stage2	VMAX	DPF	DTC Off	EGR	LAMBDA	MAF							
MM8GMF	CAT/KAT	LAMBDA														
SID803A	Stage1	DPF	EGR	EVAP												

KIA

34 ECU

CPGDSH2.2X	E85 Conversion	Pops&Bangs	Stage1	VMAX	CAT/KAT	EGR	GPF/OPF	LAMBDA
DCM1.2	Stage1							
DCM3.2	Stage1							
DCM3.7	Stage1	VMAX	DPF	EGR	FLAPS (Swirl)	LAMBDA	Immo Off (FLASH)	
DCM6.2	Stage1	Adblue	CAT/KAT	DPF	EGR	LAMBDA		
DCU17PC43	Adblue							
DELPHI	Stage1	Stage1+	Stage2	EGR				

[illegible]

1 ECU

GEN832K Stage1

2 ECU

MED17.1.1	Stage2	
MED9.1	Pops&Bangs	Stage1

60 ECU

[illegible]

EDC17	Pops&Bangs Stage1
EDC17C09	Stage1
EDC17C10	Stage1 DPF
EDC17C49	Launch Control Activation Stage1 Stage1+ Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX TVA
EDC17C69	E85 Conversion Stage1 Stage1+ Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop TVA Immo Off (FLASH)
EDC17C79	Stage1 Stage2 Torque Monitor VMAX Active Grill Shutter (AGS) Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX TVA
EDC17CP04	Stage1
EDC17CP14	Stage1
EDC17CP27	Stage1 Stage1+ Torque Monitor DPF EGR FLAPS (Swirl) Immo Off (EPROM)
EDC17CP52	E85 Conversion Stage1 Torque Monitor VMAX Adblue DPF EGR LAMBDA NOX Immo Off (EPROM)
GPEC2	Pops&Bangs VMAX CAT/KAT EVAP LAMBDA
GPEC2A	Cylinder On Demand OFF Stage1 CAT/KAT EGR EVAP FLAPS (Swirl) LAMBDA FCA Unlock
GPEC3	Active Grill Shutter (AGS) CAT/KAT FLAPS (Swirl) LAMBDA
GPEC4	Stage1 CAT/KAT DTC Off EVAP LAMBDA
IAW4SF	Immo Off (FLASH)
MARELLI	Stage1 Stage1+ DPF EGR
ME17.3.0	E85 Conversion Pops&Bangs Stage1 Stage2 DTC Off
ME17.3.X	E85 Conversion Pops&Bangs Pops&Bangs (Switchable) Stage1 Stage1+ Stage2 CAT/KAT LAMBDA
ME2.8	Stage1
ME3.1	Stage1
ME7	E85 Conversion
ME7.3	Stage1
ME7.3.1	E85 Conversion Stage1 Stage2 Stage3
ME7.3.2	E85 Conversion
ME7.4.5	Stage1
ME7.6	Stage1
ME7.6.2	E85 Conversion
ME7.9.10	E85 Conversion Pops&Bangs Stage1 Stage1+ VMAX CAT/KAT LAMBDA
ME9.1	Stage1
MED17	Pops&Bangs Stage1 Stage3 CAT/KAT
MED17.3	E85 Conversion
MED17.3.0	E85 Conversion
MED17.3.1	Stage1
MED17.3.30	Stage1
MED17.3.5	Stage1
MED17.6.9	Stage1
MED7.1.1	Stage1
MED7.6.2	Stage1
MJ8DF	HardCut Stage1 VMAX Adblue CAT/KAT DPF EGR FLAPS (Swirl) Glow Plug LAMBDA MAF Start-Stop TVA
MJ9DF	E85 Conversion Stage1 Stage1+ Stage2 VMAX Adblue CAT/KAT DPF EGR LAMBDA NOX Start-Stop TVA Immo Off (FLASH)
MJD6F	HardCut Stage1 Stage2 VMAX DPF DTC Off EGR LAMBDA MAF
MM8GMF	CAT/KAT LAMBDA
SID803A	Stage1 DPF EGR EVAP

LAND ROVER

25 ECU

[illegible]

MED17	Stage1	Stage2	CAT/KAT	DPF	DTC Off	EGR						
MED17.0	Stage1											
MED17.1.9	Stage1											
MED17.5.4	Stage1	Stage2										
MED17.8.3	Stage1											
MED17.8.31	Stage1	Stage2										
MED17.8.32	Stage2											
MED17.8.3X	Pops&Bangs	Stage1	CAT/KAT	DTC Off	GPF/OPF	LAMBDA						
MED17.9.7-17.9.9	Exhaust Valve OFF	Launch Control Activation	Stage1	CAT/KAT	EVAP	LAMBDA						
MED17.9.9	Stage2											
MED172	Stage1											
MEDC17.9	Exhaust Valve OFF	Stage1	Torque Monitor	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX
	Start-Stop	TVA										
SID201-04	E85 Conversion	Stage1	Stage1+	Stage2	VMAX	Adblue	DPF	DTC Off	EGR			
SID204	Stage1											
SID208	Stage1	Adblue	DPF	EGR								
SID20X	Stage1											

LDV

2 ECU

EDC17C53	DPF	EGR	
EDC17C81	DPF	EGR	LAMBDA

LEXUS

247 ECU

89663-02E73	Stage1
89663-02G31	Stage1
89663-02G32	Stage1
89663-02G40	Stage1
89663-02G41	Stage1
89663-02G42	Stage1
89663-02J22	Stage1
89663-02X72	Stage1
89663-06A31	Stage1
89663-06A35	Stage1
89663-06A41	Stage1
89663-06A45	Stage1
89663-06B40	Stage1
89663-06D40	Stage1
89663-06E72	Stage1
89663-06E82	Stage1
89663-06F51	Stage1
89663-06N42	Stage1
89663-06N61	Stage1
89663-0C330	Stage1
89663-0C572	Stage1
89663-0C582	Stage1
89663-0C592	Stage1
89663-0C601	Stage1
89663-0C710	Stage1
89663-0C821	Stage1
89663-0C831	Stage1
89663-0C841	Stage1
89663-0C850	Stage1
89663-0C851	Stage1
89663-0C852	Stage1
89663-0C891	Stage1
89663-0CA01	Stage1
89663-0CA11	Stage1
89663-0CA21	Stage1

89663-0CA31	Stage1
89663-0CA41	Stage1
89663-0CA51	Stage1
89663-0CA61	Stage1
89663-0CA71	Stage1
89663-0CA81	Stage1
89663-0CA91	Stage1
89663-0CB01	Stage1
89663-0CC31	Stage1
89663-0CD70	Stage1
89663-0CJ54	Stage1
89663-0CL10	Stage1
89663-0E142	Stage1
89663-0F097	DPF EGR
89663-0F098	DPF EGR
89663-0K121	Stage1 EGR
89663-0K222	Stage1 EGR
89663-0K223	EGR
89663-0K242	EGR
89663-0K873	EGR
89663-0KK91	EGR
89663-0KK93	EGR
89663-0KM60	EGR
89663-0KM61	EGR
89663-0KM63	EGR
89663-0T070	Stage1
89663-0T121	Stage1
89663-0T160	Stage1
89663-0T220	Stage1
89663-30B02	Stage1
89663-30B10	Stage1
89663-30B11	Stage1
89663-30C02	Stage1
89663-30C51	Stage1
89663-30E00	Stage1
89663-30E70	Stage1
89663-30F51	Stage1
89663-30G01	Stage1
89663-30K81	Stage1
89663-30N40	Stage1
89663-30S31	Stage1
89663-33A50	Stage1
89663-33A51	Stage1
89663-33A53	Stage1
89663-33A60	Stage1
89663-33A61	Stage1
89663-33A70	Stage1
89663-33A71	Stage1
89663-33A72	Stage1
89663-33A74	Stage1
89663-33B51	Stage1
89663-33B52	Stage1
89663-33B60	Stage1
89663-33D30	Stage1
89663-33D71	Stage1
89663-33E90	Stage1
89663-33F41	Stage1
89663-33G81	Stage1
89663-33J92	Stage1

89663-33K10	Stage1
89663-33M22	Stage1
89663-33M42	Stage1
89663-42A33	Stage1
89663-42B82	Stage1
89663-42C72	Stage1
89663-42E70	DPF EGR
89663-42F11	Stage1
89663-42F13	Stage1
89663-42F40	Stage1
89663-42L90	Stage1
89663-42M20	Stage1
89663-42M21	Stage1
89663-42N52	Stage1
89663-42N62	Stage1
89663-42Q11	Stage1
89663-42Q21	Stage1
89663-48A01	Stage1
89663-48C10	Stage1
89663-48C30	Stage1
89663-48G00	Stage1
89663-48M50	Stage1
89663-50A90	Stage1
89663-50B91	Stage1
89663-52D02	Stage1
89663-52D30	Stage1
89663-52F01	Stage1
89663-52J01	Stage1
89663-60A31	EGR
89663-60A32	EGR
89663-60A33	EGR
89663-60A34	EGR
89663-60A60	EGR
89663-60A63	EGR
89663-60A70	EGR
89663-60A71	EGR
89663-60A72	EGR
89663-60A73	EGR
89663-60A80	EGR
89663-60A82	EGR
89663-60A83	EGR
89663-60B03	EGR
89663-60B30	EGR
89663-60B81	Stage1
89663-60C00	Stage1
89663-60C01	Stage1
89663-60C02	Stage1
89663-60C03	Stage1
89663-60C21	Stage1
89663-60C22	Stage1
89663-60C26	Stage1
89663-60C30	Stage1
89663-60C32	Stage1
89663-60C34	Stage1
89663-60C35	Stage1
89663-60C51	Stage1
89663-60D00	Stage1
89663-60E10	Stage1
89663-60E62	Stage1

89663-60E64	Stage1
89663-60E70	Stage1
89663-60E72	Stage1
89663-60E74	Stage1
89663-60E80	Stage1
89663-60F32	Stage1
89663-60F42	Stage1
89663-60F52	Stage1
89663-60F91	Stage1
89663-60F92	Stage1
89663-60G00	EGR
89663-60G01	EGR
89663-60G02	EGR
89663-60G03	EGR
89663-60G62	Stage1
89663-60G92	DPF EGR
89663-60J01	EGR
89663-60J10	EGR
89663-60J20	EGR
89663-60J21	EGR
89663-60J30	EGR
89663-60J50	EGR
89663-60J80	EGR
89663-60K01	Stage1
89663-60K40	DPF EGR
89663-60K41	DPF EGR
89663-60K60	EGR
89663-60K62	EGR
89663-60K90	EGR
89663-60K91	EGR
89663-60L20	EGR
89663-60L50	EGR
89663-60L70	Stage1
89663-60M00	Stage1
89663-60M30	Stage1
89663-60M50	Stage1
89663-60M90	EGR
89663-60N40	EGR
89663-60N41	EGR
89663-60N70	EGR
89663-60N71	EGR
89663-60N72	EGR
89663-60N73	EGR
89663-60N74	EGR
89663-60P10	EGR
89663-60P50	Stage1
89663-60P90	DPF EGR
89663-60Q00	Stage1
89663-60Q10	Stage1
89663-60Q60	Stage1
89663-60R00	EGR
89663-60U50	Stage1
89663-60U90	Stage1 DPF EGR
89663-60U91	DPF EGR
89663-60V20	EGR
89663-60V60	EGR
89663-60X26	Stage1 DPF EGR
89663-60Z31	Stage1
89663-6A160	Stage1

89663-F0305	Stage1
89663-F0593	Stage1
89663-YWF06	Stage1
89663-YWF14	Stage1
89663-YWF18	Stage1
89663-YWF25	Stage1
89663-YWF28	Stage1
89663-YWF29	Stage1
89663-YWF34	Stage1
89663-YWL01	Stage1
89663-YWL09	Stage1
89663-YWL11	Stage1
89663-YWL19	Stage1
89663-YWL23	Stage1
DCM6.2	Stage1 Adblue DPF EGR NOX
DCM7.1	Stage1 Adblue DPF EGR
DENSO	DPF DTC Off EGR
DENSO GEN1	E85 Conversion HardCut Stage1 Stage1+ Stage2 Stage3 VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) TVA Immo Off (FLASH)
DENSO GEN2	E85 Conversion Stage1 Stage1+ Stage2 VMAX Adblue CAT/KAT DPF EGR FLAPS (Swirl) LAMBDA NOX TVA Immo Off (FLASH)
DENSO GEN3	Stage1 Adblue CAT/KAT DPF EGR LAMBDA
DIESEL	Stage1 Stage1+ Adblue CAT/KAT DPF EGR FLAPS (Swirl) LAMBDA NOX
EDC15	Stage1
EDC15C9	Stage1 EGR
EDC16C10	Stage1 DPF EGR
EDC16C31	E85 Conversion Stage1 VMAX DPF DTC Off EGR FLAPS (Swirl)
EDC17C01	Stage1
EDC17C47	Launch Control Activation DPF EGR FLAPS (Swirl) LAMBDA TVA
EDC17C60	Stage1 Adblue DPF
EDC17C73	Stage1 Torque Monitor DPF EGR FLAPS (Swirl) LAMBDA TVA
EDC17CP07	Stage1
EDC17CP07-CP37	Stage1 Torque Monitor VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA TVA
ME17.9.52	E85 Conversion Stage1 CAT/KAT EGR LAMBDA
MG1CS201	Stage1 CAT/KAT GPF/OPF LAMBDA
PETROL	Stage1 CAT/KAT LAMBDA
SID805	Stage1

MAHINDRA

4 ECU

EDC17C53	VMAX DPF EGR FLAPS (Swirl) LAMBDA
EDC17C55	Torque Monitor VMAX Adblue DPF EGR
EDC17C81	VMAX Adblue DPF EGR
MD1CS018	Adblue EGR

MASERATI

5 ECU

EDC17C79	Stage1
ME7.1.3	Stage1
ME7.3.2	Stage1
MED17.3.4	Stage1
MED17.3.X	Pops&Bangs Stage1 Stage2 CAT/KAT EVAP LAMBDA

MAXUS

2 ECU

EDC17C53	DPF EGR
EDC17C81	DPF EGR LAMBDA

MAZDA

9 ECU

CX (DIESEL)	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	Adblue	DPF	EGR	LAMBDA	TVA
CX3	DPF										
DENSO	Stage1	DPF	TVA								
DENSO (SH1)	E85 Conversion	Stage1	Stage1+	Stage2	Adblue	CAT/KAT	DPF	DTC Off	EGR	TVA	
EDC16C3	Stage1	DPF	EGR	FLAPS (Swirl)	Glow Plug	LAMBDA	TVA				
EDC16C34	Stage1	DPF	DTC Off	EGR	Glow Plug						
EDC16C7	Stage1										
SID208	Stage1										
SKYACTIV-G	Stage1	Stage1+									

MERCEDES-BENZ

65 ECU

CRD11	Stage1																	
CRD11 (DCM3.2)	E85 Conversion	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	CAT/KAT	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA						
CRD2	Stage1	DPF	DTC Off															
CRD2.X	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA						
CRD3	Stage1	Stage2	Adblue	DPF														
CRD3.2R	Stage1																	
CRD3.4	DPF																	
CRD3.X	Exhaust Valve OFF	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	NOX	Start-Stop	TVA		
CRV2.0	EGR																	
DCM3.2	Stage1																	
DELPHI	Stage1	Stage1+																
EDC15	HardCut	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	DPF	EGR	FLAPS (Swirl)	MAF	TVA					
EDC15C12	Stage1																	
EDC15C2	Stage1																	
EDC15C5	Stage1	Stage2																
EDC15C6	Stage1	Stage2	EGR															
EDC16	Gearbox Tuning	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	EGT Off	FLAPS (Swirl)	LAMBDA	MAF	Readiness Calibration	TVA	Immo Off (FLASH)
EDC16C0	Stage1																	
EDC16C2	DPF	FLAPS (Swirl)																
EDC16C31	E85 Conversion	Stage1	Stage2	VMAX	DPF	DTC Off	EGR	TVA										
EDC16C31-CP31	Stage1	Stage1+	Stage2	Stage3	VMAX	DPF	EGR	FLAPS (Swirl)	LAMBDA	MAF	Readiness Calibration	TVA						
EDC16C32	Stage1	Stage2	VMAX	DPF	EGR	FLAPS (Swirl)	LAMBDA	MAF	TVA									
EDC16C36	Stage1																	
EDC16C39	Stage1																	
EDC16C6	Stage1																	
EDC16CP31	E85 Conversion	Stage1	Stage2	Adblue	DPF	DTC Off	FLAPS (Swirl)	TVA										
EDC16CP36	E85 Conversion	Stage1	Stage2	Stage3	VMAX	DPF	EGR	FLAPS (Swirl)	LAMBDA	MAF	Readiness Calibration	TVA						
EDC17C01	Stage1	Adblue																
EDC17C42	Stage1																	
EDC17C43	Stage1																	
EDC17C43-CP46	Stage1	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop	TVA					
EDC17C66	E85 Conversion	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop			
EDC17CP01	Stage1	Torque Monitor	VMAX	DPF	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration										
EDC17CP10	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	TVA			
EDC17CP46	E85 Conversion	Stage1	Stage2	VMAX	Adblue	DPF	DTC Off	EGR										
EDC17CP57	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop	TVA			
MD1CP001	Stage1	Stage1+	Torque Monitor	Adblue	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Start-Stop	TVA					
MD1CS006	Stage1	Torque Monitor	Adblue	DPF	EGR	NOX												
ME12	Stage1																	
ME17.7.X	E85 Conversion																	

Model	Configuration
ME2.0	E85 Conversion Stage1
ME2.7	Stage1
ME2.7.2	Stage1 VMAX
ME2.8	E85 Conversion Stage1
ME2.8.1	E85 Conversion Stage1
ME2.8.X	E85 Conversion Stage1 Stage1+ VMAX CAT/KAT EGR LAMBDA
ME9.7	E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX CAT/KAT DTC Off EGR FLAPS (Swirl) LAMBDA
MED17	E85 Conversion Pops&Bangs Stage1 Stage2 VMAX CAT/KAT DPF DTC Off EGR LAMBDA
MED17.2	E85 Conversion
MED17.2.2	E85 Conversion
MED17.4	E85 Conversion
MED17.7	E85 Conversion Pops&Bangs Stage1 Stage2 CAT/KAT LAMBDA
MED17.7.1	E85 Conversion Stage1 Stage2
MED17.7.2	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX CAT/KAT EVAP FLAPS (Swirl) LAMBDA NOX
MED17.7.3	E85 Conversion Exhaust Valve OFF Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX CAT/KAT FLAPS (Swirl) LAMBDA NOX
MED17.7.5	E85 Conversion Pops&Bangs Stage1 Stage2
MED17.7.X	E85 Conversion Exhaust Valve OFF Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX CAT/KAT DPF DTC Off EVAP FLAPS (Swirl) LAMBDA NOX
MED7.7.2	E85 Conversion
MED9.7	E85 Conversion Stage1
MEV17.2.2	E85 Conversion
MG1CP002	Pops&Bangs Stage1 Stage1+ Torque Monitor CAT/KAT DTC Off GPF/OPF LAMBDA
SID307	Stage1 Torque Monitor VMAX DPF EGR LAMBDA
SID310	Stage1 Stage1+ Torque Monitor VMAX Adblue DPF EGR LAMBDA NOX Start-Stop TVA
SIM271	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 Stage3 CAT/KAT DTC Off LAMBDA
TEMIC	Gearbox Tuning Stage1 Adblue EGR

MG

6 ECU

EDC17C06	Stage1
EDC17C54	Stage1
EDC17CP02	Stage1
GEN2048K	Stage1
GEN824K	Stage1
MED17	Stage1

MINI

88 ECU

DCM3.7	Stage1
EDC15	Pops&Bangs Stage1 Stage1+ Stage2 Stage3 VMAX Adblue DPF EGR FLAPS (Swirl) MAF
EDC15C4	Pops&Bangs Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX Adblue DPF DTC Off EGR Immo Off (EPROM) Immo Off (FLASH)
EDC15C6	Stage1
EDC15P	Stage1 Stage2
EDC16	Stage1
EDC16C1	EGR
EDC16C31	E85 Conversion Gearbox Tuning HardCut Pops&Bangs Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF Smoke Limiter Off TVA Immo Off (FLASH)
EDC16C35	E85 Conversion HardCut Stage1 Stage1+ Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA
EDC16CP35	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 Stage3 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF Readiness Calibration TVA
EDC16CP39	Stage1
EDC17	Stage1 Stage2 Adblue CAT/KAT DPF DTC Off EGR
EDC17C06	E85 Conversion Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX Adblue DPF EGR FLAPS (Swirl) LAMBDA MAF NOX Start-Stop Immo Off (FLASH)
EDC17C41	E85 Conversion HardCut RPM Soft Limiter Removal Sport Displays Calibration Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop TVA

EDC17C42	DPF
EDC17C50	Stage1 Stage2 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl)
EDC17C50-C56	E85 Conversion HardCut Launch Control Activation Pops&Bangs RPM Soft Limiter Removal Sport Displays Calibration Stage1
	Stage1+ Stage2 Stage3 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX
	Readiness Calibration Start-Stop TVA Immo Off (FLASH)
EDC17C56	E85 Conversion Stage1 Stage2 DPF DTC Off EGR
EDC17C76	VMAX DPF EGR FLAPS (Swirl) LAMBDA NOX TVA
EDC17CP02	HardCut Pops&Bangs Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX CAT/KAT DPF DTC Off EGR
	FLAPS (Swirl) LAMBDA Readiness Calibration Start-Stop Swirl Flaps Off TVA TPROT
EDC17CP09	Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA
	Readiness Calibration Start-Stop TVA
EDC17CP45	E85 Conversion Stage1 Stage2 Adblue DPF DTC Off EGR TVA
EDC17CP45-CP49	Sport Displays Calibration Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl)
	LAMBDA NOX Readiness Calibration Start-Stop TVA Immo Off (FLASH)
EDC17CP49	Stage1 Stage2 Adblue DPF
EMS2	Stage1
MARELLI	Stage1
MD1CP002	Sport Displays Calibration Stage1 Stage2 Stage3 Torque Monitor VMAX Adblue DPF EGR FLAPS (Swirl) LAMBDA
	Readiness Calibration
MD1CP032	DPF EGR FLAPS (Swirl) LAMBDA Readiness Calibration TVA
MD1CS001	Sport Displays Calibration Stage1 Stage2 Torque Monitor VMAX Active Grill Shutter (AGS) Adblue DPF EGR FLAPS (Swirl)
	LAMBDA LIMP NOX Readiness Calibration TVA TVA Off
ME7	E85 Conversion Stage1
ME7.1	E85 Conversion Stage1
ME7.1-ME7.1.1	E85 Conversion Stage1 CAT/KAT DTC Off LAMBDA
ME7.2	E85 Conversion Stage1 Stage2 VMAX
ME9	E85 Conversion Stage1 Stage2 VMAX DTC Off
ME9.0	E85 Conversion Stage1
ME9.1	E85 Conversion Stage1
ME9.2	E85 Conversion Stage1 VMAX DTC Off
ME9.2.2	E85 Conversion
ME9.4	E85 Conversion Stage1 DPF
ME9.6	Stage1
ME9.8	Stage1
ME9.X	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX CAT/KAT DTC Off LAMBDA
MED17	E85 Conversion Stage1 Stage2 CAT/KAT EGR
MED17.1.1	E85 Conversion Stage1 Stage2
MED17.2	E85 Conversion Stage1 Stage2
MED17.2.2	E85 Conversion Stage1
MED9	E85 Conversion
MED9.1.5	E85 Conversion Stage1
MEV17.2	E85 Conversion Stage1
MEV17.2.2	E85 Conversion
MEV17.4	E85 Conversion Stage1
MEV17.4.6	E85 Conversion Stage1
MEV9.1	E85 Conversion
MEV9.2	E85 Conversion
MEV9.4.6	E85 Conversion Stage1
MEVD17.2	E85 Conversion Pops&Bangs Pops&Bangs (Switchable) Stage1 Stage1+ Stage2 VMAX CAT/KAT DPF DTC Off
	FLAPS (Swirl) LAMBDA
MEVD17.2.2	E85 Conversion Stage1 CAT/KAT
MEVD17.2.3	E85 Conversion Pops&Bangs Sport Displays Calibration Stage1 Stage1+ Stage2 VMAX CAT/KAT DTC Off EVAP
	LAMBDA Readiness Calibration SAP Start-Stop
MEVD17.2.4	Pops&Bangs Sport Displays Calibration Stage1 Stage2 VMAX CAT/KAT EVAP LAMBDA Readiness Calibration
MEVD17.2.5	E85 Conversion Pops&Bangs Sport Displays Calibration Stage1 Stage2 VMAX CAT/KAT FLAPS (Swirl) LAMBDA
	Readiness Calibration Start-Stop
MEVD17.2.6	E85 Conversion Pops&Bangs Sport Displays Calibration Stage1 Stage1+ Stage2 VMAX CAT/KAT LAMBDA
MEVD17.2.8	Pops&Bangs Pops&Bangs (Switchable) Sport Displays Calibration Stage1 Stage2 Torque Monitor VMAX CAT/KAT LAMBDA
	Readiness Calibration
MEVD17.2.84	Stage1

NISSAN		58 ECU
DCM1.2	Stage1 Stage2	
DCM3.4	Stage1 VMAX DPF EGR LAMBDA	
DCM3.7	DPF EGR	
DDCR-DCM1.2	Boost Increase Stage1 Stage1+ Stage2 VMAX DPF EGR TVA	
DELPHI	Stage1	
DENSO	E85 Conversion Stage1 Stage1+ VMAX DPF EGR	
EDC15	Stage1 Stage2	
EDC15C	Stage1	
EDC15C13	Stage1+ EGR	
EDC15C2	Stage1 DPF	

EDC15C3	Stage1 Stage1+ Stage2 Stage3 VMAX DTC Off EGR MAF
EDC15V	Stage1
EDC16	Stage1
EDC16C3	E85 Conversion Stage1 Stage1+ Stage2 VMAX DPF EGR
EDC16C36	E85 Conversion Stage1 VMAX DPF DTC Off EGR TVA
EDC16C41	E85 Conversion Stage1 DPF DTC Off EGR FLAPS (Swirl) LAMBDA Readiness Calibration
EDC16CP33	E85 Conversion Hotstart Stage1 Stage1+ Stage2 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA TVA
	Immo Off (FLASH)
EDC16CP42	Stage1 Stage2 VMAX Adblue DPF DTC Off EGR TVA
EDC17	Stage1 VMAX Adblue DPF DTC Off FLAPS (Swirl)
EDC17C11	Exhaust Valve OFF Stage1 Stage2 VMAX DPF EGR LAMBDA TVA
EDC17C42	E85 Conversion Exhaust Valve OFF Stage1 Stage1+ Stage2 Torque Monitor VMAX DPF DTC Off EGR FLAPS (Swirl)
	LAMBDA TVA
EDC17C45	Exhaust Valve OFF Stage1 Torque Monitor Adblue DPF EGR LAMBDA TVA
EDC17C84	Exhaust Valve OFF Stage1 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Start-Stop
	TVA Immo Off (FLASH)
EDC17CP11	Stage1 VMAX DPF EGR FLAPS (Swirl)
EDC17CP19	Stage1 Torque Monitor DPF EGR FLAPS (Swirl) LAMBDA TVA
EDC17CP58	Exhaust Valve OFF Stage1 DPF EGR FLAPS (Swirl) LAMBDA TVA
EMS2	Stage1
EMS2.2	Adblue
EMS3	Stage1
EMS3110	E85 Conversion Exhaust Valve OFF Launch Control Activation Pops&Bangs Stage1 Stage2 VMAX CAT/KAT DPF EVAP
	LAMBDA
EMS3125	E85 Conversion Stage1 CAT/KAT EVAP LAMBDA
EMS3130	Stage1
EMS3132	Stage1
EMS314X	E85 Conversion Stage1 Adblue CAT/KAT EVAP GPF/OPF LAMBDA
EMS3150	Stage1
EMS3155	E85 Conversion Stage1 Stage2
EMS315X	E85 Conversion Exhaust Valve OFF Pops&Bangs Stage1 Torque Monitor VMAX CAT/KAT DTC Off EVAP LAMBDA
EMS3160	CAT/KAT EVAP GPF/OPF LAMBDA
EMS3161	CAT/KAT EVAP GPF/OPF LAMBDA
HITACHI	E85 Conversion Pops&Bangs Stage1 Stage2 CAT/KAT DTC Off EGR LAMBDA
MAXITY	Stage1+
MD1CS006	Exhaust Valve OFF Stage1 Torque Monitor VMAX Adblue DPF DTC Off EGR LAMBDA TVA
MD1CS016	Stage1 Torque Monitor Adblue DPF EGR LAMBDA
ME17.9.23	CAT/KAT LAMBDA
MEC93	Stage1
S3000	E85 Conversion Stage1 CAT/KAT LAMBDA
SID301	Stage1 EGR
SID301-04	Stage1 DPF EGR TVA
SID305	Stage1 DPF DTC Off EGR
SID305-6	Stage1 Stage1+ Stage2 VMAX Adblue DPF DTC Off EGR LAMBDA TVA
SID306	Stage1 DPF
SID307	Stage1 Torque Monitor Adblue DPF EGR LAMBDA TVA
SID309	Exhaust Valve OFF Stage1 VMAX DPF EGR FLAPS (Swirl) LAMBDA TVA
SID310	Exhaust Valve OFF Stage1 Torque Monitor VMAX Adblue DPF DTC Off EGR LAMBDA NOX Start-Stop TVA
SID321	Stage1 Torque Monitor VMAX Adblue DPF EGR LAMBDA Start-Stop TVA
SIM32	E85 Conversion Stage1 CAT/KAT DTC Off LAMBDA
V42	E85 Conversion Pops&Bangs Stage1 Stage2 CAT/KAT DPF EGR EVAP LAMBDA
V50	Stage1

OPEL

64 ECU

DCM3	Stage1
DCM3.7	Stage1 Adblue DPF EGR FLAPS (Swirl) LAMBDA TVA
DCM7.1	VMAX Adblue DPF EGR LAMBDA NOX Start-Stop
DELCO E37	CAT/KAT EVAP LAMBDA
DELCO E38	Stage1 CAT/KAT EVAP LAMBDA

DELCO E39	E85 Conversion	Pops&Bangs	Stage1	CAT/KAT	EVAP	LAMBDA							
DELCO E78	E85 Conversion	Stage1	Stage2	CAT/KAT	LAMBDA								
DELCO E80-E84	E85 Conversion	Stage1	CAT/KAT	LAMBDA									
DELCO E83	E85 Conversion	Stage1	Stage1+	CAT/KAT	EGR	LAMBDA							
DELCO E87	Pops&Bangs	Stage1	CAT/KAT	DPF	EGR	FLAPS (Swirl)	LAMBDA						
DELCO E92	Stage1	CAT/KAT	DPF	LAMBDA									
DELCO E98	E85 Conversion	Stage1	Stage2	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	TVA
DENSO	Stage1	DPF	EGR										
E98	Stage1												
EDC15	Stage1	Stage1+	Stage2	Stage3	DPF	EGR	MAF						
EDC15C2	Stage1												
EDC15C4	Stage1												
EDC15C7	Stage1												
EDC15V	Stage1												
EDC15VM	Stage1	Stage2	DPF	EGR									
EDC16C3	Stage1	Adblue											
EDC16C36	E85 Conversion	Stage1	VMAX	DPF	DTC Off	EGR							
EDC16C39	E85 Conversion	Hotstart	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	MAF
	TVA												
EDC16C9	E85 Conversion	Hotstart	Stage1	Stage1+	Stage2	Stage3	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF
	TVA												
EDC16CP33	Stage1	Stage2	VMAX	DPF	DTC Off	EGR	TVA						
EDC17	Stage1	VMAX	Adblue	DPF									
EDC17C01	Stage1												
EDC17C11	Stage1	Torque Monitor	VMAX	DPF	EGR	LAMBDA							
EDC17C18	Stage1	Stage2	EGR										
EDC17C18-C19	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	DPF	EGR	FLAPS (Swirl)	Glow Plug	LAMBDA	TVA		
EDC17C19	Stage1	Stage2	DPF										
EDC17C42	Stage1	Stage2	Torque Monitor	VMAX	DPF	EGR							
EDC17C59	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA		
EDC17C60	Stage1												
EDC17C84	Torque Monitor	VMAX	Adblue	DPF	EGR	LAMBDA	NOX	Start-Stop	TVA				
EDC17CP47	Stage1	Torque Monitor	Adblue	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA					
EMS040	DTC Off												
MARELLI	Stage1	Stage2	Adblue	DPF	DTC Off	EGR							
MD1CS003	Stage1	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	Start-Stop	TPROT		
ME1.5.5	E85 Conversion	Stage1	Stage1+	Stage2	Stage3	CAT/KAT	EGR	LAMBDA					
ME17.8.8	CAT/KAT	EVAP	LAMBDA										
ME3.1.1	Stage1												
ME7.6.2	E85 Conversion	Stage1	Stage2										
ME7.6.3	Stage1	Stage2											
ME7.6.4	Stage1												
ME7.6.X	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	CAT/KAT	DTC Off	EVAP	FLAPS (Swirl)	LAMBDA			
ME7.9.9	Stage1												
ME9	Stage1												
ME9.1	Stage1												
ME9.5	Stage1												
ME9.6	Stage1	Stage2	DTC Off										
ME9.6.1	Stage1												
MED9	Stage1												
MED9.6.1	Stage1												
MG1CS042	Stage1												
MJD602-3	HardCut	Stage1	Stage1+	Stage2	Adblue	DPF	EGR	MAF					
MS56	Stage1												
MT35	E85 Conversion	Stage1	Stage2	Stage3	CAT/KAT	DTC Off	EGR	EVAP	LAMBDA				
MT80	CAT/KAT	LAMBDA											
PSG16	Stage1	DPF	DTC Off	EGR	FLAPS (Swirl)	TVA							
SH7059	Stage1												
SID310	Stage1												
SIMTEC7.5	Stage1	CAT/KAT	LAMBDA										

PEUGEOT

82 ECU

DCM3.4	Stage1Stage2DPFEGRNOXImmo Off (EPROM)
DCM3.5	Stage1Stage1+Stage2Stage3Torque MonitorVMAXDPFDTC OffEGRFLAPS (Swirl)LAMBDAMAFTVA
DCM6.2	E85 ConversionStage1Stage1+Torque MonitorVMAXAdblueDPFEGRFLAPS (Swirl)LAMBDA NOXStart-StopTVA Immo Off (EPROM)
DCM7	AdblueDPF
DCM7.1	E85 ConversionStage1Stage1+Stage3Torque MonitorVMAXAdblueCAT/KATDPFDTC OffEGRLAMBDA NOX
DCU102	Stage1DPFEGR
DDCR	Stage1EGR
DELPHI	Stage1Stage1+Stage2DPFDTC Off
EDC15	Stage1Stage2VMAXDPFEGRMAF
EDC15C	Stage1
EDC15C2	Stage1Stage2VMAXDPFEGRImmo Off (EPROM)Immo Off (FLASH)
EDC15C3-C7	Stage1Stage2CAT/KATEGRMAFImmo Off (FLASH)
EDC15C6	Stage1
EDC15C7	Stage1
EDC16	Stage1Stage2DPF
EDC16C0	Stage1DPF
EDC16C3	Stage1Stage1+Stage2VMAXDPFEGRGlow PlugLAMBDA TVA
EDC16C31	Stage1DPF
EDC16C32	Stage1
EDC16C34	E85 ConversionHardCutPops&BangsStage1Stage1+Stage2Stage3Torque MonitorVMAXAdblueDPFDTC Off EGRFLAPS (Swirl)Glow PlugLAMBDAMAFTVAImmo Off (FLASH)
EDC16C39	Stage1Stage2VMAXDPFEGRLAMBDAMAFTVA
EDC16CP34	Stage1
EDC16CP36	Stage1
EDC16CP39	Stage1Stage2VMAXDPFDTC OffEGRFLAPS (Swirl)LAMBDAMAFTVA
EDC16U31	Stage1
EDC17	Stage1DPFMAF
EDC17C09	Stage1DPF
EDC17C10	Stage1Stage1+Torque MonitorVMAXAdblueDPFDTC OffEGRFLAPS (Swirl)LAMBDAReadiness CalibrationStart-Stop TVAImmo Off (FLASH)
EDC17C42-CP42	Stage1Stage1+Torque MonitorDPFDTC OffEGRFLAPS (Swirl)LAMBDA TVA
EDC17C60	E85 ConversionStage1Stage1+Torque MonitorVMAXAdblueCAT/KATDPFDTC OffEGRFLAPS (Swirl)LAMBDA NOXReadiness CalibrationStart-StopTVAImmo Off (FLASH)TPROT
EDC17CP04	Stage1
EDC17CP11	Stage1Torque MonitorDPFEGR
EDC17CP14	Stage1
EDC17CP42	Stage1
EDC17CP52	Stage1Stage2VMAXAdblueDPFEGRLAMBDA
M7.9.5	Torque MonitorCAT/KATLAMBDA
MARELLI	Stage1Stage1+Stage2
MD1CS003	Stage1Torque MonitorVMAXAdblueCAT/KATDPFEGRFLAPS (Swirl)LAMBDA NOXStart-StopImmo Off (FLASH) TPROT
ME17.4	E85 Conversion
ME7	E85 ConversionStage1
ME7.4.4	E85 ConversionStage1
ME7.4.5	E85 ConversionStage1
ME7.4.6	E85 Conversion
ME7.4.7	E85 Conversion
ME7.4.X	E85 ConversionStage1CAT/KATLAMBDA
ME7.5	E85 Conversion
ME7.9.51	Stage1
MED17	Stage1Stage2DPFEGR
MED17.4	E85 ConversionStage1
MED17.4.2	E85 ConversionStage1
MED17.4.4	E85 ConversionStage1Stage2

DCM1.2	Stage1	Stage2						
DCM3.4	Stage1	VMAX	DPF	EGR	LAMBDA			
DCM3.7	DPF	EGR						
DDCR-DCM1.2	Boost Increase	Stage1	Stage1+	Stage2	VMAX	DPF	EGR	TVA
DELPHI	Stage1							
DENSO	E85 Conversion	Stage1	Stage1+	VMAX	DPF	EGR		
EDC15	Stage1	Stage2						
EDC15C	Stage1							
EDC15C13	Stage1+	EGR						
EDC15C2	Stage1	DPF						
EDC15C3	Stage1	Stage1+	Stage2	Stage3	VMAX	DTC Off	EGR	MAF
EDC15V	Stage1							

EDC16	Stage1
EDC16C3	E85 ConversionStage1Stage1+Stage2VMAXDPFEGR
EDC16C36	E85 ConversionStage1VMAXDPFDTC OffEGRTVA
EDC16C41	E85 ConversionStage1DPFDTC OffEGRFLAPS (Swirl)LAMBDAReadiness Calibration
EDC16CP33	E85 ConversionHotstartStage1Stage1+Stage2VMAXAdblueDPFDTC OffEGRFLAPS (Swirl)LAMBDA TVAImmo Off (FLASH)
EDC16CP42	Stage1Stage2VMAXAdblueDPFDTC OffEGR TVA
EDC17	Stage1VMAXAdblueDPFDTC OffFLAPS (Swirl)
EDC17C11	Exhaust Valve OFFStage1Stage2VMAXDPFEGR LAMBDA TVA
EDC17C42	E85 ConversionExhaust Valve OFFStage1Stage1+Stage2Torque MonitorVMAXDPFDTC OffEGRFLAPS (Swirl)LAMBDA TVA
EDC17C45	Exhaust Valve OFFStage1Torque MonitorAdblueDPFEGR LAMBDA TVA
EDC17C84	Exhaust Valve OFFStage1Torque MonitorVMAXAdblueDPFDTC OffEGRFLAPS (Swirl)LAMBDA NOXStart-Stop TVAImmo Off (FLASH)
EDC17CP11	Stage1VMAXDPFEGRFLAPS (Swirl)
EDC17CP19	Stage1Torque MonitorDPFEGRFLAPS (Swirl)LAMBDA TVA
EDC17CP58	Exhaust Valve OFFStage1DPFEGRFLAPS (Swirl)LAMBDA TVA
EMS2	Stage1
EMS2. 2	Adblue
EMS3	Stage1
EMS3110	E85 ConversionExhaust Valve OFFLaunch Control ActivationPops&BangsStage1Stage2VMAXCAT/KATDPFEVAPLAMBDA
EMS3125	E85 ConversionStage1CAT/KATEVAPLAMBDA
EMS3130	Stage1
EMS3132	Stage1
EMS314X	E85 ConversionStage1AdblueCAT/KATEVAPGPF/OPFLAMBDA
EMS3150	Stage1
EMS3155	E85 ConversionStage1Stage2
EMS315X	E85 ConversionExhaust Valve OFFPops&BangsStage1Torque MonitorVMAXCAT/KATDTC OffEVAPLAMBDA
EMS3160	CAT/KATEVAPGPF/OPFLAMBDA
EMS3161	E85 ConversionCAT/KATEVAPGPF/OPFLAMBDA
HITACHI	E85 ConversionPops&BangsStage1Stage2CAT/KATDTC OffEGR LAMBDA
MAXITY	Stage1+
MD1CS006	Exhaust Valve OFFStage1Torque MonitorVMAXAdblueDPFDTC OffEGR LAMBDA TVA
MD1CS016	Stage1Torque MonitorAdblueDPFEGR LAMBDA
ME17.9.23	CAT/KATLAMBDA
MEC93	Stage1
S3000	E85 ConversionStage1CAT/KATLAMBDA
SID301	Stage1EGR
SID301-04	Stage1DPFEGR TVA
SID305	Stage1DPFDTC OffEGR
SID305-6	Stage1Stage1+Stage2VMAXAdblueDPFDTC OffEGR LAMBDA TVA
SID306	Stage1DPF
SID307	Stage1Torque MonitorAdblueDPFEGR LAMBDA TVA
SID309	Exhaust Valve OFFStage1VMAXDPFEGRFLAPS (Swirl)LAMBDA TVA
SID310	Exhaust Valve OFFStage1Torque MonitorVMAXAdblueDPFDTC OffEGR LAMBDA NOXStart-Stop TVA
SID321	Stage1Torque MonitorVMAXAdblueDPFEGR LAMBDAStart-Stop TVA
SIM32	E85 ConversionStage1CAT/KATDTC OffLAMBDA
V42	E85 ConversionPops&BangsStage1Stage2CAT/KATDPFEGREVAPLAMBDA
V50	Stage1
VALE0	CAT/KAT

ROLLS-ROYCE

1 ECU

GEN2048K	Stage1Stage2
----------	--------------

SAAB

5 ECU

EDC16C39	Stage1
EDC16C9	Stage1

EDC17C19	Stage1
EDC17CP21	Stage1
ME9.6	Stage1

SEAT

250 ECU

CRD3.X	Adblue
DCM3.5	Stage1
DCM3.7	E85 Conversion Stage1 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA TVA Water Pump
DCM6.2	E85 Conversion Exhaust Valve OFF Stage1 Stage1+ VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Start-Stop Water Pump
DELPHI	Stage1
DL501	Gearbox Tuning Stage1
DQ200	Gearbox Tuning Stage1
DQ200G2	Gearbox Tuning Stage1
DQ250	Gearbox Tuning Launch Control Activation Stage1 Stage1+
DQ381	Gearbox Tuning Pops&Bangs Stage1
DQ38X	Gearbox Tuning Stage1
DQ500	Gearbox Tuning Stage1 Stage2
DSG AL551	Gearbox Tuning Stage1 Stage1+
EDC15	E85 Conversion Hotstart Launch Control Activation Pops&Bangs Stage1 Stage1+ Stage2 Stage3 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) MAF Multimap TVA
EDC15C	Stage1
EDC15C4	Stage1
EDC15C5	Stage1
EDC15C6	Stage1 Stage2
EDC15P	Stage1 Stage2 VMAX MAF
EDC15V	Stage1
EDC15VM	Stage1 Stage2 DPF
EDC15VMP	Stage1
EDC16	E85 Conversion Stage1 Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF
EDC16C0	Stage1 Stage2 DTC Off MAF
EDC16C1	Stage1
EDC16C10	Stage1
EDC16C2	Stage1
EDC16C3	Stage1
EDC16C31	E85 Conversion Stage1 Stage1+ Stage2 DPF DTC Off EGR FLAPS (Swirl) MAF
EDC16C32	E85 Conversion Stage1 Stage2 DPF
EDC16C34	E85 Conversion Stage1 Stage2 VMAX DPF EGR FLAPS (Swirl)
EDC16C35	Stage1 VMAX
EDC16C36	Stage1
EDC16C39	Stage1
EDC16C4	Stage1 Stage2 VMAX EGR
EDC16C7	Stage1
EDC16C8	Stage1
EDC16C9	Stage1
EDC16CAN	Stage1
EDC16CP31	E85 Conversion Stage1 Stage2 DPF
EDC16CP34	E85 Conversion Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA
EDC16CP35	Stage1
EDC16CP36	Stage1 Stage2 DPF
EDC16CP39	Stage1
EDC16CP42	Stage1
EDC16U1	E85 Conversion Gearbox Tuning HardCut Hot Start Fix Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA Immo Off (FLASH)
EDC16U2	Stage1 Stage2
EDC16U2.1	Stage1
EDC16U3	Stage1

EDC16U31	E85 Conversion	HardCut	Hotstart	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	VMAX	DPF	DTC Off		
	EGR	EGT Off	FLAPS (Swirl)	LAMBDA	MAF	TVA	Immo Off (EPROM)						
EDC16U34	E85 Conversion	HardCut	Hot Start Fix	Hotstart	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	DPF	DTC Off	EGR
	FLAPS (Swirl)	LAMBDA	MAF	TVA	Immo Off (EPROM)								
EDC16UC40	Stage1												
EDC16V2	Stage1	DPF	EGR										
EDC17	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	
EDC17121	Stage1												
EDC17521	Stage1												
EDC17C01	Stage1												
EDC17C06	Stage1												
EDC17C08	Stage1												
EDC17C10	Stage1	DPF	EGR										
EDC17C18	Stage1												
EDC17C19	Stage1												
EDC17C41	Stage1												
EDC17C42	DPF	EGR											
EDC17C43	Stage1												
EDC17C43-CP46	Stage1												
EDC17C46	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	Adblue	CAT/KAT	Decat	DPF	DTC Off	
	EGR	FLAPS (Swirl)	LAMBDA	LIMP	MAF	NOX	Readiness Calibration	Start-Stop	TVA	Water Pump	Immo Off (FLASH)		
EDC17C49	Stage1	DPF	EGR	LAMBDA	TVA								
EDC17C54	E85 Conversion	Exhaust Valve OFF	Stage1	Stage2	Stage3	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR		
	FLAPS (Swirl)	LAMBDA	NOX	Oil Pressure Fix	Readiness Calibration	Start-Stop	TVA	Water Pump	Immo Off (FLASH)				
EDC17C60	Stage1	Adblue	DPF										
EDC17C64	E85 Conversion	Exhaust Valve OFF	HardCut	Pops&Bangs	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	Adblue			
	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	NOX	Readiness Calibration	Start-Stop	TVA	Water Pump	
	Immo Off (FLASH)	TPROT											
EDC17C66	E85 Conversion	Stage1											
EDC17C69	Stage1												
EDC17C74	E85 Conversion	HardCut	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	Active Grill Shutter (AGS)	Adblue	CAT/KAT	DPF		
	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop	TVA	Water Pump	Immo Off (FLASH)	TPROT		
EDC17C79	Stage1												
EDC17CP01	Stage1	DPF	EGR										
EDC17CP02	Stage1	DPF	LAMBDA	Readiness Calibration									
EDC17CP04	E85 Conversion	HardCut	Stage1	Stage2	Torque Monitor	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA		
	Readiness Calibration	TVA	Immo Off (FLASH)										
EDC17CP10	Stage1	Stage2	DPF	EGR									
EDC17CP11	Stage1												
EDC17CP14	E85 Conversion	HardCut	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue			
	Decat	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Stage2+	Start-Stop	TVA	Water Pump	
	Immo Off (FLASH)												
EDC17CP20	E85 Conversion	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	
	NOX	Readiness Calibration	Start-Stop	TVA	Water Pump	Immo Off (FLASH)							
EDC17CP24	Exhaust Valve OFF	Stage1	Stage2	VMAX	Adblue	DPF	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration	TVA		
EDC17CP42	Stage1												
EDC17CP44	E85 Conversion	Exhaust Valve OFF	HardCut	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX			
	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Oil Pressure Fix	Readiness Calibration	Start-Stop	TVA	Immo Off (FLASH)	
EDC17CP46	Stage1	Stage2											
EDC17CP54	Stage1	Stage2	VMAX	Adblue	DPF	EGR	FLAPS (Swirl)	LAMBDA	NOX	Oil Pressure Fix	Readiness Calibration	Start-Stop	TVA
EDC17CP57	Stage1	Stage2	Adblue										
EDC17CP74	E85 Conversion	Stage1	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop	
	TVA	Water Pump											
EDC17CV52	Stage1												
EDC17U01	Stage1	Stage2	DTC Off										
EDC17U01-05	Stage1	Stage1+	Stage2	Torque Monitor	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA				
EDC17U05	Stage1												
IAW4MV	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	CAT/KAT	DPF	EGR	LAMBDA				
MARELLI	Pops&Bangs	Stage1	Stage1+	Stage2	CAT/KAT	DTC Off	EGR	LAMBDA					
MD1CP001	Stage1												

MD1CP004	Stage1 Stage2 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop TVA
MD1CP014	Stage1 VMAX Adblue DPF EGR FLAPS (Swirl) NOX Start-Stop
MD1CS004	Hotstart Stage1 Stage1+ VMAX Adblue DPF DTC Off EGR LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop
MD1CS006	Stage1 Adblue
MD1CS014	Stage1 Adblue DPF EGR LAMBDA Oil Pressure Fix Start-Stop
MDG1	Stage1
ME17	E85 Conversion Stage1 TVA
ME17.5.2	E85 Conversion Stage1 DTC Off TVA
ME17.5.20	E85 Conversion Stage1 DTC Off TVA
ME17.5.20-26	Cylinder On Demand OFF E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX CAT/KAT DTC Off EGR EVAP LAMBDA Readiness Calibration Immo Off (EPROM) Immo Off (FLASH)
ME17.5.24	Stage1
ME17.5.26	E85 Conversion
ME17.5.2X	Stage1
ME17.5.6	E85 Conversion Pops&Bangs Stage1 Stage2 CAT/KAT DTC Off EVAP LAMBDA Readiness Calibration
ME2.0	Stage1
ME2.7	Stage1
ME2.7.1	Stage1
ME2.7.2	Stage1
ME2.8	Stage1
ME2.8.1	Stage1 Stage2
ME3	Stage1
ME3.8	Stage1 Stage2 DPF
ME3.8.1	Stage1
ME5.2	Stage1
ME5.9.2	Stage1
ME7	E85 Conversion Stage1 Stage2
ME7.1	E85 Conversion Stage1 Stage2 Stage3 VMAX
ME7.1-ME7.1.1	E85 Conversion HardCut Pops&Bangs Stage1 Stage1+ Stage2 Stage3 VMAX Adblue CAT/KAT DPF DTC Off EVAP Ignition Cut LAMBDA
ME7.1.1	E85 Conversion Stage1 Stage2 Stage3 VMAX Decat LAMBDA
ME7.1.5	Stage1
ME7.2	Stage1 Stage2
ME7.3.2	Stage1
ME7.5	Anti-Lag E85 Conversion Launch Control Activation Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 VMAX Adblue CAT/KAT DPF DTC Off EGR EVAP LAMBDA MAF SAP TVA
ME7.5.10	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 CAT/KAT DTC Off EGR EVAP LAMBDA
ME7.8	E85 Conversion Stage1 Stage2
ME7.8.2	Stage1
ME9	Stage1 Stage2
ME9.1	Stage1 Stage2 VMAX
ME9.1.1	Stage1 Stage2
ME9.5	Pops&Bangs Stage1 Stage1+ Stage2 Adblue DTC Off EGR LAMBDA
ME9.7	Stage1 Stage2
MED17	E85 Conversion Pops&Bangs Stage1 VMAX CAT/KAT DPF EGR
MED17.1	E85 Conversion Exhaust Valve OFF HardCut Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA Readiness Calibration SAP TVA TPROT
MED17.1.1	Cylinder On Demand OFF E85 Conversion Exhaust Valve OFF Pops&Bangs Stage1 Stage1+ Stage2 VMAX CAT/KAT DPF DTC Off EVAP FLAPS (Swirl) GPF/OPF LAMBDA Readiness Calibration SAP Start-Stop TVA Immo Off (FLASH)
MED17.1.10	Stage1 Stage2
MED17.1.11	Stage1 Stage2
MED17.1.15	E85 Conversion
MED17.1.2	E85 Conversion Stage1 CAT/KAT EVAP LAMBDA Readiness Calibration
MED17.1.21	E85 Conversion Stage1
MED17.1.27	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX Active Grill Shutter (AGS) CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA
MED17.1.6	Stage1 Stage2
MED17.1.61	Stage1

MED17.1.62	E85 Conversion	Stage1	Stage2																						
MED17.1.63	Stage1																								
MED17.1.6X	E85 Conversion	Pops&Bangs	Pops&Bangs (Switchable)	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	VMAX	Active Grill Shutter (AGS)	Adblue	CAT/KAT	Decat	DPF	DTC Off	EGR	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA	Readiness Calibration	SAP	TVA	Immo Off (FLASH)	
MED17.5	E85 Conversion	Hot Start Fix	Launch Control Activation	Pops&Bangs	Pops&Bangs (Switchable)	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	EVAP	FLAPS (Swirl)	LAMBDA	MAF	Readiness Calibration	TVA	Immo Off (FLASH)	
MED17.5.1	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DTC Off	FLAPS (Swirl)	LAMBDA	Readiness Calibration													
MED17.5.2	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	EVAP	FLAPS (Swirl)	LAMBDA	Readiness Calibration	Start-Stop	TVA											
MED17.5.20	E85 Conversion	Pops&Bangs	Stage1	Stage2																					
MED17.5.20-26	Cylinder On Demand OFF	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DTC Off	EVAP	FLAPS (Swirl)	LAMBDA	Readiness Calibration	TVA	Immo Off (FLASH)									
MED17.5.21	Cylinder On Demand OFF	E85 Conversion	Pops&Bangs	Stage1	Stage2	DTC Off	TVA																		
MED17.5.25	E85 Conversion	Pops&Bangs	Stage1	Stage2	FLAPS (Swirl)	TVA																			
MED17.5.5	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DTC Off	FLAPS (Swirl)	LAMBDA	Readiness Calibration	Start-Stop	TVA	Immo Off (FLASH)										
MED17.5.53	E85 Conversion	Pops&Bangs	Stage1	Stage2	DTC Off																				
MED17.5.X	Stage1	Stage2																							
MED17.6.9	Stage1																								
MED17.7	Stage1	Stage2																							
MED17.7.1	Stage1																								
MED17.7.2	Stage1	Stage2																							
MED17.7.3	Stage1	Stage2																							
MED17.7.3.1	Stage1																								
MED17.7.5	Stage1																								
MED17.7.7	Stage1																								
MED7.5.11	E85 Conversion	Pops&Bangs	Stage1	CAT/KAT	EGR	NOX																			
MED9	E85 Conversion	Stage1																							
MED9.1	E85 Conversion	Exhaust Valve OFF	HardCut	Launch Control Activation	Pops&Bangs	Pops&Bangs (Switchable)	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	CAT/KAT	Cold Start Delete	Decat	DPF	DTC Off	EGR	EVAP	FLAPS (Swirl)	LAMBDA	MAF	TVA	Immo Off (FLASH)
MED9.1.1	E85 Conversion	Stage1	DTC Off																						
MED9.1.2	E85 Conversion	Stage1																							
MED9.1.3	E85 Conversion	Stage1																							
MED9.1.4	E85 Conversion	Stage1																							
MED9.1.5	E85 Conversion	Stage1	Stage2																						
MED9.5	E85 Conversion	Stage1																							
MED9.5.10	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Immo Off (FLASH)										
MED9.6	Stage1																								
MED9.6.1	Stage1	Stage2																							
MED9.7	Stage1																								
MEDC17	Pops&Bangs	Stage1	Stage2	Adblue	DPF	DTC Off	EGR	Immo Off (FLASH)																	
MEDC17521	Stage1																								
MEVD17.2	Stage1																								
MG1CP002	Stage1																								
MG1CP007	Pops&Bangs	Stage1	Stage2	CAT/KAT	EVAP	GPF/OPF	LAMBDA	Start-Stop																	
MG1CS001	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Active Grill Shutter (AGS)	CAT/KAT	EVAP	FLAPS (Swirl)	LAMBDA	SAP													
MG1CS002	E85 Conversion	Exhaust Valve OFF	Pops&Bangs	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	CAT/KAT	DPF	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA	SAP	Start-Stop									
MG1CS008	Exhaust Valve OFF	Pops&Bangs	Stage1	Stage2	CAT/KAT	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA																
MG1CS011	Cylinder On Demand OFF	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Torque Monitor	VMAX	CAT/KAT	EVAP	GPF/OPF	LAMBDA	Start-Stop													
MG1CS031	Pops&Bangs	RPM Soft Limiter Removal	Torque Monitor	CAT/KAT	EVAP	FLAPS (Swirl)	LAMBDA																		
MG1CS111	E85 Conversion	Pops&Bangs	Stage1	Stage1+	VMAX	CAT/KAT	EVAP	GPF/OPF	LAMBDA	Readiness Calibration															
MS6.2	Stage1																								
MSA15	Stage1																								

MSB15	Stage1
PCR2.1	E85 Conversion HardCut Launch Control Activation Pops&Bangs Stage1 Stage1+ Stage2 Stage3 VMAX Adblue Decat DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF Readiness Calibration Start-Stop TVA Water Pump
PPD1.2	DPF
PPD1.X	Hotstart Launch Control Activation Stage1 Stage1+ Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA Immo Off (FLASH)
SDI10	VMAX CAT/KAT LAMBDA
SDI3	CAT/KAT DPF LAMBDA
SDI6/7/8/9	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 CAT/KAT EVAP LAMBDA
SID3	Stage2
SID307	Stage1
SID310	DPF EGR
SID9	Stage1 Stage2
SIM05	Stage1 Stage2 DPF DTC Off Immo Off (FLASH)
SIM0510	E85 Conversion Stage1
SIM0510.10	E85 Conversion Stage1 Stage2 VMAX
SIM0510.12	Stage1
SIM0510.1X	E85 Conversion Stage1
SIM0510.2	Stage1
SIM0510.22	Stage1
SIM0510.23	Stage1
SIM0510.24	Stage1
SIM0510.2X	E85 Conversion Pops&Bangs Stage1 Stage2
SIM0510.X	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX CAT/KAT DPF EGR EVAP FLAPS (Swirl) LAMBDA MAF Start-Stop
SIM0511.X	E85 Conversion Pops&Bangs CAT/KAT EVAP FLAPS (Swirl) LAMBDA
SIM0512	E85 Conversion Pops&Bangs Stage1 Stage2 CAT/KAT DTC Off TVA
SIM0512.1	E85 Conversion Pops&Bangs
SIM0512.2	E85 Conversion Stage1
SIM0512.X	E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA
SIM0516.X	CAT/KAT EVAP LAMBDA SAP
SIM0518	E85 Conversion Pops&Bangs Stage1 Stage2 VMAX CAT/KAT DTC Off
SIM0518.1	E85 Conversion Pops&Bangs Stage1
SIM0518.10	E85 Conversion Pops&Bangs Stage1 Stage2 VMAX
SIM0518.2	Stage1 DTC Off
SIM0518.4	Stage1
SIM0518.6	E85 Conversion
SIM0518.X	E85 Conversion Exhaust Valve OFF Launch Control Activation Pops&Bangs Pops&Bangs (Switchable) RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX Active Grill Shutter (AGS) CAT/KAT DPF DTC Off EVAP Farts (GOLF 7 SIMOS18) FLAPS (Swirl) GPF/OPF LAMBDA Readiness Calibration SAP Start-Stop TVA Immo Off (FLASH)
SIM0519.X	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX Adblue CAT/KAT EVAP FLAPS (Swirl) GPF/OPF LAMBDA SAP Start-Stop TVA
SIM052	E85 Conversion Stage1 Stage2
SIM053	E85 Conversion Stage1 Stage2
SIM053.2	Stage1
SIM053.3	E85 Conversion
SIM053.X	E85 Conversion Stage1 Stage2 CAT/KAT EGR LAMBDA
SIM054	Stage1
SIM056.2	E85 Conversion
SIM056.X	E85 Conversion Stage1 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA
SIM057.1	E85 Conversion Stage1
SIM057.X	E85 Conversion Pops&Bangs Stage1 CAT/KAT EGR LAMBDA
SIM058	E85 Conversion Stage1
SIM058.2	E85 Conversion Stage1
SIM058.3	Stage1
SIM058.4	E85 Conversion Stage1 Stage2 VMAX DTC Off LAMBDA
SIM058.5	E85 Conversion Stage1 Stage2 TVA
SIM058.X	E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage2 Stage3 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA SAP TVA

SIMOS9.1	E85 Conversion	Stage1		
SIMOS9.X	E85 Conversion	Stage1	CAT/KAT	LAMBDA
TEMIC	Gearbox Tuning	Stage1	Stage2	DPF

250 ECU

CRD3.X	Adblue
DCM3.5	Stage1
DCM3.7	E85 Conversion Stage1 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA TVA Water Pump
DCM6.2	E85 Conversion Exhaust Valve OFF Stage1 Stage1+ VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Start-Stop Water Pump
DELPHI	Stage1
DL501	Gearbox Tuning Stage1
DQ200	Gearbox Tuning Stage1
DQ200G2	Gearbox Tuning Stage1
DQ250	Gearbox Tuning Launch Control Activation Stage1 Stage1+
DQ381	Gearbox Tuning Pops&Bangs Stage1
DQ38X	Gearbox Tuning Stage1
DQ500	Gearbox Tuning Stage1 Stage2
DSG AL551	Gearbox Tuning Stage1 Stage1+
EDC15	E85 Conversion Hotstart Launch Control Activation Pops&Bangs Stage1 Stage1+ Stage2 Stage3 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) MAF Multimap TVA
EDC15C	Stage1
EDC15C4	Stage1
EDC15C5	Stage1
EDC15C6	Stage1 Stage2
EDC15P	Stage1 Stage2 VMAX MAF
EDC15V	Stage1
EDC15VM	Stage1 Stage2 DPF
EDC15VMP	Stage1
EDC16	E85 Conversion Stage1 Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF
EDC16C0	Stage1 Stage2 DTC Off MAF
EDC16C1	Stage1
EDC16C10	Stage1
EDC16C2	Stage1
EDC16C3	Stage1
EDC16C31	E85 Conversion Stage1 Stage1+ Stage2 DPF DTC Off EGR FLAPS (Swirl) MAF
EDC16C32	E85 Conversion Stage1 Stage2 DPF
EDC16C34	E85 Conversion Stage1 Stage2 VMAX DPF EGR FLAPS (Swirl)
EDC16C35	Stage1 VMAX
EDC16C36	Stage1
EDC16C39	Stage1
EDC16C4	Stage1 Stage2 VMAX EGR
EDC16C7	Stage1
EDC16C8	Stage1
EDC16C9	Stage1
EDC16CAN	Stage1
EDC16CP31	E85 Conversion Stage1 Stage2 DPF
EDC16CP34	E85 Conversion Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA
EDC16CP35	Stage1
EDC16CP36	Stage1 Stage2 DPF
EDC16CP39	Stage1
EDC16CP42	Stage1
EDC16U1	E85 Conversion Gearbox Tuning HardCut Hot Start Fix Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA Immo Off (FLASH)
EDC16U2	Stage1 Stage2
EDC16U2.1	Stage1
EDC16U3	Stage1

EDC16U31	E85 Conversion HardCut Hotstart RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 VMAX DPF DTC Off
	EGR EGT Off FLAPS (Swirl) LAMBDA MAF TVA Immo Off (EPROM)
EDC16U34	E85 Conversion HardCut Hot Start Fix Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX Adblue DPF DTC Off EGR
	FLAPS (Swirl) LAMBDA MAF TVA Immo Off (EPROM)
EDC16UC40	Stage1
EDC16V2	Stage1 DPF EGR
EDC17	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl)
EDC17121	Stage1
EDC17521	Stage1
EDC17C01	Stage1
EDC17C06	Stage1
EDC17C08	Stage1
EDC17C10	Stage1 DPF EGR
EDC17C18	Stage1
EDC17C19	Stage1
EDC17C41	Stage1
EDC17C42	DPF EGR
EDC17C43	Stage1
EDC17C43-CP46	Stage1
EDC17C46	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue CAT/KAT Decat DPF DTC Off
	EGR FLAPS (Swirl) LAMBDA LIMP MAF NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH)
EDC17C49	Stage1 DPF EGR LAMBDA TVA
EDC17C54	E85 Conversion Exhaust Valve OFF Stage1 Stage2 Stage3 Torque Monitor VMAX Adblue DPF DTC Off EGR
	FLAPS (Swirl) LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH)
EDC17C60	Stage1 Adblue DPF
EDC17C64	E85 Conversion Exhaust Valve OFF HardCut Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue
	CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF NOX Readiness Calibration Start-Stop TVA Water Pump
	Immo Off (FLASH) TPROT
EDC17C66	E85 Conversion Stage1
EDC17C69	Stage1
EDC17C74	E85 Conversion HardCut Stage1 Stage1+ Stage2 Torque Monitor VMAX Active Grill Shutter (AGS) Adblue CAT/KAT DPF
	DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH) TPROT
EDC17C79	Stage1
EDC17CP01	Stage1 DPF EGR
EDC17CP02	Stage1 DPF LAMBDA Readiness Calibration
EDC17CP04	E85 Conversion HardCut Stage1 Stage2 Torque Monitor VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA
	Readiness Calibration TVA Immo Off (FLASH)
EDC17CP10	Stage1 Stage2 DPF EGR
EDC17CP11	Stage1
EDC17CP14	E85 Conversion HardCut RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX Adblue
	Decat DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Stage2+ Start-Stop TVA Water Pump
	Immo Off (FLASH)
EDC17CP20	E85 Conversion Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA
	NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH)
EDC17CP24	Exhaust Valve OFF Stage1 Stage2 VMAX Adblue DPF EGR FLAPS (Swirl) LAMBDA Readiness Calibration TVA
EDC17CP42	Stage1
EDC17CP44	E85 Conversion Exhaust Valve OFF HardCut Pops&Bangs Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX
	Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop TVA Immo Off (FLASH)
EDC17CP46	Stage1 Stage2
EDC17CP54	Stage1 Stage2 VMAX Adblue DPF EGR FLAPS (Swirl) LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop TVA
EDC17CP57	Stage1 Stage2 Adblue
EDC17CP74	E85 Conversion Stage1 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop
	TVA Water Pump
EDC17CV52	Stage1
EDC17U01	Stage1 Stage2 DTC Off
EDC17U01-05	Stage1 Stage1+ Stage2 Torque Monitor DPF EGR FLAPS (Swirl) LAMBDA TVA
EDC17U05	Stage1
IAW4MV	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 CAT/KAT DPF EGR LAMBDA
MARELLI	Pops&Bangs Stage1 Stage1+ Stage2 CAT/KAT DTC Off EGR LAMBDA
MD1CP001	Stage1

MD1CP004	Stage1 Stage2 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop TVA
MD1CP014	Stage1 VMAX Adblue DPF EGR FLAPS (Swirl) NOX Start-Stop
MD1CS004	Hotstart Stage1 Stage1+ VMAX Adblue DPF DTC Off EGR LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop
MD1CS006	Stage1 Adblue
MD1CS014	Stage1 Adblue DPF EGR LAMBDA Oil Pressure Fix Start-Stop
MDG1	Stage1
ME17	E85 Conversion Stage1 TVA
ME17.5.2	E85 Conversion Stage1 DTC Off TVA
ME17.5.20	E85 Conversion Stage1 DTC Off TVA
ME17.5.20-26	Cylinder On Demand OFF E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX CAT/KAT DTC Off EGR EVAP LAMBDA Readiness Calibration Immo Off (EPROM) Immo Off (FLASH)
ME17.5.24	Stage1
ME17.5.26	E85 Conversion
ME17.5.2X	Stage1
ME17.5.6	E85 Conversion Pops&Bangs Stage1 Stage2 CAT/KAT DTC Off EVAP LAMBDA Readiness Calibration
ME2.0	Stage1
ME2.7	Stage1
ME2.7.1	Stage1
ME2.7.2	Stage1
ME2.8	Stage1
ME2.8.1	Stage1 Stage2
ME3	Stage1
ME3.8	Stage1 Stage2 DPF
ME3.8.1	Stage1
ME5.2	Stage1
ME5.9.2	Stage1
ME7	E85 Conversion Stage1 Stage2
ME7.1	E85 Conversion Stage1 Stage2 Stage3 VMAX
ME7.1-ME7.1.1	E85 Conversion HardCut Pops&Bangs Stage1 Stage1+ Stage2 Stage3 VMAX Adblue CAT/KAT DPF DTC Off EVAP Ignition Cut LAMBDA
ME7.1.1	E85 Conversion Stage1 Stage2 Stage3 VMAX Decat LAMBDA
ME7.1.5	Stage1
ME7.2	Stage1 Stage2
ME7.3.2	Stage1
ME7.5	Anti-Lag E85 Conversion Launch Control Activation Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 VMAX Adblue CAT/KAT DPF DTC Off EGR EVAP LAMBDA MAF SAP TVA
ME7.5.10	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 CAT/KAT DTC Off EGR EVAP LAMBDA
ME7.8	E85 Conversion Stage1 Stage2
ME7.8.2	Stage1
ME9	Stage1 Stage2
ME9.1	Stage1 Stage2 VMAX
ME9.1.1	Stage1 Stage2
ME9.5	Pops&Bangs Stage1 Stage1+ Stage2 Adblue DTC Off EGR LAMBDA
ME9.7	Stage1 Stage2
MED17	E85 Conversion Pops&Bangs Stage1 VMAX CAT/KAT DPF EGR
MED17.1	E85 Conversion Exhaust Valve OFF HardCut Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA Readiness Calibration SAP TVA TPROT
MED17.1.1	Cylinder On Demand OFF E85 Conversion Exhaust Valve OFF Pops&Bangs Stage1 Stage1+ Stage2 VMAX CAT/KAT DPF DTC Off EVAP FLAPS (Swirl) GPF/OPF LAMBDA Readiness Calibration SAP Start-Stop TVA Immo Off (FLASH)
MED17.1.10	Stage1 Stage2
MED17.1.11	Stage1 Stage2
MED17.1.15	E85 Conversion
MED17.1.2	E85 Conversion Stage1 CAT/KAT EVAP LAMBDA Readiness Calibration
MED17.1.21	E85 Conversion Stage1
MED17.1.27	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX Active Grill Shutter (AGS) CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA
MED17.1.6	Stage1 Stage2
MED17.1.61	Stage1

MED17.1.62	E85 Conversion	Stage1	Stage2																						
MED17.1.63	Stage1																								
MED17.1.6X	E85 Conversion	Pops&Bangs	Pops&Bangs (Switchable)	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	VMAX	Active Grill Shutter (AGS)	Adblue	CAT/KAT	Decat	DPF	DTC Off	EGR	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA	Readiness Calibration	SAP	TVA	Immo Off (FLASH)	
MED17.5	E85 Conversion	Hot Start Fix	Launch Control Activation	Pops&Bangs	Pops&Bangs (Switchable)	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	EVAP	FLAPS (Swirl)	LAMBDA	MAF	Readiness Calibration	TVA	Immo Off (FLASH)	
MED17.5.1	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DTC Off	FLAPS (Swirl)	LAMBDA	Readiness Calibration													
MED17.5.2	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	EVAP	FLAPS (Swirl)	LAMBDA	Readiness Calibration	Start-Stop	TVA											
MED17.5.20	E85 Conversion	Pops&Bangs	Stage1	Stage2																					
MED17.5.20-26	Cylinder On Demand OFF	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DTC Off	EVAP	FLAPS (Swirl)	LAMBDA	Readiness Calibration	TVA	Immo Off (FLASH)									
MED17.5.21	Cylinder On Demand OFF	E85 Conversion	Pops&Bangs	Stage1	Stage2	DTC Off	TVA																		
MED17.5.25	E85 Conversion	Pops&Bangs	Stage1	Stage2	FLAPS (Swirl)	TVA																			
MED17.5.5	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DTC Off	FLAPS (Swirl)	LAMBDA	Readiness Calibration	Start-Stop	TVA	Immo Off (FLASH)										
MED17.5.53	E85 Conversion	Pops&Bangs	Stage1	Stage2	DTC Off																				
MED17.5.X	Stage1	Stage2																							
MED17.6.9	Stage1																								
MED17.7	Stage1	Stage2																							
MED17.7.1	Stage1																								
MED17.7.2	Stage1	Stage2																							
MED17.7.3	Stage1	Stage2																							
MED17.7.3.1	Stage1																								
MED17.7.5	Stage1																								
MED17.7.7	Stage1																								
MED7.5.11	E85 Conversion	Pops&Bangs	Stage1	CAT/KAT	EGR	NOX																			
MED9	E85 Conversion	Stage1																							
MED9.1	E85 Conversion	Exhaust Valve OFF	HardCut	Launch Control Activation	Pops&Bangs	Pops&Bangs (Switchable)	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	CAT/KAT	Cold Start Delete	Decat	DPF	DTC Off	EGR	EVAP	FLAPS (Swirl)	LAMBDA	MAF	TVA	Immo Off (FLASH)
MED9.1.1	E85 Conversion	Stage1	DTC Off																						
MED9.1.2	E85 Conversion	Stage1																							
MED9.1.3	E85 Conversion	Stage1																							
MED9.1.4	E85 Conversion	Stage1																							
MED9.1.5	E85 Conversion	Stage1	Stage2																						
MED9.5	E85 Conversion	Stage1																							
MED9.5.10	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Immo Off (FLASH)										
MED9.6	Stage1																								
MED9.6.1	Stage1	Stage2																							
MED9.7	Stage1																								
MEDC17	Pops&Bangs	Stage1	Stage2	Adblue	DPF	DTC Off	EGR	Immo Off (FLASH)																	
MEDC17521	Stage1																								
MEVD17.2	Stage1																								
MG1CP002	Stage1																								
MG1CP007	Pops&Bangs	Stage1	Stage2	CAT/KAT	EVAP	GPF/OPF	LAMBDA	Start-Stop																	
MG1CS001	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Active Grill Shutter (AGS)	CAT/KAT	EVAP	FLAPS (Swirl)	LAMBDA	SAP													
MG1CS002	E85 Conversion	Exhaust Valve OFF	Pops&Bangs	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	CAT/KAT	DPF	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA	SAP	Start-Stop									
MG1CS008	Exhaust Valve OFF	Pops&Bangs	Stage1	Stage2	CAT/KAT	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA																
MG1CS011	Cylinder On Demand OFF	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Torque Monitor	VMAX	CAT/KAT	EVAP	GPF/OPF	LAMBDA	Start-Stop													
MG1CS031	Pops&Bangs	RPM Soft Limiter Removal	Torque Monitor	CAT/KAT	EVAP	FLAPS (Swirl)	LAMBDA																		
MG1CS111	E85 Conversion	Pops&Bangs	Stage1	Stage1+	VMAX	CAT/KAT	EVAP	GPF/OPF	LAMBDA	Readiness Calibration															
MS6.2	Stage1																								
MSA15	Stage1																								

MSB15	Stage1
PCR2.1	E85 Conversion HardCut Launch Control Activation Pops&Bangs Stage1 Stage1+ Stage2 Stage3 VMAX Adblue Decat DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF Readiness Calibration Start-Stop TVA Water Pump
PPD1.2	DPF
PPD1.X	Hotstart Launch Control Activation Stage1 Stage1+ Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA Immo Off (FLASH)
SDI10	VMAX CAT/KAT LAMBDA
SDI3	CAT/KAT DPF LAMBDA
SDI6/7/8/9	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 CAT/KAT EVAP LAMBDA
SID3	Stage2
SID307	Stage1
SID310	DPF EGR
SID9	Stage1 Stage2
SIM05	Stage1 Stage2 DPF DTC Off Immo Off (FLASH)
SIM0510	E85 Conversion Stage1
SIM0510.10	E85 Conversion Stage1 Stage2 VMAX
SIM0510.12	Stage1
SIM0510.1X	E85 Conversion Stage1
SIM0510.2	Stage1
SIM0510.22	Stage1
SIM0510.23	Stage1
SIM0510.24	Stage1
SIM0510.2X	E85 Conversion Pops&Bangs Stage1 Stage2
SIM0510.X	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX CAT/KAT DPF EGR EVAP FLAPS (Swirl) LAMBDA MAF Start-Stop
SIM0511.X	E85 Conversion Pops&Bangs CAT/KAT EVAP FLAPS (Swirl) LAMBDA
SIM0512	E85 Conversion Pops&Bangs Stage1 Stage2 CAT/KAT DTC Off TVA
SIM0512.1	E85 Conversion Pops&Bangs
SIM0512.2	E85 Conversion Stage1
SIM0512.X	E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA
SIM0516.X	CAT/KAT EVAP LAMBDA SAP
SIM0518	E85 Conversion Pops&Bangs Stage1 Stage2 VMAX CAT/KAT DTC Off
SIM0518.1	E85 Conversion Pops&Bangs Stage1
SIM0518.10	E85 Conversion Pops&Bangs Stage1 Stage2 VMAX
SIM0518.2	Stage1 DTC Off
SIM0518.4	Stage1
SIM0518.6	E85 Conversion
SIM0518.X	E85 Conversion Exhaust Valve OFF Launch Control Activation Pops&Bangs Pops&Bangs (Switchable) RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX Active Grill Shutter (AGS) CAT/KAT DPF DTC Off EVAP Farts (GOLF 7 SIMOS18) FLAPS (Swirl) GPF/OPF LAMBDA Readiness Calibration SAP Start-Stop TVA Immo Off (FLASH)
SIM0519.X	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX Adblue CAT/KAT EVAP FLAPS (Swirl) GPF/OPF LAMBDA SAP Start-Stop TVA
SIM052	E85 Conversion Stage1 Stage2
SIM053	E85 Conversion Stage1 Stage2
SIM053.2	Stage1
SIM053.3	E85 Conversion
SIM053.X	E85 Conversion Stage1 Stage2 CAT/KAT EGR LAMBDA
SIM054	Stage1
SIM056.2	E85 Conversion
SIM056.X	E85 Conversion Stage1 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA
SIM057.1	E85 Conversion Stage1
SIM057.X	E85 Conversion Pops&Bangs Stage1 CAT/KAT EGR LAMBDA
SIM058	E85 Conversion Stage1
SIM058.2	E85 Conversion Stage1
SIM058.3	Stage1
SIM058.4	E85 Conversion Stage1 Stage2 VMAX DTC Off LAMBDA
SIM058.5	E85 Conversion Stage1 Stage2 TVA
SIM058.X	E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage2 Stage3 VMAX CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA SAP TVA

SIMOS9.1	E85 Conversion	Stage1		
SIMOS9.X	E85 Conversion	Stage1	CAT/KAT	LAMBDA
TEMIC	Gearbox Tuning	Stage1	Stage2	DPF

SMART

7 ECU

EDC15	Stage1	Stage1+	Stage2	Stage3	VMAX	EGR	MAF			
EDC15C5	Stage1									
EDC16C31	Stage1	VMAX								
EDC16C31-C32	Stage1	DPF	DTC Off	EGR	MAF					
ME17.9.20	E85 Conversion	Stage1	CAT/KAT	LAMBDA						
ME7.7	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DPF	LAMBDA	TVA
ME7.7.0	Stage1									

SSANGYONG

5 ECU

DCM3.2	Stage1	DPF	EGR					
DCM3.7	Stage1	DPF	EGR	FLAPS (Swirl)				
DCM6.2	Stage1	VMAX	Adblue	DPF	EGR	LAMBDA		
DCM6.X	Stage1							
DELPHI	Stage1							

SUBARU

1 ECU

DIESEL	E85 Conversion	Stage1	DPF	EGR				
--------	----------------	--------	-----	-----	--	--	--	--

SUZUKI

17 ECU

DCM1.2	Stage1							
DENS0	EGR							
DIESEL	Stage1	CAT/KAT	DPF					
EDC15	Stage1	Stage2						
EDC15C2	Stage1	EGR						
EDC16C3	Stage1	VMAX	DPF	EGR	TVA			
EDC16C36	Stage1	DPF	EGR					
EDC16C39	Stage1	DPF	EGR					
EDC17C49	Stage1	Torque Monitor	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA	
ME17	Stage1							
ME17.9.6X	E85 Conversion	Pops&Bangs	Rev Limiter Raise	Stage1	Stage2	VMAX	CAT/KAT	LAMBDA
MED17	Stage1							
MED17.9.63	Stage1	Stage2						
MJD6J0	DPF	EGR	MAF					
MJD8DS	E85 Conversion	Stage1	Adblue	DPF	DTC Off	EGR	LAMBDA	MAF
MM8GSW	Stage1							
SIMOS3.X	EGR							

TATA

1 ECU

EDC17C69	Stage1	Adblue	DPF					
----------	--------	--------	-----	--	--	--	--	--

TOYOTA

247 ECU

89663-02E73	Stage1							
89663-02G31	Stage1							
89663-02G32	Stage1							
89663-02G40	Stage1							
89663-02G41	Stage1							
89663-02G42	Stage1							
89663-02J22	Stage1							
89663-02X72	Stage1							

89663-06A31	Stage1
89663-06A35	Stage1
89663-06A41	Stage1
89663-06A45	Stage1
89663-06B40	Stage1
89663-06D40	Stage1
89663-06E72	Stage1
89663-06E82	Stage1
89663-06F51	Stage1
89663-06N42	Stage1
89663-06N61	Stage1
89663-0C330	Stage1
89663-0C572	Stage1
89663-0C582	Stage1
89663-0C592	Stage1
89663-0C601	Stage1
89663-0C710	Stage1
89663-0C821	Stage1
89663-0C831	Stage1
89663-0C841	Stage1
89663-0C850	Stage1
89663-0C851	Stage1
89663-0C852	Stage1
89663-0C891	Stage1
89663-0CA01	Stage1
89663-0CA11	Stage1
89663-0CA21	Stage1
89663-0CA31	Stage1
89663-0CA41	Stage1
89663-0CA51	Stage1
89663-0CA61	Stage1
89663-0CA71	Stage1
89663-0CA81	Stage1
89663-0CA91	Stage1
89663-0CB01	Stage1
89663-0CC31	Stage1
89663-0CD70	Stage1
89663-0CJ54	Stage1
89663-0CL10	Stage1
89663-0E142	Stage1
89663-0F097	DPF EGR
89663-0F098	DPF EGR
89663-0K121	Stage1 EGR
89663-0K222	Stage1 EGR
89663-0K223	EGR
89663-0K242	EGR
89663-0K873	EGR
89663-0KK91	EGR
89663-0KK93	EGR
89663-0KM60	EGR
89663-0KM61	EGR
89663-0KM63	EGR
89663-0T070	Stage1
89663-0T121	Stage1
89663-0T160	Stage1
89663-0T220	Stage1
89663-30B02	Stage1
89663-30B10	Stage1
89663-30B11	Stage1

89663-30C02	Stage1
89663-30C51	Stage1
89663-30E00	Stage1
89663-30E70	Stage1
89663-30F51	Stage1
89663-30G01	Stage1
89663-30K81	Stage1
89663-30N40	Stage1
89663-30S31	Stage1
89663-33A50	Stage1
89663-33A51	Stage1
89663-33A53	Stage1
89663-33A60	Stage1
89663-33A61	Stage1
89663-33A70	Stage1
89663-33A71	Stage1
89663-33A72	Stage1
89663-33A74	Stage1
89663-33B51	Stage1
89663-33B52	Stage1
89663-33B60	Stage1
89663-33D30	Stage1
89663-33D71	Stage1
89663-33E90	Stage1
89663-33F41	Stage1
89663-33G81	Stage1
89663-33J92	Stage1
89663-33K10	Stage1
89663-33M22	Stage1
89663-33M42	Stage1
89663-42A33	Stage1
89663-42B82	Stage1
89663-42C72	Stage1
89663-42E70	DPF EGR
89663-42F11	Stage1
89663-42F13	Stage1
89663-42F40	Stage1
89663-42L90	Stage1
89663-42M20	Stage1
89663-42M21	Stage1
89663-42N52	Stage1
89663-42N62	Stage1
89663-42Q11	Stage1
89663-42Q21	Stage1
89663-48A01	Stage1
89663-48C10	Stage1
89663-48C30	Stage1
89663-48G00	Stage1
89663-48M50	Stage1
89663-50A90	Stage1
89663-50B91	Stage1
89663-52D02	Stage1
89663-52D30	Stage1
89663-52F01	Stage1
89663-52J01	Stage1
89663-60A31	EGR
89663-60A32	EGR
89663-60A33	EGR
89663-60A34	EGR

89663-60A60	EGR
89663-60A63	EGR
89663-60A70	EGR
89663-60A71	EGR
89663-60A72	EGR
89663-60A73	EGR
89663-60A80	EGR
89663-60A82	EGR
89663-60A83	EGR
89663-60B03	EGR
89663-60B30	EGR
89663-60B81	Stage1
89663-60C00	Stage1
89663-60C01	Stage1
89663-60C02	Stage1
89663-60C03	Stage1
89663-60C21	Stage1
89663-60C22	Stage1
89663-60C26	Stage1
89663-60C30	Stage1
89663-60C32	Stage1
89663-60C34	Stage1
89663-60C35	Stage1
89663-60C51	Stage1
89663-60D00	Stage1
89663-60E10	Stage1
89663-60E62	Stage1
89663-60E64	Stage1
89663-60E70	Stage1
89663-60E72	Stage1
89663-60E74	Stage1
89663-60E80	Stage1
89663-60F32	Stage1
89663-60F42	Stage1
89663-60F52	Stage1
89663-60F91	Stage1
89663-60F92	Stage1
89663-60G00	EGR
89663-60G01	EGR
89663-60G02	EGR
89663-60G03	EGR
89663-60G62	Stage1
89663-60G92	DPF EGR
89663-60J01	EGR
89663-60J10	EGR
89663-60J20	EGR
89663-60J21	EGR
89663-60J30	EGR
89663-60J50	EGR
89663-60J80	EGR
89663-60K01	Stage1
89663-60K40	DPF EGR
89663-60K41	DPF EGR
89663-60K60	EGR
89663-60K62	EGR
89663-60K90	EGR
89663-60K91	EGR
89663-60L20	EGR
89663-60L50	EGR

89663-60L70	Stage1
89663-60M00	Stage1
89663-60M30	Stage1
89663-60M50	Stage1
89663-60M90	EGR
89663-60N40	EGR
89663-60N41	EGR
89663-60N70	EGR
89663-60N71	EGR
89663-60N72	EGR
89663-60N73	EGR
89663-60N74	EGR
89663-60P10	EGR
89663-60P50	Stage1
89663-60P90	DPF EGR
89663-60Q00	Stage1
89663-60Q10	Stage1
89663-60Q60	Stage1
89663-60R00	EGR
89663-60U50	Stage1
89663-60U90	Stage1 DPF EGR
89663-60U91	DPF EGR
89663-60V20	EGR
89663-60V60	EGR
89663-60X26	Stage1 DPF EGR
89663-60Z31	Stage1
89663-6A160	Stage1
89663-F0305	Stage1
89663-F0593	Stage1
89663-YWF06	Stage1
89663-YWF14	Stage1
89663-YWF18	Stage1
89663-YWF25	Stage1
89663-YWF28	Stage1
89663-YWF29	Stage1
89663-YWF34	Stage1
89663-YWL01	Stage1
89663-YWL09	Stage1
89663-YWL11	Stage1
89663-YWL19	Stage1
89663-YWL23	Stage1
DCM6.2	Stage1 Adblue DPF EGR NOX
DCM7.1	Stage1 Adblue DPF EGR
DENS0	DPF DTC Off EGR
DENS0 GEN1	E85 Conversion HardCut Stage1 Stage1+ Stage2 Stage3 VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) TVA Immo Off (FLASH)
DENS0 GEN2	E85 Conversion Stage1 Stage1+ Stage2 VMAX Adblue CAT/KAT DPF EGR FLAPS (Swirl) LAMBDA NOX TVA Immo Off (FLASH)
DENS0 GEN3	Stage1 Adblue CAT/KAT DPF EGR LAMBDA
DIESEL	Stage1 Stage1+ Adblue CAT/KAT DPF EGR FLAPS (Swirl) LAMBDA NOX
EDC15	Stage1
EDC15C9	Stage1 EGR
EDC16C10	Stage1 DPF EGR
EDC16C31	E85 Conversion Stage1 VMAX DPF DTC Off EGR FLAPS (Swirl)
EDC17C01	Stage1
EDC17C47	Launch Control Activation DPF EGR FLAPS (Swirl) LAMBDA TVA
EDC17C60	Stage1 Adblue DPF
EDC17C73	Stage1 Torque Monitor DPF EGR FLAPS (Swirl) LAMBDA TVA
EDC17CP07	Stage1
EDC17CP07-CP37	Stage1 Torque Monitor VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA TVA

ME17.9.52	E85 Conversion	Stage1	CAT/KAT	EGR	LAMBDA
MG1CS201	Stage1	CAT/KAT	GPF/OPF	LAMBDA	
PETROL	Stage1	CAT/KAT	LAMBDA		
SID805	Stage1				

VAUXHALL

64 ECU

DCM3	Stage1
DCM3.7	Stage1 Adblue DPF EGR FLAPS (Swirl) LAMBDA TVA
DCM7.1	VMAX Adblue DPF EGR LAMBDA NOX Start-Stop
DELCO E37	CAT/KAT EVAP LAMBDA
DELCO E38	Stage1 CAT/KAT EVAP LAMBDA
DELCO E39	E85 Conversion Pops&Bangs Stage1 CAT/KAT EVAP LAMBDA
DELCO E78	E85 Conversion Stage1 Stage2 CAT/KAT LAMBDA
DELCO E80-E84	E85 Conversion Stage1 CAT/KAT LAMBDA
DELCO E83	E85 Conversion Stage1 Stage1+ CAT/KAT EGR LAMBDA
DELCO E87	Pops&Bangs Stage1 CAT/KAT DPF EGR FLAPS (Swirl) LAMBDA
DELCO E92	Stage1 CAT/KAT DPF LAMBDA
DELCO E98	E85 Conversion Stage1 Stage2 VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX TVA
DENSO	Stage1 DPF EGR
E98	Stage1
EDC15	Stage1 Stage1+ Stage2 Stage3 DPF EGR MAF
EDC15C2	Stage1
EDC15C4	Stage1
EDC15C7	Stage1
EDC15V	Stage1
EDC15VM	Stage1 Stage2 DPF EGR
EDC16C3	Stage1 Adblue
EDC16C36	E85 Conversion Stage1 VMAX DPF DTC Off EGR
EDC16C39	E85 Conversion Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) MAF TVA
EDC16C9	E85 Conversion Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA
EDC16CP33	Stage1 Stage2 VMAX DPF DTC Off EGR TVA
EDC17	Stage1 VMAX Adblue DPF
EDC17C01	Stage1
EDC17C11	Stage1 Torque Monitor VMAX DPF EGR LAMBDA
EDC17C18	Stage1 Stage2 EGR
EDC17C18-C19	Stage1 Stage1+ Stage2 Torque Monitor VMAX DPF EGR FLAPS (Swirl) Glow Plug LAMBDA TVA
EDC17C19	Stage1 Stage2 DPF
EDC17C42	Stage1 Stage2 Torque Monitor VMAX DPF EGR
EDC17C59	Stage1 Stage1+ Stage2 Torque Monitor VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA TVA
EDC17C60	Stage1
EDC17C84	Torque Monitor VMAX Adblue DPF EGR LAMBDA NOX Start-Stop TVA
EDC17CP47	Stage1 Torque Monitor Adblue DPF EGR FLAPS (Swirl) LAMBDA TVA
EMS040	DTC Off
MARELLI	Stage1 Stage2 Adblue DPF DTC Off EGR
MD1CS003	Stage1 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA Start-Stop TPROT
ME1.5.5	E85 Conversion Stage1 Stage1+ Stage2 Stage3 CAT/KAT EGR LAMBDA
ME17.8.8	CAT/KAT EVAP LAMBDA
ME3.1.1	Stage1
ME7.6.2	E85 Conversion Stage1 Stage2
ME7.6.3	Stage1 Stage2
ME7.6.4	Stage1
ME7.6.X	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 CAT/KAT DTC Off EVAP FLAPS (Swirl) LAMBDA
ME7.9.9	Stage1
ME9	Stage1
ME9.1	Stage1
ME9.5	Stage1
ME9.6	Stage1 Stage2 DTC Off

ME9.6.1	Stage1
MED9	Stage1
MED9.6.1	Stage1
MG1CS042	Stage1
MJD602-3	HardCut Stage1 Stage1+ Stage2 Adblue DPF EGR MAF
MS56	Stage1
MT35	E85 Conversion Stage1 Stage2 Stage3 CAT/KAT DTC Off EGR EVAP LAMBDA
MT80	CAT/KAT LAMBDA
PSG16	Stage1 DPF DTC Off EGR FLAPS (Swirl) TVA
SH7059	Stage1
SID310	Stage1
SIMTEC7.5	Stage1 CAT/KAT LAMBDA
SIMTEC76	E85 Conversion Stage1 CAT/KAT EGR LAMBDA

VOLKSWAGEN

250 ECU

CRD3.X	Adblue
DCM3.5	Stage1
DCM3.7	E85 Conversion Stage1 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA TVA Water Pump
DCM6.2	E85 Conversion Exhaust Valve OFF Stage1 Stage1+ VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Start-Stop Water Pump
DELPHI	Stage1
DL501	Gearbox Tuning Stage1
DQ200	Gearbox Tuning Stage1
DQ200G2	Gearbox Tuning Stage1
DQ250	Gearbox Tuning Launch Control Activation Stage1 Stage1+
DQ381	Gearbox Tuning Pops&Bangs Stage1
DQ38X	Gearbox Tuning Stage1
DQ500	Gearbox Tuning Stage1 Stage2
DSG AL551	Gearbox Tuning Stage1 Stage1+
EDC15	E85 Conversion Hotstart Launch Control Activation Pops&Bangs Stage1 Stage1+ Stage2 Stage3 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) MAF Multimap TVA
EDC15C	Stage1
EDC15C4	Stage1
EDC15C5	Stage1
EDC15C6	Stage1 Stage2
EDC15P	Stage1 Stage2 VMAX MAF
EDC15V	Stage1
EDC15VM	Stage1 Stage2 DPF
EDC15VMP	Stage1
EDC16	E85 Conversion Stage1 Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF
EDC16C0	Stage1 Stage2 DTC Off MAF
EDC16C1	Stage1
EDC16C10	Stage1
EDC16C2	Stage1
EDC16C3	Stage1
EDC16C31	E85 Conversion Stage1 Stage1+ Stage2 DPF DTC Off EGR FLAPS (Swirl) MAF
EDC16C32	E85 Conversion Stage1 Stage2 DPF
EDC16C34	E85 Conversion Stage1 Stage2 VMAX DPF EGR FLAPS (Swirl)
EDC16C35	Stage1 VMAX
EDC16C36	Stage1
EDC16C39	Stage1
EDC16C4	Stage1 Stage2 VMAX EGR
EDC16C7	Stage1
EDC16C8	Stage1
EDC16C9	Stage1
EDC16CAN	Stage1
EDC16CP31	E85 Conversion Stage1 Stage2 DPF
EDC16CP34	E85 Conversion Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA

EDC16CP35	Stage1
EDC16CP36	Stage1 Stage2 DPF
EDC16CP39	Stage1
EDC16CP42	Stage1
EDC16U1	E85 Conversion Gearbox Tuning HardCut Hot Start Fix Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA Immo Off (FLASH)
EDC16U2	Stage1 Stage2
EDC16U2.1	Stage1
EDC16U3	Stage1
EDC16U31	E85 Conversion HardCut Hotstart RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 VMAX DPF DTC Off EGR EGT Off FLAPS (Swirl) LAMBDA MAF TVA Immo Off (EPROM)
EDC16U34	E85 Conversion HardCut Hot Start Fix Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA Immo Off (EPROM)
EDC16UC40	Stage1
EDC16V2	Stage1 DPF EGR
EDC17	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl)
EDC17121	Stage1
EDC17521	Stage1
EDC17C01	Stage1
EDC17C06	Stage1
EDC17C08	Stage1
EDC17C10	Stage1 DPF EGR
EDC17C18	Stage1
EDC17C19	Stage1
EDC17C41	Stage1
EDC17C42	DPF EGR
EDC17C43	Stage1
EDC17C43-CP46	Stage1
EDC17C46	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue CAT/KAT Decat DPF DTC Off EGR FLAPS (Swirl) LAMBDA LIMP MAF NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH)
EDC17C49	Stage1 DPF EGR LAMBDA TVA
EDC17C54	E85 Conversion Exhaust Valve OFF Stage1 Stage2 Stage3 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH)
EDC17C60	Stage1 Adblue DPF
EDC17C64	E85 Conversion Exhaust Valve OFF HardCut Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH) TPROT
EDC17C66	E85 Conversion Stage1
EDC17C69	Stage1
EDC17C74	E85 Conversion HardCut Stage1 Stage1+ Stage2 Torque Monitor VMAX Active Grill Shutter (AGS) Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH) TPROT
EDC17C79	Stage1
EDC17CP01	Stage1 DPF EGR
EDC17CP02	Stage1 DPF LAMBDA Readiness Calibration
EDC17CP04	E85 Conversion HardCut Stage1 Stage2 Torque Monitor VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA Readiness Calibration TVA Immo Off (FLASH)
EDC17CP10	Stage1 Stage2 DPF EGR
EDC17CP11	Stage1
EDC17CP14	E85 Conversion HardCut RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX Adblue Decat DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Stage2+ Start-Stop TVA Water Pump Immo Off (FLASH)
EDC17CP20	E85 Conversion Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH)
EDC17CP24	Exhaust Valve OFF Stage1 Stage2 VMAX Adblue DPF EGR FLAPS (Swirl) LAMBDA Readiness Calibration TVA
EDC17CP42	Stage1
EDC17CP44	E85 Conversion Exhaust Valve OFF HardCut Pops&Bangs Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop TVA Immo Off (FLASH)
EDC17CP46	Stage1 Stage2
EDC17CP54	Stage1 Stage2 VMAX Adblue DPF EGR FLAPS (Swirl) LAMBDA NOX Oil Pressure Fix Readiness Calibration Start-Stop TVA
EDC17CP57	Stage1 Stage2 Adblue

EDC17CP74	E85 Conversion	Stage1	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop
	TVA	Water Pump										
EDC17CV52	Stage1											
EDC17U01	Stage1	Stage2		DTC Off								
EDC17U01-05	Stage1	Stage1+	Stage2	Torque Monitor	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA			
EDC17U05	Stage1											
IAW4MV	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	CAT/KAT	DPF	EGR	LAMBDA			
MARELLI	Pops&Bangs	Stage1	Stage1+	Stage2	CAT/KAT	DTC Off	EGR	LAMBDA				
MD1CP001	Stage1											
MD1CP004	Stage1	Stage2	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Oil Pressure Fix
	Readiness Calibration	Start-Stop	TVA									
MD1CP014	Stage1	VMAX	Adblue	DPF	EGR	FLAPS (Swirl)	NOX	Start-Stop				
MD1CS004	Hotstart	Stage1	Stage1+	VMAX	Adblue	DPF	DTC Off	EGR	LAMBDA	NOX	Oil Pressure Fix	Readiness Calibration
	Start-Stop											
MD1CS006	Stage1	Adblue										
MD1CS014	Stage1	Adblue	DPF	EGR	LAMBDA	Oil Pressure Fix	Start-Stop					
MDG1	Stage1											
ME17	E85 Conversion	Stage1	TVA									
ME17.5.2	E85 Conversion	Stage1	DTC Off	TVA								
ME17.5.20	E85 Conversion	Stage1	DTC Off	TVA								
ME17.5.20-26	Cylinder On Demand OFF	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT			
	DTC Off	EGR	EVAP	LAMBDA	Readiness Calibration	Immo Off (EPROM)	Immo Off (FLASH)					
ME17.5.24	Stage1											
ME17.5.26	E85 Conversion											
ME17.5.2X	Stage1											
ME17.5.6	E85 Conversion	Pops&Bangs	Stage1	Stage2	CAT/KAT	DTC Off	EVAP	LAMBDA	Readiness Calibration			
ME2.0	Stage1											
ME2.7	Stage1											
ME2.7.1	Stage1											
ME2.7.2	Stage1											
ME2.8	Stage1											
ME2.8.1	Stage1	Stage2										
ME3	Stage1											
ME3.8	Stage1	Stage2	DPF									
ME3.8.1	Stage1											
ME5.2	Stage1											
ME5.9.2	Stage1											
ME7	E85 Conversion	Stage1	Stage2									
ME7.1	E85 Conversion	Stage1	Stage2	Stage3	VMAX							
ME7.1-ME7.1.1	E85 Conversion	HardCut	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	CAT/KAT	DPF	DTC Off
	Ignition Cut	LAMBDA										
ME7.1.1	E85 Conversion	Stage1	Stage2	Stage3	VMAX	Decat	LAMBDA					
ME7.1.5	Stage1											
ME7.2	Stage1	Stage2										
ME7.3.2	Stage1											
ME7.5	Anti-Lag	E85 Conversion	Launch Control Activation	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2				
	Stage3	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	EVAP	LAMBDA	MAF	SAP	TVA
ME7.5.10	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	CAT/KAT	DTC Off	EGR	EVAP	LAMBDA		
ME7.8	E85 Conversion	Stage1	Stage2									
ME7.8.2	Stage1											
ME9	Stage1	Stage2										
ME9.1	Stage1	Stage2	VMAX									
ME9.1.1	Stage1	Stage2										
ME9.5	Pops&Bangs	Stage1	Stage1+	Stage2	Adblue	DTC Off	EGR	LAMBDA				
ME9.7	Stage1	Stage2										
MED17	E85 Conversion	Pops&Bangs	Stage1	VMAX	CAT/KAT	DPF	EGR					
MED17.1	E85 Conversion	Exhaust Valve OFF	HardCut	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX			
	CAT/KAT	DTC Off	EVAP	FLAPS (Swirl)	LAMBDA	Readiness Calibration	SAP	TVA	TPROT			
MED17.1.1	Cylinder On Demand OFF	E85 Conversion	Exhaust Valve OFF	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DPF		
	DTC Off	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA	Readiness Calibration	SAP	Start-Stop	TVA	Immo Off (FLASH)		

MED17.1.10	Stage1	Stage2																							
MED17.1.11	Stage1	Stage2																							
MED17.1.15	E85 Conversion																								
MED17.1.2	E85 Conversion	Stage1	CAT/KAT	EVAP	LAMBDA	Readiness Calibration																			
MED17.1.21	E85 Conversion	Stage1																							
MED17.1.27	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Active Grill Shutter (AGS)	CAT/KAT	DTC Off	EVAP	FLAPS (Swirl)	LAMBDA													
MED17.1.6	Stage1	Stage2																							
MED17.1.61	Stage1																								
MED17.1.62	E85 Conversion	Stage1	Stage2																						
MED17.1.63	Stage1																								
MED17.1.6X	E85 Conversion	Pops&Bangs	Pops&Bangs (Switchable)	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	VMAX	Active Grill Shutter (AGS)	Adblue	CAT/KAT	Decat	DPF	DTC Off	EGR	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA	Readiness Calibration	SAP	TVA	Immo Off (FLASH)	
MED17.5	E85 Conversion	Hot Start Fix	Launch Control Activation	Pops&Bangs	Pops&Bangs (Switchable)	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	EVAP	FLAPS (Swirl)	LAMBDA	MAF	Readiness Calibration	TVA	Immo Off (FLASH)	
MED17.5.1	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DTC Off	FLAPS (Swirl)	LAMBDA	Readiness Calibration													
MED17.5.2	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	EVAP	FLAPS (Swirl)	LAMBDA	Readiness Calibration	Start-Stop	TVA											
MED17.5.20	E85 Conversion	Pops&Bangs	Stage1	Stage2																					
MED17.5.20-26	Cylinder On Demand OFF	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DTC Off	EVAP	FLAPS (Swirl)	LAMBDA	Readiness Calibration	TVA	Immo Off (FLASH)									
MED17.5.21	Cylinder On Demand OFF	E85 Conversion	Pops&Bangs	Stage1	Stage2	DTC Off	TVA																		
MED17.5.25	E85 Conversion	Pops&Bangs	Stage1	Stage2	FLAPS (Swirl)	TVA																			
MED17.5.5	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DTC Off	FLAPS (Swirl)	LAMBDA	Readiness Calibration	Start-Stop	TVA	Immo Off (FLASH)										
MED17.5.53	E85 Conversion	Pops&Bangs	Stage1	Stage2	DTC Off																				
MED17.5.X	Stage1	Stage2																							
MED17.6.9	Stage1																								
MED17.7	Stage1	Stage2																							
MED17.7.1	Stage1																								
MED17.7.2	Stage1	Stage2																							
MED17.7.3	Stage1	Stage2																							
MED17.7.3.1	Stage1																								
MED17.7.5	Stage1																								
MED17.7.7	Stage1																								
MED7.5.11	E85 Conversion	Pops&Bangs	Stage1	CAT/KAT	EGR	NOX																			
MED9	E85 Conversion	Stage1																							
MED9.1	E85 Conversion	Exhaust Valve OFF	HardCut	Launch Control Activation	Pops&Bangs	Pops&Bangs (Switchable)	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	CAT/KAT	Cold Start Delete	Decat	DPF	DTC Off	EGR	EVAP	FLAPS (Swirl)	LAMBDA	MAF	TVA	Immo Off (FLASH)
MED9.1.1	E85 Conversion	Stage1	DTC Off																						
MED9.1.2	E85 Conversion	Stage1																							
MED9.1.3	E85 Conversion	Stage1																							
MED9.1.4	E85 Conversion	Stage1																							
MED9.1.5	E85 Conversion	Stage1	Stage2																						
MED9.5	E85 Conversion	Stage1																							
MED9.5.10	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Immo Off (FLASH)										
MED9.6	Stage1																								
MED9.6.1	Stage1	Stage2																							
MED9.7	Stage1																								
MEDC17	Pops&Bangs	Stage1	Stage2	Adblue	DPF	DTC Off	EGR	Immo Off (FLASH)																	
MEDC17521	Stage1																								
MEVD17.2	Stage1																								
MG1CP002	Stage1																								
MG1CP007	Pops&Bangs	Stage1	Stage2	CAT/KAT	EVAP	GPF/OPF	LAMBDA	Start-Stop																	
MG1CS001	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Active Grill Shutter (AGS)	CAT/KAT	EVAP	FLAPS (Swirl)	LAMBDA	SAP													

MG1CS002	E85 Conversion	Exhaust Valve OFF	Pops&Bangs	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	CAT/KAT	DPF	EVAP
	FLAPS (Swirl)	GPF/OPF	LAMBDA	SAP	Start-Stop						
MG1CS008	Exhaust Valve OFF	Pops&Bangs	Stage1	Stage2	CAT/KAT	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA		
MG1CS011	Cylinder On Demand OFF	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Torque Monitor	VMAX	CAT/KAT	EVAP	GPF/OPF	
	LAMBDA	Start-Stop									
MG1CS031	Pops&Bangs	RPM Soft Limiter Removal	Torque Monitor	CAT/KAT	EVAP	FLAPS (Swirl)	LAMBDA				
MG1CS111	E85 Conversion	Pops&Bangs	Stage1	Stage1+	VMAX	CAT/KAT	EVAP	GPF/OPF	LAMBDA	Readiness Calibration	
MS6.2	Stage1										
MSA15	Stage1										
MSB15	Stage1										
PCR2.1	E85 Conversion	HardCut	Launch Control Activation	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	
	Decat	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	Readiness Calibration	Start-Stop	TVA	Water Pump
PPD1.2	DPF										
PPD1.X	Hotstart	Launch Control Activation	Stage1	Stage1+	Stage2	Stage3	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)
	MAF	TVA	Immo Off (FLASH)								
SDI10	VMAX	CAT/KAT	LAMBDA								
SDI3	CAT/KAT	DPF	LAMBDA								
SDI6/7/8/9	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	CAT/KAT	EVAP	LAMBDA			
SID3	Stage2										
SID307	Stage1										
SID310	DPF	EGR									
SID9	Stage1	Stage2									
SIM05	Stage1	Stage2	DPF	DTC Off	Immo Off (FLASH)						
SIM0S10	E85 Conversion	Stage1									
SIM0S10.10	E85 Conversion	Stage1	Stage2	VMAX							
SIM0S10.12	Stage1										
SIM0S10.1X	E85 Conversion	Stage1									
SIM0S10.2	Stage1										
SIM0S10.22	Stage1										
SIM0S10.23	Stage1										
SIM0S10.24	Stage1										
SIM0S10.2X	E85 Conversion	Pops&Bangs	Stage1	Stage2							
SIM0S10.X	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DPF	EGR	EVAP	FLAPS (Swirl)
	Start-Stop										
SIM0S11.X	E85 Conversion	Pops&Bangs	CAT/KAT	EVAP	FLAPS (Swirl)	LAMBDA					
SIM0S12	E85 Conversion	Pops&Bangs	Stage1	Stage2	CAT/KAT	DTC Off	TVA				
SIM0S12.1	E85 Conversion	Pops&Bangs									
SIM0S12.2	E85 Conversion	Stage1									
SIM0S12.X	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	VMAX	CAT/KAT	DTC Off	EVAP
	FLAPS (Swirl)	LAMBDA									
SIM0S16.X	CAT/KAT	EVAP	LAMBDA	SAP							
SIM0S18	E85 Conversion	Pops&Bangs	Stage1	Stage2	VMAX	CAT/KAT	DTC Off				
SIM0S18.1	E85 Conversion	Pops&Bangs	Stage1								
SIM0S18.10	E85 Conversion	Pops&Bangs	Stage1	Stage2	VMAX						
SIM0S18.2	Stage1	DTC Off									
SIM0S18.4	Stage1										
SIM0S18.6	E85 Conversion										
SIM0S18.X	E85 Conversion	Exhaust Valve OFF	Launch Control Activation	Pops&Bangs	Pops&Bangs (Switchable)	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	Active Grill Shutter (AGS)
	GPF/OPF	LAMBDA	Readiness Calibration	SAP	Start-Stop	TVA	Immo Off (FLASH)	DPF	DTC Off	EVAP	Farts (GOLF 7 SIM0S18)
SIM0S19.X	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	Adblue	CAT/KAT	EVAP	FLAPS (Swirl)	GPF/OPF
	SAP	Start-Stop	TVA								
SIM0S2	E85 Conversion	Stage1	Stage2								
SIM0S3	E85 Conversion	Stage1	Stage2								
SIM0S3.2	Stage1										
SIM0S3.3	E85 Conversion										
SIM0S3.X	E85 Conversion	Stage1	Stage2	CAT/KAT	EGR	LAMBDA					
SIM0S4	Stage1										
SIM0S6.2	E85 Conversion										
SIM0S6.X	E85 Conversion	Stage1	VMAX	CAT/KAT	DTC Off	EVAP	FLAPS (Swirl)	LAMBDA			

SIMOS7.1	E85 Conversion	Stage1				
SIMOS7.X	E85 Conversion	Pops&Bangs	Stage1	CAT/KAT	EGR	LAMBDA
SIMOS8	E85 Conversion	Stage1				
SIMOS8.2	E85 Conversion	Stage1				
SIMOS8.3	Stage1					
SIMOS8.4	E85 Conversion	Stage1	Stage2	VMAX	DTC Off	LAMBDA
SIMOS8.5	E85 Conversion	Stage1	Stage2	TVA		
SIMOS8.X	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage2	Stage3
			VMAX	CAT/KAT	DTC Off	EVAP
	FLAPS (Swirl)	LAMBDA	SAP	TVA		
SIMOS9.1	E85 Conversion	Stage1				
SIMOS9.X	E85 Conversion	Stage1	CAT/KAT	LAMBDA		
TEMIC	Gearbox Tuning	Stage1	Stage2	DPF		

VOLVO

32 ECU

(VEA-VED) VERSION1	Stage1	DPF	EGR	FLAPS (Swirl)	LAMBDA							
DENSO	EGR	TVA										
EDC15	E85 Conversion	Stage1	Stage2	EGR								
EDC15C11	Stage1	EGR										
EDC15C2	Stage1	Stage2										
EDC15C3	Stage1											
EDC15VM	Stage1											
EDC16	Stage1	Stage2	DPF	MAF								
EDC16C31	E85 Conversion	Stage1	Stage1+	Stage2	Stage3	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	MAF	TVA
EDC16C34	E85 Conversion	Stage1	Stage2	VMAX	DPF	EGR	MAF					
EDC17CP22	Stage1	Torque Monitor	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA					
EDC17CP48	Stage1	Stage2	Torque Monitor	DPF	DTC Off	EGR	LAMBDA	Immo Off (FLASH)				
EDC17CP68	Stage1	Torque Monitor	DPF	EGR	FLAPS (Swirl)	LAMBDA						
EMS2	E85 Conversion											
EMS2000	Stage1	DTC Off										
EMS22	DPF											
ME7	Stage1	Stage2										
ME7.0	E85 Conversion	Stage1	Stage1+									
ME7.0.1	Stage1	LAMBDA										
ME9	Stage1	Stage2										
ME9.0	Stage1											
ME9.0C	Stage1	Stage1+	Stage2	Stage3	CAT/KAT	LAMBDA						
ME9.7	Stage1											
MED17	Stage1	Stage2										
MED17.0	E85 Conversion	Stage1	VMAX	LAMBDA	MAF							
MED17.1.9	Stage1											
MG1CS080	Stage1	CAT/KAT	EVAP	LAMBDA								
SID206	DPF	DTC Off	EGR									
SID803	Stage1	DPF										
SID803A	Stage1	VMAX	DPF	EGR								
SID807	Stage1											
SID807-807EVO	Stage1	VMAX	DPF	EGR								